




STM32CubeIDE user guide

Introduction

STM32CubeIDE is an all-in-one multi-OS development tool, and is part of the STM32Cube software ecosystem. It contains an advanced C/C++ development platform supporting software development of STM32-based products.

This document details the STM32CubeIDE features and usage, including how to get started, create and build projects, debug with standard and advanced techniques, and many other software analysis solutions. STM32CubeIDE is based on the Eclipse C/C++ Development Tools™ (CDT™) and GCC toolchain, which cannot be entirely described in this user manual. Additional information on Eclipse® is available from the STM32CubeIDE embedded help system. Special documents covering the details of the toolchain and GDB servers are included within the product.



1 Getting started

STM32CubeIDE supports STM32 products based on the Arm® Cortex® processor. Refer to STMicroelectronics documents listed in [Section 6: References](#) for details.

Note: Arm is a registered trademark of Arm Limited (or its subsidiaries) in the US and/or elsewhere.

1.1 Product information


STM32CubeIDE is an advanced C/C++ development platform with peripheral configuration, code generation, code compilation, linking, and debug features. It is based on the Eclipse®/CDT™ framework and GCC toolchain for the development, and GDB for the debugging. It allows the integration of the hundreds of existing plugins that complete the features of the Eclipse® IDE.

STM32CubeIDE integrates ST MCUFinder (ST-MCU-FINDER-PC) and STM32CubeMX functionalities to offer all-in-one tool experience. It makes it easy to create new STM32 MCU or board projects and build them using the included GCC toolchain.

STM32CubeIDE includes a build analyzer and a static stack analyzer that provide the user with useful information about project status and memory requirements.

STM32CubeIDE also includes standard and advanced debugging features including views of CPU core registers, memories, and peripheral registers, as well as live variable watch, and serial wire viewer interface. A fault analyzer displays error information if an error is triggered by the STM32 processor during a debug session.

Figure 1. STM32CubeIDE key features



Legend:

Specific STM32CubeIDE functions	Open-based updated by ST	Base technology platform
STM32CubeIDE main function groups	Third-party solutions	Operating systems

DT64654V1

1.1.1 System requirements

STM32CubeIDE is tested and verified on the Microsoft® Windows®, Linux®, and macOS® operating systems.

Important: STM32CubeIDE supports only 64-bit OS versions. For more details about supported versions of operating systems, refer to [ST-02].

Note: Microsoft and Windows are trademarks of the Microsoft group of companies.
 Linux® is a registered trademark of Linus Torvalds.
 macOS® is a trademark of Apple Inc., registered in the U.S. and other countries and regions.

1.1.2 Downloading the latest STM32CubeIDE version

The latest version of STM32CubeIDE is available for free download from the www.st.com/stm32softwaretools website.

1.1.3 Installing STM32CubeIDE

The STM32CubeIDE installation guide [ST-04] gives directions on how to install on supported versions of Windows®, Linux® and macOS®. It is possible to have several versions of STM32CubeIDE installed in parallel. Read the installation guide if STM32CubeIDE is not already installed or if a new version must be installed. Installing updates and additional Eclipse® plugins in this manual also provides information on how to install updates.

1.1.4 License

STM32CubeIDE is delivered under the *Mix Ultimate Liberty+OSS+3rd-party V1* software license agreement (SLA0048).

For more details about the license agreement of each component, refer to [ST-02].

1.1.5 Support

There are several different support options provided by STMicroelectronics. For instance, the ST Community is offering places to meet people with similar mind-set all over the world at any time. Choose the support option by visiting www.st.com/content/st_com/en/support/support-home.html.

1.2 Using STM32CubeIDE

1.2.1 Basic concepts and terminology

The basic concepts using STM32CubeIDE and Eclipse® terminology are outlined in this section.

Workspaces

When starting STM32CubeIDE, a workspace is selected. The workspace contains the development environment to be used. Technically, the workspace is a directory that may hold projects. The user may access any project within the active workspace.

A project contains files, which may be organized into sub-directories. Files existing somewhere else on the computer can also be linked to the project.

A single computer may hold several workspaces at various locations in the file system. The user may switch between workspaces, but only one workspace can be active at a time. Switching workspace is a quick way of switching from one set of projects to another.

In practice, the workspace and project model facilitate a well-structured hierarchy of workspaces, containing projects, which in turn contain files.

Information center

The first time STM32CubeIDE is started and a workspace is selected, the *Information Center* is opened. The *Information Center* provides quick access to start a new project, get access to videos, read STM32CubeIDE documentation, or get access to ST support and community. The *Information Center* can be easily accessed at any time via the *Information Center* toolbar button or from the *Help* menu.

Perspectives, menu bar, toolbar

When the *Information Center* is closed, STM32CubeIDE displays a perspective, which contains a menu bar, toolbar, views and editors. Each perspective is optimized for a special type of work. For instance, the *C/C++ perspective* is meant for creating, editing and building projects. The *Debug perspective* is intended to be used when debugging code on hardware.

Each perspective can be customized according to the user's need. It is possible to reset the perspective at any time if, for instance, too many views are opened or if the views are reordered. It is also possible to create new perspectives.


Views and editors

A perspective normally displays many views. Each view is developed to present specific information, which for instance can be collected from the project or from an embedded system under debug.

A perspective has one editor area. The editor can be used to edit project files. Many files can be edited in different tabs in the editor.

STM32CubeIDE window

Figure 2. STM32CubeIDE window



1.2.2 Starting STM32CubeIDE

Start **STM32CubeIDE** by performing the following steps depending on the operating system used.

Windows®

If a desktop shortcut is created during the installation of the product, the shortcut can be used to start STM32CubeIDE. The product can also be started from the Windows® start menu under STMicroelectronics programs.

Otherwise:

1. Locate where STM32CubeIDE is installed, for instance in `C:\ST\STM32CubeIDE_1.0.2`
2. Open the STM32CubeIDE folder
3. Start the `stm32cubeide.exe` program

Linux® or macOS®


When using Linux® or macOS®, the program can be started in a similar way by opening the STM32CubeIDE folder where the product is installed.

STM32CubeIDE Launcher

When the product is started, it displays the *STM32CubeIDE Launcher* dialog with workspace selection. The first time the product is started, it presents a default location and workspace name. The dialog enables the user to select the name and location of the active workspace for holding all the projects currently accessible by the user. Any newly created project is stored in this workspace. The workspace is created if it does not yet exist.

Note: If Windows® is used, avoid locating the workspace folder too many levels below the file system root to avoid exceeding the Windows® path length character limitations. Build errors occur if the file paths become longer than what Windows® can handle.

Figure 3. STM32CubeIDE Launcher – Workspace selection




Click on the **[Launch]** button to launch STM32CubeIDE. The first time, it opens the *Information Center*, which is described in [Section 1.3: Information Center](#).

1.2.3 STM32CubeIDE user authentication

User authentication allows the users to log in using their my.st.com (myST) credentials once registered. This functionality is available through the menu **[Help]>[STM32Cube updates]>[Connection to myST]**.

Figure 4. Connection to myST menu




DT72084V3

User authentication requires that STM32CubeIDE is connected to the Internet. To configure and check the Internet connection, first select **[Windows]>[Preferences]>[Network Setting]**, and then check the connection through the **[Check Connection]** button under **[Windows]>[Preferences]>[STM32Cube]>[Firmware Updater]**.

Once the **[Check connection]** step is done successfully, click on **[Help]>[STM32Cube updates]>[Connection to myST]**. A window is then displayed to login or logout depending on the authentication status. If the user is not already logged in, the window features the button **[Enter myST account information]** as shown in Figure 5. The user must click on this button to launch the authentication steps.

Figure 5. Connection to myST window



DT76504V1

Once the button **[Enter myST account information]** is clicked, a new window is displayed to create an account (if not yet registered) and log in.

Create a my.st.com account

The creation of an account is proposed within STM32CubeIDE:

- Click on the **[Create Account]** button
- Fill the account creation form
- Click on the **[Register]** button to create a new my.st.com account

Sign in to a my.st.com account

Once registered, use the my.st.com credentials to log in:

- Enter the email address and password
- Tick the checkbox **[Remember me on this computer]** to maintain the authentication for the next sessions
- Click on the **[Login]** button

Figure 6. Registration or login window

The window is titled "User Authentication Dialog" and contains two main sections: "Already registered?" and "New user?".

Already registered?

Enter your e-mail address and password to login your myST user.

E-mail address

your_email@domaine_name

Password

.....

☐ Remember me on this computer. ⓘ

Login

Forgot password?

New user?

myST brings you a set of personalized features:

- Participate to ST Events
- Stay informed with ST eNewsletters
- Get help with ST Online Support
- Discuss on the ST Community
- Benefit from our Online Design Tools
- Download Software
- Order free samples
- Manage your weekly product updates
- Buy ST Products & Tools

Create Account

A yellow "Feedback" button is located on the right side of the window.

DT72085V2

After a verification of the account in the same menu, the button becomes **[Clear myST account information for this session]** if the user has not checked **[Remember me on this computer]**. This indicates that the authentication was successfully performed with the stored credentials and that the network is operational.

Figure 7. Authentication window from the current session

The window is titled "IDE Connection to myST" and contains a message box with the following text:


STM32CubeIDE downloads software components from st.com for project configuration and code generation. Those downloads require your myST account information. You can remove those information from STM32CubeIDE with the clear button.

Clear myST account information for this session

DT76505V1

Otherwise, if the user has checked **[Remember me on this computer]** to maintain the authentication for the next sessions, the button becomes **[Clear myST account information for this computer]**.

Figure 8. Authentication window from the computer



DT76506V1

Access from artifact download panels

The authentication enables the advanced use of STM32CubeIDE. For instance, after a successful authentication, the user can install an STM32Cube MCU Package:

- From outside the project via the help, shortcut, or example selection menus
- Inside the project, when generating the code or loading the `.ioc` file that recommends downloading the MCU Package

Software installation is impossible without authentication.

Offline work

In many cases, users need to work without being connected to the Internet. STM32CubeIDE makes this possible by following these instructions:

- Manually download the needed STM32Cube firmware packages from the STMicroelectronics website www.st.com
- Inside STM32CubeIDE, use the following menus:
 1. **[Help]>[Manage embedded software packages]**
 2. **[STM32Cube MCU Packages]>[From local...]**
- Point to the manually downloaded zip file, then accept the license and install it


1.2.4

Help system

The **[Help]** menu provides several different help systems as seen in [Figure 9](#). The *Information Center* contains links to all available STM32CubeIDE documentation. It is also recommended for new users to try different Eclipse® built-in help systems to get an understanding of Eclipse® basics.

The **[Help]** menu also gives access to two important submenus:

- **[STM32Cube updates]**
 - **[Connection to myST]**
 - **[Check for Target Selector Device Database Updates]**
 - **[Check for Embedded Software Package Updates]**
- **[Configuration Tool]**
 - **[Manage Embedded Software Package]**
 - **[Target Device Docs and Resources]**

Figure 9. Help menu


DT64657V4

1.3 Information Center


The *Information Center* provides quick access to:

1. Start a new project
2. Import an existing project
3. Get access to videos
4. Read [STM32CubeIDE](#) documentation
5. Get access to *Getting Started with STM32CubeIDE* (*STM32CubeIDE quick start guide* [ST-03])
6. Explore the STM32 MPU and MCU wikis
7. Get access to STMicroelectronics support and community on Twitter™, Facebook™, YouTube™, or ST community at community.st.com
8. Explore the STMicroelectronics application tools

It is not required to read all material before using the product for the first time. Rather, it is recommended to consider the *Information Center* as a collection of reference information to return to, whenever required.

1.3.1 Accessing the Information Center


The *Information Center* can easily be accessed at any time, from any perspective, using the [Information Center] toolbar button . This icon is located at the right of the toolbar. It is also possible to open the *Information Center* from the [Help]>[Information Center] menu command.


Figure 10. Help - Information Center menu


1.3.2 Home page

When the *Information Center* is opened, the *Home* page is displayed. It contains links to start a new project, import projects, read documentation, and access STMicroelectronics support and community.

Figure 11. Information Center – Home page



When using an old workspace, the *Information Center* may not display valid information, showing “*This page can’t be displayed*” or opening old manuals when accessing documents. In such case, reload the page by clicking on the **[Home]** button  at the top-right corner of the *Information Center* window.

1.3.3 Videos

The *Information Center* also contains a video browser page (shown in Figure 13), which is opened from the *Home* page when clicking on the *Access to videos* link. A shortcut in the *Help* menu also provides quick access to the videos, as shown in Figure 12.

Figure 12. Help – Tutorial video





Figure 13. Information Center – Video browser page



Scroll through the *Videos* page and click on a video thumbnail in the list to open it in a web browser. The videos are listed in groups:

- *STM32CubeIDE Tutorials*
- *STM32CubeMX*
- *Discover your STM32 with STM32CubeIDE*

To navigate back to the *Home* page, press *STM32CubeIDE Home* at the top left of the *Information Center*.

The new videos are marked with the keyword “New”. The videos are available from two servers: the YouTube™ server and a dedicated server for China.

1.4 Perspectives, editors, and views


STM32CubeIDE is a powerful product with many views, loaded with various features. Displaying all views simultaneously would overload the user with information that may not be relevant to the task at hand.

To overcome such a situation, views can be organized in perspectives, where a perspective contains a number of predefined views and an editor area visible by default. A perspective typically handles one development task, such as *C/C++ Code Editing* or *Debugging*.

1.4.1 Perspectives


The perspectives can be customized according to the user's need; Views can be moved, resized and new views can be opened. It is possible to reset the perspective at any time if, for instance, too many views are opened or if the views are reordered. The perspective is reset by right-clicking the perspective icon in the toolbar and selecting **[Reset]** from the list. This resets the views; Added views in the perspective are closed and the default views are moved to their original location.

Figure 14. Reset perspective



As seen in Figure 14, it is also possible to customize a perspective and save the perspective with a new name. Switching from one perspective to another is a quick way to hide some views and display others. To switch perspective, select the **[Open Perspective]** toolbar buttons at the right of the toolbar.


Figure 15. Toolbar buttons for switching perspective



Another way to switch perspective is to use the menu command **[Window]>[Perspective]>[Open Perspective]>[Other...]** and select the perspective to use.

1.4.1.1 C/C++ perspective

The C/C++ perspective is intended for creating new projects, editing files, and building the project. The left part of the perspective contains the *Project Explorer* view. The editor is located in the middle. The right part contains some views for the project (*Outline* and *Build Targets* views). At the bottom in the example illustrated in Figure 16, there are the *Problems*, *Tasks*, *Console* and *Properties* views. At the lowest right, the *Build analyzer* and *Static stack analyzer* views are displayed.


Figure 16. C/C++ perspective


DT64663V3

1.4.1.2

Debug perspective


The *Debug* perspective is intended for debugging the code. The *Debug* perspective is normally opened automatically when a new debug session is started. Later, when the debug session is closed, the perspective is switched back to the *C/C++* perspective.

Figure 17. Debug perspective


1.4.1.3 Device Configuration Tool perspective

The *Device Configuration Tool* perspective contains the **STM32CubeMX** device configuration tool integrated in **STM32CubeIDE**. This perspective is used for device configuration. When an *.ioc file is opened in an editor and the *Device Configuration Tool* perspective is used, the device can be configured in this perspective. How the device configuration is made is described in [ST-17].


Figure 18. Device Configuration Tool perspective



1.4.1.4 Remote System Explorer perspective


The *Remote System Explorer* perspective is basically used when developing STM32 Arm® Cortex® MPU-based systems. The *Remote Systems* view is used to view files and the *Remote Shell* view is used to run commands.

Figure 19. Remote System Explorer perspective



The *Remote Systems* view contains buttons to open a new connection via FTP, Linux®, Local, SSH, Telnet and others.

Figure 20. New connection



1.4.2 Editors

The editor area in a perspective is used by editors. Any number of editors can be opened simultaneously but only one can be active at a time. Different editors can be associated with different file extensions. Example of editors are; c-editor, linker script editor, ioc-file editor for STM32CubeMX device configuration.


To open a file in the editor, double-click on the file in the *Project Explorer* view or open the file via the **[File]** menu. When a file is modified in the editor, it is displayed with an asterisk (*) indicating that the file has unsaved changes.

1.4.3 Views

Only the most common views associated with the perspective are displayed by default. There are many more views in the product supporting different features. Some of these views only provide valid data when a debug session is ongoing, while others always display data.


Views can be opened from the **[Window]>[Show View]** menu by selecting one of the views in the list.

Figure 21. [Show View] menu



The above list of views in [Figure 21](#) is still not complete. It contains only the most common views for the work task related to the perspective currently selected. To access even more views, select **[Other...]** from the list. This opens the *Show View* dialog box. Double-click on any view to open it and access its additional features.

Figure 22. Show View dialog



The views can be resized and their positions can be changed: Simply drag the view to a new place in STM32CubeIDE. The view can also be dragged outside the STM32CubeIDE window on the screen. Such detached views are shown in separate windows. Detached views works like the other views but are always shown in front of the workbench. Detached views can be attached again by dragging the tab in the detached view into the STM32CubeIDE window.

To restore the perspective to original state, right-click the perspective icon in the toolbar and select **[Reset]** from the list. Another way to reset the perspective is to use the menu **[Window]>[Perspective]>[Reset Perspective]**.


1.4.4 Quick Access edit field

The magnifying glass in the toolbar opens the *Quick Access* text box, where any search phrase or keyword can be entered. GUI objects like menu commands, toolbar buttons, preference settings or views can be found using the text box. As any search string is typed, the *Quick Access* shows all the GUI objects that match the criteria, in real time. Type a couple of characters or more and see how the list of results is refined correspondingly on-the-fly.

The *Quick Access* is a time saver when looking for a specific GUI object that cannot be found quickly otherwise, such as a preference setting deeply buried in the configuration dialogs. It is also convenient to retrieve a menu command or toolbar button hidden in the currently active perspective.

For example, in Figure 23, the search string “SWV” entered in the *Quick Access* provides immediately the list of matching views, GUI commands and preference settings. To open the view or preference setting, click on the GUI object in the search result list.

Figure 23. Quick access




1.5 Configuration - Preferences

STM32CubeIDE can be customized in many ways. The menu **[Window]>[Preferences]** is used to open the *Preferences* dialog. In this dialog, the left pane is used to navigate to certain preference pages. There is also a filter field, which can be used to narrow down the content displayed. The arrow controls on the upper-right side of the dialog can be used to navigate back and forth across pages. The right pane contains the setting of the displayed preferences. Make any preferred change and press **[Apply]** to update the setting.

[Restore Defaults] resets all changes. The preference settings are stored in a metadata folder in the workspace of the application. [Section 1.7: Managing existing workspaces](#) in this user manual provides information on how to backup preferences and copy preferences across workspaces.

Figure 24. Preferences




It is advised to walk through the preferences pages and get an understanding of the possible configuration options. The following sections present some of them.

1.5.1 Preferences - Editors

The editor can be configured in many ways. For instance, the menu selection **[General]>[Editors]>[Text Editors]** provides a *Preferences* pane containing general editor settings such as:

- Displayed tab width
- Insert spaces for tabs
- Highlight current tab
- Show line numbers
- Others

Figure 25. Preferences - Text Editors




1.5.2 Preferences - Code style formatter

It is possible to configure the editor to use special formatting.


The menu selection [C/C++]>[Code Style]>[Formatter] provides a *Preferences* pane containing settings to set an active profile.

Figure 26. Preferences - Formatter



At this point, if **[Edit...]** is pressed, a new dialog is opened, where the selected profile can be updated according to specific coding rules. This is displayed in [Figure 27](#).


Figure 27. Preferences - Code style edit



1.5.3 Preferences - Network proxy settings

STM32CubeIDE uses the Internet for instance to get access to STM32 devices information. If a proxy server is used for Internet access, some configuration settings are required in STM32CubeIDE. The proxy settings are set in the *Preferences* pane obtained through **[General]>[Network Connections]**. To change the settings, set **[Active provider]** to *Manual* and update the *Proxy entries* for HTTP and HTTPS with specific *Host*, *Port*, *User* and *Password* using the **[Edit...]** button.

Figure 28. Preferences - Network Connections



Note: If there is a problem to save the proxy settings, the reason can be a corrupt *secure_storage* file. Proceed as follows to solve the problem:

1. Close all running STM32CubeIDE applications
2. Rename the file
`C:\Users\user_name\.eclipse\org.eclipse.equinox.security\secure_storage`
 to a new name
3. Restart STM32CubeIDE
4. Update the proxy network settings, with user and password information, and save them to create a new *secure_storage* file

1.5.4 Preferences - Build variables

The STM32CubeIDE preferences feature build variables that are only visible in the IDE.

The menu selection **[C/C++]>[Build]>[Build Variables]** provides a *Preferences* pane with *Build Variables*, which can be used as `${VAR}` in STM32CubeIDE. Enable **[Show system variables]** to display all available variables.

Figure 29. Preferences – Build variables





Table 1. Examples of toolchain build variables

Variable	Description
<code>gnu_tools_for_stm32_compiler_path</code>	Path to GNU Tools for STM32 toolchain.
<code>gnu_arm_embedded_compiler_path</code>	Path to GNU ARM Embedded toolchain.
<code>stm32cubeide_make_path</code>	Path to make and BusyBox.

A pre-build step example using build variables to display toolchain version is given in Figure 30.

Figure 30. Pre-build step using build variables



1.6 Workspaces and projects

The basic concepts of workspaces and projects compares as follows:

- A workspace contains projects. Technically, a workspace is a directory containing project directories or references to them.
- A project contains files. Technically, a project is a directory containing files that may be organized in sub-directories.
- A single computer may hold several workspaces at various locations in the file system. Each workspace may contain several projects.
- The user may switch between workspaces, but only one workspace can be active at one time.
- The user may access any project within the active workspace. Projects located in another workspace cannot be accessed, unless the user switches to that workspace.
- The files included in a project do not need to be physically located in a folder in the project but can be located somewhere else and linked into the project.
- Switching workspaces is a quick way of shifting from one set of projects to another. It triggers a quick restart of the product.


In practice, the project and workspace model facilitates a well-structured hierarchy of workspaces, containing projects, containing files.

1.7 Managing existing workspaces

The workspace can be selected when starting STM32CubeIDE. It is also possible to switch to another workspace during the use of STM32CubeIDE. In this case STM32CubeIDE restarts after the new workspace is selected. To restart STM32CubeIDE with a new workspace, select menu **[File]>[Switch Workspace]**.

The workspaces known to STM32CubeIDE can be managed by selecting **[Window]>[Preferences]** then, in the *Preferences* dialog, selecting **[General]>[Startup and Shutdown]>[Workspaces]**. In the right pane, it is possible to enable **[Prompt for workspace on startup]** and set **[Number of recent workspaces to remember]** to the desired value.

Figure 31. Preferences - Workspaces



It is also possible to select and remove recent workspaces from the list of recent workspaces. However, removing a workspace from that list does not remove the files. Neither does it remove the files from the file system.

1.7.1 Backup of preferences for a workspace

It is generally a good practice to take a copy of the existing preferences for a workspace. It can be especially useful to recreate the workspace after a crash without the time-consuming process to redo the settings manually. In the menu, select **[File]>[Export]**. Then, in the panel, select **[General]>[Preferences]**. Press the **[Next]** button and, in the next page, enable **[Export All]** along with a correct filename.

1.7.2 Copy preferences between workspaces

To copy workspace preferences from one workspace to another, an existing export of preferences must first be created as explained in [Backup of preferences for a workspace](#).


Then select **[File]>[Switch Workspace]** and the new workspace. STM32CubeIDE restarts and opens with the new workspace.

In the menu, select **[File]>[Import]** and in the panel select **[General]>[Preferences]**. Press the **[Next]** button and, on the next page, enable **[Import All]** and enter the file name. The preferences are now the same in both workspaces.

1.7.3 Keeping track of Java heap space

To keep track on how much Java heap space is used, select the **[Window]>[Preferences]** menu. In the *Preferences* page, select the **[General]** node and then enable **[Show heap status]**. The currently used and available Java heap space is then displayed in the STM32CubeIDE status bar. The garbage collector can also be triggered manually from the status bar.


Figure 32. Display of Java heap space status



1.7.4 Unavailable workspace

Only one instance of STM32CubeIDE can access one workspace at a time. This is to prevent conflicting changes in the workspace. If STM32CubeIDE is started with a workspace that is already used by another instance of the program, the following error message is displayed.

Figure 33. Workspace unavailable



If this message is displayed, choose a different workspace, or return to the already running STM32CubeIDE.

1.8 STM32CubeIDE and Eclipse® basics

STM32CubeIDE contains so many features that it is easy to miss some really useful capabilities. Noteworthy features are spell checking of C/C++ comments, word- and code completion, content assist, parameter hints and code templates. The editor also includes an include-file dependency browser, code navigation using hypertext-links, bookmark and to-do lists, and powerful search mechanisms. The next sections remind some of the useful tools that can be easily missed.

1.8.1 Keyboard shortcuts

It is convenient to use keyboard shortcuts instead of the mouse. One important shortcut to know is the shortcut **Ctrl+Shift+L**. This shortcut opens a cheat sheet with all available shortcuts.


Figure 34. Shortcut keys

Activate Editor	F12
Backward History	Alt+Left
Build All	Ctrl+B
Build Target Build	Shift+F9
Close	Ctrl+F4
Close All	Ctrl+Shift+F4
Collapse All	Ctrl+Shift+Numpad_Divide
Content Assist	Ctrl+Space
Context Information	Ctrl+Shift+Space
Copy	Ctrl+Insert
Cut	Shift+Delete
Debug	F11
Delete	Delete
Expand All	Ctrl+Shift+Numpad_Multiply
Find Text in Workspace	Ctrl+Alt+G
Find and Replace	Ctrl+F
Forward History	Alt+Right
Last Edit Location	Ctrl+Q
Maximize Active View or Editor	Ctrl+M

Press 'Ctrl+Shift+L' to open the preference page

Pressing **Ctrl+Shift+L** in this sheet opens the *Keys* pane in the *Preferences* dialog.

Figure 35. Shortcut preferences



The *Keys* pane offers the possibility to examine the shortcuts in detail and change the scheme (default, GNU Emacs, or Microsoft® Visual Studio®), reconfigure shortcut keys, and others.

Table 2 presents the default bindings of some of the keys to mention.

Table 2. Key shortcut examples

Binding	Command	Detail
Keyboard shortcut overview		
Ctrl+Shift+L	List keyboard shortcuts	Lists all the defined keyboard shortcuts.
Navigation in files and C symbols		
Ctrl+Shift+R	Open resource	Finds files from any perspective.
Ctrl+H	Search for keyword	Searches for a keyword in a defined scope with the possibility to use <code>reg.exp</code> .
Alt+Enter	View properties	Views the properties for the selected resource.
Ctrl+Page up or Ctrl+Page down Alt+→ or Alt+←	Switch editor	Switches to an open editor to the left or to the right.
Ctrl+E	Select editor	Moves to an open editor by filtering text or selecting in the menu.
Ctrl+Shift+T	Search for elements	Searches for elements (such as functions, symbols, or others) in workspace resources.

Binding	Command	Detail
Ctrl+Q	Go to the last edit	Goes to the editor, and to the position in this editor, where the last edit was done.
Navigation through file information		
Ctrl+O	Quick outline	Navigates through large files from perspectives lacking an outline view.
Ctrl+L	Go to line	Goes to a line in the editor.
Ctrl+F	Search inside context	Searches within the file currently active in the editor.
Ctrl+Alt+I	Open include browser	Opens the include browser for the current resource.
Ctrl+Alt+H	Open call hierarchy	Shows how the function calls are made to and from a selected function.
Ctrl+Space	Code completion	Code completion using the parameter hints from the context <i>Parameter hints</i> .
Code formatting and refactoring		
Shift+Alt+A	Toggle block select	Edits one column across multiple rows.
Ctrl+I	Indent line	Indents a source code line according to defined format rules.
Ctrl+Shift+F	Format the selected code	Formats the source code according to defined format rules.
Shift+Alt+R	Quick renaming	Renames any C symbol across all the files in all open projects.
Version control		
Ctrl+Alt+C	Commit resources	Commits the modified files within the active context.
Debug		
F11	Debug project	Starts a debug session of the project currently active.
F8	Resume	Continues the debugging process until the next breakpoint.
F5	Step into	Steps into the next method call at the currently executing line of code.
F6	Step over	Steps over the next method call at the currently executing line of code.
F7	Step return	Returns from a method that has been stepped into.
Shift+F5	Reverse step into	Steps into the last method call at the currently executing line of code.
Shift+F6	Reverse step over	Steps over the last method call at the currently executing line of code.
Ctrl+R	Run to a line	Runs to the position of the cursor in the code.
Ctrl+F2	Terminate	Stops the debugging process.
Ctrl+Alt+B	Skip breakpoints	Skips all breakpoints.
Good to know		
[Window]>[Preferences]>[General]>[Keys]		Allows the users to define their own keyboard shortcuts. Also allows the choice of other keyboard shortcut schemes: GNU Emacs, or Microsoft® Visual Studio®, or others.


1.8.2 Editor zoom in and zoom out

It is possible to increase or decrease the default font size for text editors by pressing **Ctrl++** and **Ctrl+-**:

- **Ctrl++** : zoom in text
- **Ctrl+-** : zoom out text

Note: If a keyboard with a numeric keypad is used and the **+** or **-** keys are pressed on the numeric keypad, use the **Shift** key in addition to make the zoom work (**Ctrl+Shift++** or **Ctrl+Shift-**).

Figure 36. Editor with text zoomed in



1.8.3 Quickly find and open a file


Pressing **Ctrl+Shift+R** to find and open a file quickly is one of the featured easily missed. Type a couple of characters part of the name of the file to open. It is possible to add the ***** and **?** search wildcards as appropriate. The editor then lists the matching filenames. Select the desired file in the search result list, and open the file using any of these three ways:

- **[Show In]:** sends the file to one of the views chosen in the drop-down list (such as the #include file dependency browser view)
- **[Open With]:** opens the file in the editor selected in the drop-down list
- **[Open]:** probably the most commonly used option, simply opens the file in the standard C/C++ editor

1.8.4 Branch folding

A block of code enclosed within `#if` and `#endif` can be folded. To activate the functionality, go to **[Window]>[Preferences]**, then **[C/C++]>[Editor]>[Folding]** and check the **[Enable folding of preprocessor branches (#if/#endif)]** checkbox. Once the checkbox is checked, the editor must be restarted. Close the file, open it again, and the small icon in the left margin of the editor showing that the functionality is activated.

Figure 37. Editor folding




1.8.5 Block selection mode


Alt+Shift+A toggles the selection mode between normal and block. When the block mode is enabled, use either the mouse or the **Shift+Arrow** keys of the keyboard to select a block of text.

Use of the block selection mode

To start using the block selection mode, press **Alt+Shift+A**. Click somewhere in the text and drag down. A column is then marked as shown in Figure 38.

Figure 38. Editor block selection



Add some text and see that this text is entered in all marked rows. As an example, the text “My_” is added and displayed in Figure 39.

Figure 39. Editor text block addition


Selection and edition of areas


Select a block. In Figure 40, the block starting with “mem3” to “mem7” is selected.

Figure 40. Editor column block selection



Copy the selected block by using **Ctrl+C**. This copied text can then be inserted elsewhere. To do so, type **Alt+Shift+A** to toggle the selection mode back to the normal mode, move the cursor to another line, and type **Ctrl+V** to paste the copied columns to the new lines.

Figure 41. Editor column block paste




1.8.6 Compare files

To compare two files easily in **STM32CubeIDE**:

1. Select the two files in the *Project Explorer* view
2. Click on one file
3. Press **Ctrl**
4. Click on the other file
Both files are now marked in the *Project Explorer* view
5. Right-click and select **[Compare With]>[Each Other]**


Note: *It is possible to configure how the comparison of files is managed. For instance, ignoring white space can be enabled from the preferences. Open the Preferences page using **[Window]>[Preferences]**, select **[General]>[Compare/Patch]**, and enable **[Ignore white space]**.*

Figure 42. Editor - Compare files



The *File Differences* editor opens and compares both files.

Figure 43. Editor - File differences




Use the navigation buttons to navigate between differences, or simply navigate in the view using the scroll bar to see the file differences.

1.8.7 Local file history

It is recommended to maintain projects with a version control system such as Apache® Subversion® (SVN) or Git™. Still, **STM32CubeIDE** contains a local file with the history of edited files, which can be useful if some investigation is needed after a file has become not functional. The workspace preferences contain a *Local History* page.


Figure 44. Local history



To show the local history of a file:


1. Select the file in the *Project Explorer* view
2. Right-click
3. Select **[Team]>[Show local History]**

Figure 45. Show local history



The *History* view opens and displays the file history.


Figure 46. File history



In the case presented in [Figure 46](#), there are three revisions of `main.c`. Double-click on a file in the *History* view to open it in the editor.


Right-click on a file in the history and select **[Compare Current with Local]** to compare it with the current version of the file.

Figure 47. Compare current history with local history



This opens the *File Differences* editor and displays the file changes.

Figure 48. Compare local file differences



2 Project set up and build

2.1 Create and import C/C++ projects

As mentioned in [Section 1.6: Workspaces and projects](#), a workspace is a directory containing projects. The first time a workspace is created, it is empty without any projects. The projects must be created or imported in the workspace. This section contains information on how to create projects in the workspace and build projects. It also covers how to import and export projects.

2.1.1 Introduction to projects

A project is a directory in the workspace containing files that may be organized in sub-directories. It is possible to access any project within the active workspace. The files included in a project do not need to be physically located in a folder in the project but can be located somewhere else and linked into the project. Projects located in another workspace cannot be accessed, unless the user switches to that workspace or import some of these projects into the workspace in use.

It is possible to rename and delete a project. If a workspace contains many projects, it is also possible to close some of them to make the work easier. Closed projects can be reopened again at any time.

This section focuses on the two types of STM32 projects supported by STM32CubeIDE:

- Executable programs
- Static library projects

However, the Eclipse® C/C++ Development Toolkit (CDT™), which STM32CubeIDE is based on, contains also basic project wizards, which can be used to create C managed build, C++ managed build, and makefile projects.

The STM32 projects can be:

- C or C++
- Generated executable or library file
- Based on [STM32Cube](#) (using STM32 firmware library package) or empty projects

STM32 projects also support an advanced umbrella project structure, where one project contains many projects, for instance one project per core for multi-core devices.

2.1.2 Creating a new STM32 project

2.1.2.1 Creating a new STM32 executable project


The easiest way to create a new STM32 C/C++ project is to use the STM32 project wizard. It is selected through the menu **[File]>[New STM32 Project]**.

Another way to create a new C/C++ project is to open the *Information Center* and press **[Start new STM32**

project]. As mentioned in [Section 1.3: Information Center](#), the *Information Center* can be opened using the  button on the toolbar or via the menu **[Help]>[Information Center]**.

Both ways initialize and launch the *STM32 Project Target Selection* tool.

Figure 49. STM32 target selection




The *MCU/MPU selector* and *Board Selector* tabs can be selected at the top of the window. Use the first tab to create a project for a specific device and the second if a project for a specific board is needed.

This section presents the creation of a project for the NUCLEO-F401RE board using the *Board Selector*.

Among the different filters available for use on the left of the window, type “401” in the *Part Number Search* field to filter the boards with names containing this string. In [Figure 50](#), two boards are listed, a Nucleo board board and a Discovery board. The NUCLEO-F401RE board is selected.

Figure 50. STM32 board selection



Five tabs, *Features*, *Large Pictures*, *Docs & Resources*, *Datasheet*, and *Buy*, offer the possibility to display detailed information about the selected board or device. For instance, documentation available for the board is displayed and can be opened when *Docs & Resources* is selected. When *Datasheet* is selected, the board datasheet is downloaded from the STMicroelectronics website.

Pressing **[Next]** when the NUCLEO-F401RE board is selected opens the *Project setup* page.

Enter a project name and select the desired setting for the project in the dialog boxes. The project named "NUCLEO-F401RE" is filled in as an example in Figure 51.


Figure 51. Project setup

According to the settings in Figure 51, the project is meant to be stored in the default location with the following options set:

- C project
- Executable binary type
- STM32Cube targeted project type


Press **[Next]** to open the *Firmware Library Package Setup* page.

Figure 52. Firmware library package setup




In this page, it is possible to select the STM32Cube firmware package to use when creating the project. In this case, the default settings are used. Press **[Finish]** to create the project.
As a result, the following dialog is displayed.

Figure 53. Initialization of all peripherals



Press **[Yes]** since it is a good practice to get the software needed to initialize the peripherals.
This opens the new dialog shown in Figure 54.


Figure 54. STM32CubeMX perspective opening



Opening the *STM32CubeMX* perspective is a good decision if there are any needs to configure the device. Enable **[Remember my decision]** if the question must not be asked the next time a new project is created. Press **[Yes]** to continue.


At this point, the project creation starts. The time it takes depends on the number of files that need to be downloaded to create the project.

Figure 55. Project creation started



When the project is created, the *STM32CubeMX* perspective is opened with a window for configuring the peripherals, clock, middleware, and power consumption.

Figure 56. STM32CubeMX



The new project is listed in the *Project Explorer* view with some of the folders and files it contains.

The NUCLEO-F401RE.ioc file contains the configuration settings and is opened in the STM32CubeMX editor. This editor contains tabs for *Pinout & configuration*, *Clock configuration*, *Project manager* and *Tools*. When changes are made in the STM32CubeMX editor, the .ioc file in the tab is marked as changed. If the file is saved, a dialog opens asking “Do you want to generate Code?”, making it easy to generate new code in the project that supports the new device configuration. For more information on how to use the STM32CubeMX editor, refer to [ST-17].

It is possible to create an STM32 project with fewer files and folders by selecting the targeted project type **[Empty]** instead of **[STM32Cube]** (refer to Figure 51. Project setup). When **[Empty]** is selected, the generated project only contains some folders, a device startup file with Reset_Handler code and vector table, the main.c file, and some other c files and linker script files. STM32 header files, system files, and CMSIS files must be added manually. These files can, for instance, be copied from some other STM32Cube targeted project or from an STM32 example project.

Note: For empty projects, make sure to configure the floating-point unit setting to use software FPU or hardware FPU according to application requirements. When using hardware FPU, initialize the FPU. For nonempty projects, the initialization of the FPU is normally done in the SystemInit function in the file system_stm32fxxx.c. To notify that the FPU configuration might be needed, the main.c file created in an empty project contains a compiler warning stating #warning "FPU is not initialized, but the project is compiling for an FPU. Please initialize the FPU before use."

2.1.2.2 Creating a new STM32 static library project

The method described in [Section 2.1.2.1: Creating a new STM32 executable project](#) can be used also to create a static library project, which simplifies the configuration of hardware or software components by the designer.

Figure 57. STM32 static library project

IDE STM32 Project

Setup STM32 project

Project

Project Name: MyLib

☒ Use default location

Location: C:\Users\carthana\STM32CubeIDE\workspace_1.12.0 Browse...

Options

Targeted Language

☒ C ☐ C++

Targeted Binary Type

☐ Executable ☒ Static Library

Targeted Project Type

☒ STM32Cube ☐ Empty

? < Back Next > Finish Cancel

2.1.2.3 Creating a new CDT™ project


Eclipse®/CDT™ projects can be used instead of the normal STM32 project wizard to produce both executable and static library project types. Static libraries are often reused in multiple application projects, possibly targeting different STM32 products per build configuration, with full control over both the source code and the build system. The STM32 project wizard does not support changing the MCU or MPU device.

The recommended way to create static library projects is therefore to rely on Eclipse®/CDT™ projects as described below.

Furthermore, it is possible to take advantage of both ways of project creation as a general recommendation for flexibility. Since, for the CDT™ project, the user must add all the files manually, it is interesting to rely on an STM32Cube project as a basis for prototyping and learning and to use a CDT™ project for production. The most efficient way is to keep both projects side by side in the same workspace to bring efficiently the new configurations and files from the STM32Cube project into the CDT™ project.

To create an Eclipse®/CDT™, go to [File]>[New]>[C/C++ Project]. This opens the window displayed in Figure 58.


Figure 58. New C/C++ project



Select either *C Managed Build* or *C++ Managed Build* depending on what the project requires and click on [Next]. This brings up the project type selector. The *Empty Project* type is the only type supporting the *MCU ARM GCC* toolchain. Make sure to select *Empty Project* under the *Executable* folder and then select the *MCU ARM GCC* toolchain as seen in Figure 59.


Once the project naming and type selection are done, click on **[Next]**.

Figure 59. Project type




This launches a standard Eclipse® project configuration window as shown in [Figure 60](#). Click on **[Next]**.

Figure 60. Project configuration selection




In the target selector screen shown in [Figure 61](#), make sure to select the appropriate target by clicking on the **[Select...]** button and filtering the correct target for the project. The target selector helps to set the `-mcpu=cortex-mX` toolchain flag correctly in the already defined build configurations seen in the previous step (see [Figure 60](#)).

Figure 61. Project default target selector



When clicking on **[Select...]**, the filter dialog shown in [Figure 62](#) shows up, allowing users to filter and select the correct device.

Figure 62. Project MCU/MPU selector



After the target selection (*MCU*), the *CPU* and *Core* fields are automatically populated in the simple single-core case as shown in Figure 63.

Figure 63. Project target selection

Select default target for the project

The selected target can be changed, per build configuration, later

MCU:

CPU:

Core:

For more advanced devices such as multi-core STM32H7 microcontrollers, the user must select the *CPU* and *Core* that the project targets to make sure that the code is built correctly. These settings are also used later to set up the debug configurations properly. Make sure that the settings are as needed for the project and click on [Finish].

Figure 64. Project target selection (advanced)

Select default target for the project

The selected target can be changed, per build configuration, later


MCU:

CPU:

Core:

After the project creation, it is possible to create different build configurations for different targets as described in Section 2.3.2.1.2. After a new build configuration is created, right-click the project in the *Project Explorer*, go to **[Properties]>[C/C++ Build]>[Settings]>[Tool Settings]>[MCU Settings]**, and click on **[Select...]** to select a new target for the specific build configuration.

Figure 65. Project target change



2.1.2.4 Creating a new CMake project

STM32CubeIDE supports CMake, another way to build a user's application. Building a CMake project is done in three steps:

1. The first step is the creation of the project itself. STM32CubeIDE offers several possibilities, such as creating it from scratch or deriving its structures from an existing CMake project.
2. The second step is the project configuration, during which the `CMakeLists.txt` build scripts are executed.
3. Ultimately, once the configuration is complete, STM32CubeIDE can generate build scripts native to the host platform.

For detailed information, refer to [ST-15].

2.1.3 Importing existing projects

This section describes different ways to import existing projects into an STM32CubeIDE workspace. The standard Eclipse® importer is capable of importing Eclipse® projects. This is used to import projects created with STM32CubeIDE. The project importer is also extended to support the import of ac6 System Workbench for STM32 projects and Atollic® projects. Such projects are converted during the import phase to STM32CubeIDE projects.

It is possible to import and debug an existing `elf` file developed by another IDE or toolchain. More information on how this is done is available in [Section 3.1.9](#).

2.1.3.1 Importing an STM32CubeIDE project

A project can be imported in many different ways. This section shows how to import a project that was exported as a compressed zip file.

- One way to open the *Import* dialog is to use the menu **[File]>[Import...]**
- Another way is to select **[Import Projects...]** in the *Project Explorer* view

Figure 66. Import project






Figure 67. Import dialog



The user must choose **[Select root directory]** or **[Select archive file]**. If the chosen option is **[Select root directory]**:

1. Click on the **[Browse...]** button.
2. **Locate Project Files:** Navigate to the folder containing the `.project` and `.cproject` files. Once located, click **[Select Folder]**.
3. Review the detected projects: STM32CubeIDE lists the projects found in the selected directory.
4. Choose and import: Select the project to import from the list and click **[Finish]** to complete the process.

Figure 68. Import projects from the root directory



The image shows the 'Import Projects' dialog box in the Eclipse IDE. The title bar says 'IDE Import'. The main heading is 'Import Projects' with a sub-instruction: 'Select a directory to search for existing Eclipse projects.' There are two radio buttons at the top: 'Select root directory:' (selected) and 'Select archive file:'. The 'Select root directory:' option has a text field containing 'C:\Users\Downloads\Test' and a 'Browse...' button. The 'Select archive file:' option has an empty text field and a 'Browse...' button. Below this is a 'Projects:' section with a list box containing one item: 'Test (C:\Users\Downloads\TestWithMX)' which is checked. To the right of the list box are three buttons: 'Select All', 'Deselect All', and 'Refresh'. Below the 'Projects:' section is an 'Options' section with four checkboxes: 'Search for nested projects' (checked), 'Copy projects into workspace' (unchecked), 'Close newly imported projects upon completion' (unchecked), and 'Hide projects that already exist in the workspace' (unchecked). Below the 'Options' section is a 'Working sets' section with a checkbox 'Add project to working sets' (unchecked) and a 'New...' button. Below that is a 'Working sets:' label followed by a dropdown menu and a 'Select...' button. At the bottom of the dialog are four buttons: a help icon (?), '< Back', 'Next >', 'Finish', and 'Cancel'.

IDE Import

Import Projects

Select a directory to search for existing Eclipse projects.

☒ Select root directory: C:\Users\Downloads\Test Browse...
☐ Select archive file: Browse...

Projects:

- ☒ Test (C:\Users\Downloads\TestWithMX)

Select All
Deselect All
Refresh

Options


- ☒ Search for nested projects
- ☐ Copy projects into workspace
- ☐ Close newly imported projects upon completion
- ☐ Hide projects that already exist in the workspace

Working sets

☐ Add project to working sets New...
 Working sets: Select...

? < Back Next > Finish Cancel

Figure 69. Import projects from an archive file



2.1.3.2 Importing System Workbench and projects


To import an ac6 System Workbench for STM32 project or an Atollic® project into STM32CubeIDE, it is advised to work on a project copy:

1. Create a copy of the project, either as a copy of the project folder or an export of the project in a zip file
2. Use the copied project for the import into STM32CubeIDE

The way to import the copied project is to open the *Import* dialog by means of the menu [File]>[Import...] or by right-clicking the *Project Explorer* view.


Select [Import ac6 System Workbench for STM32 project] or [Import Atollic TrueSTUDIO project] depending on the original tool used to create the project and press [Next >].

Figure 70. Import System Workbench projects (1 of 3)




In this example, the ac6 project is copied into the STM32CubeIDE workspace, hence the **[Directory...]** button is used and project STM32F401_Ac6 is selected. The import wizard detects that this is a System Workbench project.

Figure 71. Import System Workbench projects (2 of 3)



Press **[Finish]** to open the *Project converter* dialog.

Figure 72. Import System Workbench projects (3 of 3)




Press **[OK]** to convert the project to an STM32CubeIDE project.

There are two migration guides explaining how to migrate from ac6 System Workbench for STM32 ([ST-06]) and Atollic® to STM32CubeIDE ([ST-05]). These guides can be opened from the *Technical Documentation* page in the *Information Center*.

2.1.3.3 Importing using project files association

When STM32CubeIDE is started, a pop-up window asks if `.cproject` and `.project` files must be associated to the program.

Figure 73. Import using project files association



If the association is selected, double-clicking on a `.project` file in the personal computer file browser triggers the project import by STM32CubeIDE into the current workspace. The project converter investigates the project, which is imported directly if made for STM32CubeIDE. If the project comes from another tool, the project converter tries to identify if it is a known project format and, in such case, converts the project to an STM32CubeIDE project as described in [Section 2.1.3.2: Importing System Workbench and projects](#).

2.1.3.4 Prevent “GCC not found in path” error

When importing old projects, an error in the *Problems* view can state “Program “gcc” not found in PATH”. The error is caused by the project use of a deprecated discovery method setting. The error can be removed by updating the *Window Preferences* and *Project Properties* settings.


1. Open [Window]>[Preferences]. In the *Preferences* dialog, select [C/C++]>[Property Pages Settings] and enable checkbox [Display “Discovery Options” page].
2. Open [Project Properties]>[C/C++ Build]>[Discovery Options] and disable checkbox [Automate discovery of paths and symbols].

2.2 Edit C/C++ projects

2.2.1 Linking the project

This section contains basic information about the linker and linker script files. Detailed information about the linker can be found in the *GNU Linker* manual ([EXT-05]), which is accessed from the *Information Center*. Click on the [Information Center] toolbar button and open the *Information Center* view. Open the linker documentation using the [C/C++ Linker The GNU Linker PDF] link.

Figure 74. Linker documentation



2.2.1.1


Run time library

The toolchains included in STM32CubeIDE contain two prebuilt run time C libraries based on `newlib`. One is the *standard C* `newlib` library and the other is the *reduced C* `newlib-nano`. Use `newlib-nano` to achieve smaller code size. For information about the differences between `newlib-nano` and the standard `newlib`, refer to the `newlib-nano` readme file ([ST-09]), accessible from the *Information Center*.

To select the desired run time library for use in the project.

1. Right-click on the project in the *Project Explorer* view
2. Select menu [Project]>[Properties]
3. Select [C/C++ Build]>[Settings] in the *Properties* panel
4. Open the *Tool Settings* tab, select [MCU Settings] and configure the [Runtime library] setting

Figure 75. Linker run time library



When `newlib-nano` is used while floating-point numbers must be handled by `scanf/printf`, additional options are required. The reason is that `newlib-nano` and `newlib` handle floating-point numbers differently. In `newlib-nano`, formatted floating-point number inputs and outputs are implemented as weak symbols. Therefore, the symbols must be pulled by specifying explicitly if `%f` is used with `scanf/printf` using the `-u` option:


- `-u _scanf_float`
- `-u _printf_float`

For example, to enable output float with printf, the command line is as follows:

```
$ arm-none-eabi-gcc --specs=nano.specs -u _printf_float $(OTHER_LINK_OPTIONS)
```

The options can be enabled using the **[Use float ...]** checkboxes in **[MCU Settings]** in the *Tool Settings* tab.

Figure 76. Linker newlib-nano library and floating-point numbers



2.2.1.2


Discard unused sections

Linker optimization is the process where the linker removes unused code and data sections, dead code, from the output binary. Run time and middleware libraries typically include many functions that are not used by all applications, thus wasting valuable memory unless removed from the output binary.

When using the project wizard to create new projects, the default configuration is that the linker discards unused sections. To check or change the setting about unused sections, open at any time the build settings for the project:

1. Right-click the project in the *Project Explorer* view and select **[Properties]**
2. In the dialog, select **[C/C++ Build]>[Settings]**
3. Select the *Tool Settings* tab in the panel
4. Select **[MCU GCC Linker]>[General]**
5. Configure **[Discard unused sections (-Wl,--gc-sections)]** according to the project requirements
6. Rebuild the project

Figure 77. Linker discard unused sections



2.2.1.3

Page size allocation for malloc

When the *GNU Tools for STM32* toolchain is used with the standard C `newlib` library, the page size setting for `malloc` can be changed. The `newlib` default page size is 4096 bytes. If a `sysconf()` function is implemented in the user project, this user function is called by `_malloc_r()`.

The following example shows how to implement a `sysconf()` function with a 128-byte page size. Add a similar function if there is a need for the application to use a smaller page size than the default 4096 bytes.

```
/**
*****
** File      : sysconf.c
*****
**/

/* Includes */
#include <errno.h>
#include <unistd.h>

long sysconf(int name)
{
    if (name == _SC_PAGESIZE)
    {
        return 128;
    }
    else
    {
        errno = EINVAL;
        return -1;
    }
}
```

Note:

If the “GNU ARM Embedded” toolchain is used, it does not call any `sysconf()` function implemented in the application but always uses the default `sysconf()` function in `newlib`. Also, no call to `sysconf()` is made if the “GNU Tools for STM32” toolchain is used with the reduced C `newlib-nano` library.


2.2.1.4

Include additional object files

STM32CubeIDE makes it easy to include additional object files that must be linked to a project. They can be files from other projects, precompiled libraries where no source code is available, or object files created with other compilers.

1. Right-click the project in the *Project Explorer* view and select **[Properties]**
2. In the dialog, select **[C/C++ Build]>[Settings]**
3. Select the *Tool Settings* tab in the panel
4. Select **[MCU GCC Linker]>[Miscellaneous]**
5. Use the **[Add...]** icon to add additional object files in several possible ways:
 - Enter the filenames in the *Add file path* dialog
 - Use the **[Workspace...]** or **[File system...]** buttons to locate the files

Figure 78. Linker include additional object files



2.2.1.5

Treat linker warnings and errors

The GNU linker is normally silent for warnings. One example of such silent warning is seen if the startup code containing the normal `Reset_Handler` function is missing in the project. The GNU linker in normal silent mode creates an `elf` file and only report a warning output in the *Console* window about the missing `Reset_Handler`.

Example of warning message:

```
arm-none-eabi-gcc -o "NUCLEO-F401RE.elf" @"objects.list" -mcpu=cortex-m4
-T"C:\Users\username\STM32CubeIDE\workspace_um\NUCLEO-
F401RE\STM32F401RETX_FLASH.ld" --specs=nosys.specs -Wl,-Map="NUCLEO-F401RE.map"
-Wl,--gc-sections -static -mfpv4-sp-d16 -mfloat-abi=hard -mthumb -Wl,--start-
group -lc -lm -Wl,--end-group
c:\st\stm32cubeide_1.1.0.19w37\stm32cubeide\plugins\com.st.stm32cube.ide.mcu.extern
altools.gnu-tools-for-stm32.7-2018-q2-update.win32_1.0.0.201904181610\tools\arm-
none-eabi\bin\ld.exe: warning: cannot find entry symbol Reset_Handler; defaulting
to 0000000008000000
Finished building target: NUCLEO-F401RE.elf
```

In this case, a new `elf` file is created but, if the warning is not detected, it does not work to debug the project because the program does not contain the `Reset_Handler` function. It is possible to configure the linker to treat warnings as errors by adding the `--fatal-warnings` option.


When the `--fatal-warnings` option is used, the linker does not generate the `elf` file but displays an error in the console log:

```
c:\st\stm32cubeide_1.1.0.19w37\stm32cubeide\plugins\com.st.stm32cube.ide.mcu.extern
altools.gnu-tools-for-stm32.7-2018-q2-update.win32_1.0.0.201904181610\tools\arm-
none-eabi\bin\ld.exe: warning: cannot find entry symbol Reset_Handler; defaulting
to 0000000008000000
collect2.exe: error: ld returned 1 exit status
make: *** [makefile:40: NUCLEO-F401RE.elf] Error 1
"make -j4 all" terminated with exit code 2. Build might be incomplete.
11:26:30 Build Failed. 1 errors, 6 warnings. (took 7s.193ms)
```


To use the `-Wl,--fatal-warnings` option:

1. Right-click the project in the *Project Explorer* view and select **[Properties]**
2. In the dialog, select **[C/C++ Build]>[Settings]**
3. Select the *Tool Settings* tab in the panel
4. Select **[MCU GCC Linker]>[Miscellaneous]**
5. Add `-Wl,--fatal-warnings` to the **[Other flags]** field.

Figure 79. Linker fatal warnings



2.2.1.6 Linker script

The linker script file (`.ld`) defines the files to include and where things end up in memory. Some important parts of the linker script file are described in the next sections. For detailed information about the linker, read the C/C++ linker *GNU Linker manual* ([ST-05]). This manual is available in the documentation section of the *Information Center*. Consider sections 3.6 and 3.7 especially.

The linker script specifies the memory regions and the location of the stack, heap, bss, data, rodata, text, and program entry. The size of stack and heap are configurable by editing the `_Min_Stack_Size` and `_Min_Heap_Size` values in the linker script file. However, these values are only used by the linker to validate that stack and heap fit in memory. When running the program, the stack or heap may require more memory, which may lead to unexpected results if data is overwritten.

Table 3 presents as an example the typical program and memory layout of an STM32F4 device with 512-Kbyte flash memory and 96-Kbyte SRAM. The device is based on the Cortex®-M core with 32-bit address space (0x0000 0000 to 0xFFFF FFFF).

Table 3. Memory map layout

Example: STM32F4 96-Kbyte SRAM 512-Kbyte flash memory	Usage	Files Linker script .ld, or .h and .c files	Comment
0xFFFF FFFF 0xE000 0000	Cortex®-M4 internal peripherals.	.h and .c files.	SysTick, NVIC, ITM, debug, and others.
0xDFFF FFFF 0x6000 0000	External memory FMC (Flexible memory controller).	Must be added in linker script, and .h and .c files. ⁽¹⁾	NOR flash memory, NAND flash memory, SPI flash memory, PSRAM, SDRAM, and others.
0x5FFF FFFF 0x4000 0000	STM32 peripherals.	.h and .c files.	GPIO, ADC, timers, USB, USART, and others.
0x2001 8000	96-Kbyte SRAM Stack	Linker script _estack _Min_Stack_Size	The stack contains local data ⁽²⁾
	Heap	_Min_Heap_Size ._user_heap_stack	⁽³⁾ Heap used by malloc ⁽⁴⁾ Data
		.bss	Static global data (.bss and .data) .bss == Uninitialized data Cleared to zero by the startup code.
0x2000 0000	Data	.data	.data == Initialized data Copied from flash memory to SRAM by the startup code.
0x0808 0000	512-Kbyte flash memory Data	Linker script .data	Initialized data to copy to SRAM.
		.rodata	Read-only data placed in flash memory.
	Program	ENTRY Reset_Handler ⁽⁵⁾ .text	.text == Program, such as main() in main.c, SystemInit() in system_stm32f4xx.c, Reset_Handler in startup_stm32*.s, g_pfnVectors in startup_stm32*.s, Vector table in startup_stm32*.s.
0x0800 0000	Interrupt vector table	.isr_vector ⁽⁶⁾	

Color legend

Cortex®-M internal peripherals and STM32 peripherals.

External memory. Normally the linker script, header files, and C files must be updated to use external memories.

Flash memory and SRAM where program, data, heap, and stack are located. Usually, when creating a project with STM32CubeIDE, these flash memory and RAM regions are accessible and usable without any updates of the linker script or other files. The linker script file defines how to place code, data, heap, and stack in memory.

1. If external memory is used, the memory must be added into the linker script file. See in chapter [Section 2.2.1.7.1](#) how to add a new memory region.
2. The stack grows downwards and may go into the heap.
3. When running the program, the stack or heap may require more memory, which might lead to unexpected results if data is overwritten.
4. The heap grows upwards and may go into the stack.
5. The linker script file contains the entry point definition of the program. Normally, `ENTRY(Reset_Handler)`.
6. The interrupt vector table contains the reset value of the stack pointer, the start addresses of the program (`Reset_Handler`), exception handlers, and interrupt handlers. Normally the `Reset_Handler` code and vector table (`g_pfnVectors`) are available in file `<startup_stm32xxx.s>`.

See below the default linker script generated by **STM32CubeIDE** for an STM32F4 device with 512-Kbyte flash memory and 96-Kbyte SRAM.

The beginning of the code excerpt shows the linker script header, entry, stack, heap and memory definitions.

```
/**
*****
* @file      LinkerScript.ld
* @author    Auto-generated by STM32CubeIDE
* Abstract   : Linker script for NUCLEO-F401RE Board embedding STM32F401RETx Device from s
tm32f4 series
*
*              512Kbytes FLASH
*              96Kbytes RAM
*
*      Set heap size, stack size and stack location according
*      to application requirements.
*
*      Set memory bank area and size if external memory is used
*****
* @attention
*
* <h2><center>&copy; Copyright (c) 2020 STMicroelectronics.
* All rights reserved.</center></h2>
*
* This software component is licensed by ST under BSD 3-Clause license,
* the "License"; You may not use this file except in compliance with the
* License. You may obtain a copy of the License at:
*              opensource.org/licenses/BSD-3-Clause
*
*****
*/

/* Entry Point */
ENTRY(Reset_Handler)

/* Highest address of the user mode stack */
_estack = ORIGIN(RAM) + LENGTH(RAM); /* end of "RAM" Ram type memory */

_Min_Heap_Size = 0x200; /* required amount of heap */
_Min_Stack_Size = 0x400; /* required amount of stack */

/* Memories definition */
MEMORY
{
  RAM      (xrw)      : ORIGIN = 0x20000000, LENGTH = 96K
  FLASH    (rx)       : ORIGIN = 0x80000000, LENGTH = 512K
}

/* Sections */
SECTIONS
{
  /* The startup code into "FLASH" Rom type memory */
  .isr_vector :
  {
    . = ALIGN(4);
    KEEP(*(.isr_vector)) /* Startup code */
    . = ALIGN(4);
  } >FLASH

  /* The program code and other data into "FLASH" Rom type memory */
  .text :
  {
    . = ALIGN(4);
    *(.text)           /* .text sections (code) */
    *(.text*)          /* .text* sections (code) */
    *(.glue_7)         /* glue arm to thumb code */
    *(.glue_7t)        /* glue thumb to arm code */
    *(.eh_frame)
  }
```

The continuation of the code excerpt shows the definition of sections.

```
/* Sections */
SECTIONS
{
  /* The startup code into "FLASH" Rom type memory */
  .isr_vector :
  {
    . = ALIGN(4);
    KEEP(*(.isr_vector)) /* Startup code */
    . = ALIGN(4);
  } >FLASH

  /* The program code and other data into "FLASH" Rom type memory */
  .text :
  {
    . = ALIGN(4);
    *(.text)           /* .text sections (code) */
    *(.text*)          /* .text* sections (code) */
    *(.glue_7)         /* glue arm to thumb code */
    *(.glue_7t)        /* glue thumb to arm code */
    *(.eh_frame)
  }
```

```

    KEEP (*.init))
    KEEP (*.fini))

    . = ALIGN(4);
    _etext = .;          /* define a global symbols at end of code */
} >FLASH

/* Constant data into "FLASH" Rom type memory */
.rodata :
{
    . = ALIGN(4);
    *(.rodata)           /* .rodata sections (constants, strings, etc.) */
    *(.rodata*)          /* .rodata* sections (constants, strings, etc.) */
    . = ALIGN(4);
} >FLASH

.ARM.extab : {
    . = ALIGN(4);
    *(.ARM.extab* .gnu.linkonce.armextab.*)
    . = ALIGN(4);
} >FLASH

.ARM : {
    . = ALIGN(4);
    __exidx_start = .;
    *(.ARM.exidx*)
    __exidx_end = .;
    . = ALIGN(4);
} >FLASH

.preinit_array :
{
    . = ALIGN(4);
    PROVIDE_HIDDEN (__preinit_array_start = .);
    KEEP (*.preinit_array*)
    PROVIDE_HIDDEN (__preinit_array_end = .);
    . = ALIGN(4);
} >FLASH

.init_array :
{
    . = ALIGN(4);
    PROVIDE_HIDDEN (__init_array_start = .);
    KEEP (*(SORT(.init_array.*)))
    KEEP (*.init_array*)
    PROVIDE_HIDDEN (__init_array_end = .);
    . = ALIGN(4);
} >FLASH

.fini_array :
{
    . = ALIGN(4);
    PROVIDE_HIDDEN (__fini_array_start = .);
    KEEP (*(SORT(.fini_array.*)))
    KEEP (*.fini_array*)
    PROVIDE_HIDDEN (__fini_array_end = .);
    . = ALIGN(4);
} >FLASH

/* Used by the startup to initialize data */
_sdata = LOADADDR(.data);

/* Initialized data sections into "RAM" Ram type memory */
.data :
{
    . = ALIGN(4);
    _sdata = .;          /* create a global symbol at data start */
    *(.data)             /* .data sections */
    *(.data*)            /* .data* sections */
    *(.RamFunc)          /* .RamFunc sections */

```

```

    *(.RamFunc*)          /* .RamFunc* sections */

    . = ALIGN(4);
    _edata = .;          /* define a global symbol at data end */

} >RAM AT> FLASH

/* Uninitialized data section into "RAM" Ram type memory */
. = ALIGN(4);
.bss :
{
    /* This is used by the startup in order to initialize the .bss section */
    _sbss = .;          /* define a global symbol at bss start */
    __bss_start__ = _sbss;
    *(.bss)
    *(.bss*)
    *(COMMON)

    . = ALIGN(4);
    _ebss = .;          /* define a global symbol at bss end */
    __bss_end__ = _ebss;
} >RAM

/* User_heap_stack section, used to check that there is enough "RAM" Ram type memory left
*/
._user_heap_stack :
{
    . = ALIGN(8);
    PROVIDE ( end = . );
    PROVIDE ( _end = . );
    . = . + _Min_Heap_Size;
    . = . + _Min_Stack_Size;
    . = ALIGN(8);
} >RAM

/* Remove information from the compiler libraries */
/DISCARD/ :
{
    libc.a ( * )
    libm.a ( * )
    libgcc.a ( * )
}

.ARM.attributes 0 : { *(.ARM.attributes) }
}

```

2.2.1.6.1 The **ENTRY** command defines the start of the program

The first instruction to execute in a program is defined with the **ENTRY** command.

Example:

```

/* Entry Point */
ENTRY(Reset_Handler)

```

The **ENTRY** information is used by GDB so that the program counter (PC) is set to the value of the **ENTRY** address when a program is loaded. In the example, the program starts to execute from `Reset_Handler` when a step or continue command is given to GDB after a load.

Note: *The start of the program can be overridden if the GDB script contains a monitor reset command after the load command. Then the code starts to run from reset.*

2.2.1.6.2 Stack location

The stack location is normally used by the startup file using the `_estack` symbol. The startup code normally initializes the stack pointer with the address given in the linker script. For Cortex®-M based devices, the stack address is also set at the first address in the interrupt vector table.

Example:

```
/* Highest address of the user mode stack */
_estack = ORIGIN(RAM) + LENGTH(RAM); /* end of "RAM" Ram type memory */
```

2.2.1.6.3 Define heap and stack minimum sizes

It is common to define in the linker script the heap and stack minimum sizes to be used by the system.

Example:

```
_Min_Heap_Size = 0x200; /* required amount of heap */
_Min_Stack_Size = 0x400; /* required amount of stack */
```

The values defined here are normally used later in the linker script to make it possible for the linker to test if the heap and stack fit in the memory. The linker can then issue an error if there is not enough memory available.

2.2.1.6.4 Specify memory regions

The memory regions are specified with names `ORIGIN` and `LENGTH`. It is common also to have an attribute list specifying the usage of a particular memory region, such as `(rx)` with “r” standing for read-only section and “x” for executable section. It is not required to specify any attribute.

Example:

```
/* Memories definition */
MEMORY
{
  RAM      (xrw)      : ORIGIN = 0x20000000,    LENGTH = 96K
  FLASH    (rx)       : ORIGIN = 0x80000000,    LENGTH = 512K
}
```

2.2.1.6.5 Specify output sections (.text and .rodata)

The output sections define where the sections such as `‘.text’`, `‘.data’` or others are located in the memory. The example below tells the linker to put all sections such as `.text`, `.rodata` and others in the flash memory region. The glue sections mentioned in the example are used by GCC if there are some mixed code in the program. For instance, the glue code is used if some Arm® code makes a call to thumb code or vice versa.

Example:

```
/* Sections */
SECTIONS
{
  /* The startup code into "FLASH" Rom type memory */
  .isr_vector :
  {
    . = ALIGN(4);
    KEEP(*(.isr_vector)) /* Startup code */
    . = ALIGN(4);
  } >FLASH

  /* The program code and other data into "FLASH" Rom type memory */
  .text :
  {
    . = ALIGN(4);
    *(.text)           /* .text sections (code) */
    *(.text*)          /* .text* sections (code) */
    *(.glue_7)         /* glue arm to thumb code */
    *(.glue_7t)        /* glue thumb to arm code */
    *(.eh_frame)

    KEEP (*(.init))
    KEEP (*(.fini))

    . = ALIGN(4);
    _etext = .;        /* define a global symbols at end of code */
  } >FLASH
```

2.2.1.6.6 Specify initialized data (.data)

Initialized data values require extra handling as the initialization values must be placed in the flash memory and the startup code must be able to initialize the RAM variables with correct values. The example below creates symbols `_sdata`, `_sdata` and `_edata`. The startup code can then use these symbols to copy the values from flash memory to RAM during program start.

Example:

```
/* Used by the startup to initialize data */
_sdata = LOADADDR(.data);

/* Initialized data sections into "RAM" Ram type memory */
.data :
{
  . = ALIGN(4);
  _sdata = .;      /* create a global symbol at data start */
  *(.data)         /* .data sections */
  *(.data*)        /* .data* sections */
  *(.RamFunc)      /* .RamFunc sections */
  *(.RamFunc*)     /* .RamFunc* sections */

  . = ALIGN(4);
  _edata = .;      /* define a global symbol at data end */
} >RAM AT> FLASH
```

2.2.1.6.7 Specify uninitialized data (.bss)

Uninitialized data values must be reset to 0 by the startup code: the linker script file must identify the locations of these variables. The example below creates symbols `_sbss` and `_ebss`. The startup code can then use these symbols to set the values of the uninitialized variables to 0.

Example:

```
/* Uninitialized data section into "RAM" Ram type memory */
. = ALIGN(4);
.bss :
{
    /* This is used by the startup in order to initialize the .bss section */
    _sbss = .;          /* define a global symbol at bss start */
    __bss_start__ = _sbss;
    *(.bss)
    *(.bss*)
    *(COMMON)

    . = ALIGN(4);
    _ebss = .;          /* define a global symbol at bss end */
    __bss_end__ = _ebss;
} >RAM
```

2.2.1.6.8 Check if user heap and stack fit in the RAM

One section of the code is normally dedicated to linker checks about the fact that the needed heap and stack fit into the RAM together with all other data.

Example:

```
/* User_heap_stack section, used to check that there is enough "RAM" Ram type memory left */
/
._user_heap_stack :
{
    . = ALIGN(8);
    PROVIDE ( end = . );
    PROVIDE ( _end = . );
    . = . + _Min_Heap_Size;
    . = . + _Min_Stack_Size;
    . = ALIGN(8);
} >RAM
```

Note: *The stack is placed on top of RAM and heap after data with a gap in between. See [Table 3. Memory map layout](#).*

2.2.1.6.9 Linker map and list files

When building a project generated with [STM32CubeIDE](#), a map and a list file are created in the debug or release build output folders. These files contain detailed information on the final locations of code and data in the program.

The Build Analyzer view can be used to analyse the size and location of a program in detail. Read more about this in [Section 2.4: Build Analyzer](#).

2.2.1.7 Modify the linker script

This section presents common use cases requiring to edit the linker script. Editing and managing the script allows for more exact placements of the code and data.

2.2.1.7.1 Place code in a new memory region

Many devices have more than one memory region. It is possible to use the linker script to specifically place code in different areas. The example below shows how to update a linker script to support code to be placed in a new memory region named `IP_CODE`.

Example:

```
Original MEMORY AREA

/* Memories definition */
MEMORY
{
    RAM      (xrw)      : ORIGIN = 0x20000000,    LENGTH = 96K
    FLASH    (rx)       : ORIGIN = 0x80000000,    LENGTH = 512K
}

Add IP_CODE into MEMORY AREA

/* Memories definition */
MEMORY
{
    RAM      (xrw)      : ORIGIN = 0x20000000,    LENGTH = 96K
    FLASH    (rx)       : ORIGIN = 0x80000000,    LENGTH = 256K
    IP_CODE  (rx)       : ORIGIN = 0x80400000,    LENGTH = 256K
}
```

Place the following code a bit further down in the script, between the `.data { ... }` and the `.bss { ... }` section in the linker script file:

Example:

```
.ip_code :
{
    *(.IP_Code*);
} > IP_CODE
```

This tells the linker to place all sections named `.IP_Code*` into the `IP_CODE` memory region, which is specified to start at target memory address `0x804 0000`.

In the C code, tell the compiler which functions must go to this section by adding `__attribute__((section(".IP_Code")))` before the function declaration.

Example:

```
__attribute__((section(".IP_Code"))) int myIP_read()
{
    // Add code here...
    return 1;
}
```

The `myIP_read()` function is now placed in the `IP_CODE` memory region by the linker.

2.2.1.7.2 Place code in RAM

To place code in the RAM, some modifications of the linker script and startup code are needed. The example below describes the changes to be applied when the internal RAM is split into a few sections and the code is placed and executed in one of the internal RAM sections.

Define a new memory region in the `MEMORY {}` region in the linker script:

```
Original MEMORY AREA

/* Memories definition */
MEMORY
{
    RAM      (xrw)      : ORIGIN = 0x20000000,    LENGTH = 96K
    FLASH    (rx)       : ORIGIN = 0x80000000,    LENGTH = 512K
}

Split RAM into memory areas RAM1, RAM_CODE, RAM

/* Memories definition */
MEMORY
{
    RAM1      (xrw)      : ORIGIN = 0x20000000,    LENGTH = 16K
    RAM_CODE  (xrw)      : ORIGIN = 0x20004000,    LENGTH = 16K
    RAM       (xrw)      : ORIGIN = 0x20008000,    LENGTH = 64K
    FLASH     (rx)       : ORIGIN = 0x80000000,    LENGTH = 512K
}
```

Define an output section for the code in the linker script. This must be placed with a Load Memory Address (LMA) belonging to the flash memory, and a Virtual Memory Address (VMA) in RAM:

```
/* load code used by the startup code to initialize the ram code */
_siram_code = LOADADDR(.RAM_CODE);
.RAM_CODE :
{
    . = ALIGN(4);
    _siram_code = .; /* create a global symbol at ram_code start */
    *(.RAM_Code)      /* .RAM_Code sections */
    *(.RAM_Code*)     /* .RAM_Code* sections */
    . = ALIGN(4);
    _eram_code = .; /* define a global symbol at ram_code end */
} >RAM_CODE AT> FLASH
```

The RAM code area must be initialized and code copied from the flash memory to the RAM code area. The startup code can access the location information symbols `_siram_code`, `_sram_code` and `_eram_code`. Add load address symbols for `RAM_CODE` into the startup file:

```
/* Load address for RAM_CODE */
.word _siram_code;
.word _sram_code;
.word _eram_code;
```

Add a piece of code into the startup code to copy the RAM code from the flash memory (LMA) to the RAM (VMA):

```
Reset_Handler:
    ldr    sp, _estack          /* set stack pointer */

/* Copy the ram code from flash to RAM */
    movs  r1, #0
    b     LoopRamCodeInit

RamCodeInit:
    ldr   r3, _siram_code
    ldr   r3, [r3, r1]
    str   r3, [r0, r1]
    adds  r1, r1, #4

LoopRamCodeInit:
    ldr   r0, _sram_code
    ldr   r3, _eram_code
    adds  r2, r0, r1
    cmp   r2, r3
    bcc   RamCodeInit

/* Copy the data segment initializers from flash to SRAM */
    movs  r1, #0
    b     LoopCopyDataInit

CopyDataInit:
```

In the C code, instruct the compiler about which functions must go to this section by adding `__attribute__((section(".RAM_Code")))` before the functions declarations:

```
__attribute__((section(".RAM_Code"))) int myRAM_read()
{
    // Add code here...
    return 2;
}
```

Refer to [\[ST-14\]](#) for information on how to execute application code from CCM RAM using STM32CubeIDE. It contains examples on how to setup the linker script and startup code to execute a function or an interrupt handler from RAM. The example in the chapter 4 of [\[ST-14\]](#) can be used as an inspiration on how to add other RAM regions and setup code sections to be located in RAM.

2.2.1.7.3 Place variables at specific addresses

It is possible to place variables at specific addresses in the memory. To achieve this, the linker script must be modified. The example presented in this section places constant variables handling a product `VERSION_NUMBER`, `CRC_NUMBER`, and `BUILD_ID` in memory.

The first step is to create a new memory region in the linker script:

```
Original MEMORY AREA

/* Memories definition */
MEMORY
{
    RAM      (xrw)      : ORIGIN = 0x20000000,    LENGTH = 96K
    FLASH    (rx)       : ORIGIN = 0x80000000,    LENGTH = 512K
}

Add a new 2K FLASH_V memory region at end of flash
/* Memories definition */
MEMORY
{
    RAM      (xrw)      : ORIGIN = 0x20000000,    LENGTH = 96K
    FLASH    (rx)       : ORIGIN = 0x80000000,    LENGTH = 512K-2K
    FLASH_V  (rx)       : ORIGIN = 0x807F800,     LENGTH = 2K
}
```

At this point, the memory section must be added:

Place the following a bit further down in the script, between the .data { ... } and the .bss { ... } section

```
.flash_v :
{
*(.flash_v*);
} > FLASH_V
```

This instructs the linker to place all sections named `flash_v*` into the `flash_v` output section in the `FLASH_V` memory region, which is specified to start at target memory address `0x807 F800`.

A section can be called almost anything except some predefined names such as `"data"`.

Now, the variables that must be located into the `FLASH_V` memory must be defined with attributes in the C files:


```
__attribute__((section(".flash_v.VERSION"))) const uint32_t VERSION_NUMBER=0x00010003;
__attribute__((section(".flash_v.CRC"))) const uint32_t CRC_NUMBER=0x55667788;
__attribute__((section(".flash_v.BUILD_ID"))) const uint16_t BUILD_ID=0x1234;
```

Important: Unless the variable is referenced in the code, the linker is allowed to garbage collect it.

When debugging this example and examining the memory, it can be observed that:

- Address `0x807 f800` contains `VERSION_NUMBER`
- Address `0x807 f804` contains `CRC_NUMBER`
- Address `0x807 f808` contains `BUILD_ID`

Figure 80. Linker memory output



If the inserted data order in the flash memory is important, map the order of the variables in the linker script. This makes it possible to define the variables in any file. The linker outputs the variables in the defined order independently on how the files are linked. As a result, if the `CRC_NUMBER` is calculated in some way after the linker has built the file, the `CRC_NUMBER` can be inserted into the flash memory file by another tool:


Decide the order in the linker script by adding the specially named sections in order `BUILD_ID`, `VERSION_NUMBER`, `CRC_NUMBER`, and others(*).

```
.flash_v :
{
*(.flash_v.BUILD_ID*);
*(.flash_v.VERSION*);
*(.flash_v.CRC*);
*(.flash_v*);
} > FLASH_V
```

When debugging this example and examining the memory, it can be observed that:

- Address 0x807 f800 contains BUILD_ID
- Address 0x807 f804 contains VERSION_NUMBER
- Address 0x807 f808 contains CRC_NUMBER

Figure 81. Linker memory output specified order



2.2.1.7.4 Linking in a block of binary data

It is possible to link in a block of binary data into the linked file. The example below describes how to include a `./readme.txt` file.

Example:

```
File: readme.txt
Revision: Version 2
Product news: This release ...
```

One way to include this in the project is to make a reference in a C file to include it using the `incbin` directive and the allocatable ("`a`") option on the section:

```
asm(".section .binary_data,\"a\";\"
\".incbin \"../readme.txt\";\"
);
```

The new section `binary_data` is then added into the linker script with instructions that the section must be put in the flash memory. The `KEEP()` keyword can be used to surround an input section so that the linker garbage collector does not eliminate the section even if not called:


```
.binary_data :
{
  _binary_data_start = .;
  KEEP(*(.binary_data));
  _binary_data_end = .;
} > FLASH
```

This block can then be accessed from the C code:

```
extern int _binary_data_start;
int main(void)
{
  /* USER CODE BEGIN 1 */
  int *bin_area = &_binary_data_start;
```

The binary data, in this case the `readme` file, can be observed in the *Memory* view when the project is debugged.

Figure 82. Linker memory displaying file `readme`



2.2.1.7.5 Locate uninitialized data in memory (NOLOAD)

There is sometimes a need to have variables located into the flash memory, or some other non-volatile memory, which must not be initialized at startup. In such cases, it is possible to create a specific `MEMORY AREA` in the linker script (`FLASH_D`) and use the `NOLOAD` directive in the section using the area.

Example:

```
The MEMORY AREA can be defined like this

/* Memories definition */
MEMORY
{
    RAM      (xrw)      : ORIGIN = 0x20000000,    LENGTH = 96K
    FLASH    (rx)       : ORIGIN = 0x80000000,    LENGTH = 512K-4K
    FLASH_D  (rx)       : ORIGIN = 0x807F000,     LENGTH = 2K
    FLASH_V  (rx)       : ORIGIN = 0x807F800,     LENGTH = 2K
}
```

Add a section for `FLASH_D` using the `NOLOAD` directive. This can be done using the following code a bit further down in the linker script:

```
Place the following a bit further down in the script

.flash_d (NOLOAD) :
{
    *(.flash_d*);
} > FLASH_D
```

Finally, data can be used somewhere in the program by adding a section attribute when declaring the variables that must be located in the `FLASH_D` memory.

```
__attribute__((section(".flash_d"))) uint32_t Distance;
__attribute__((section(".flash_d"))) uint32_t Seconds;
```


2.2.1.8 Include libraries

To include a library into a project:

1. Right-click the project where the library must be included in the *Project Explorer* view and select **[Properties]**
2. In the dialog, select **[C/C++ Build]>[Settings]**
3. Select the *Tool Settings* tab in the panel
4. Select **[C Linker]>[Libraries]**

5. Add the library name to the **[Libraries]** field.
Make sure the library name is added and not the path. According to the GCC convention, the library name is its filename without the `“lib”` prefix and `“.a”` extension.
Example: for a library file named `libmyLib.a`, add the library name `myLib`.
If by any chance the library name do not comply with the GCC convention, the full library name can be entered, preceded by a colon `“:”`.
Example: for a library file named `STemWin524b_CM4_GCC.a`, add the library name `:STemWin524b_CM4_GCC.a`.
6. In the **[Library Paths]** list, set the library location path. Do not include the name of the library in the path.
Example: `${workspace_loc:/myLib/Debug}` is the path to the archive file of the library project `myLib` residing in the same workspace as the application project.
7. Enable **[Place libraries in a linker group (-Wl,--start-group \$(LIBS) -Wl,--end-group)]** if libraries need to be linked several times to resolve circular dependencies.


Figure 83. Include a library



The source folders for the header files must also be added to the [Include paths] field:

1. Select [MCU GCC Compiler]>[Include paths]
2. press the [Add...] button and add the paths to the source folders for the header files in the library

Figure 84. Add library header files to the include paths



Note: Libraries added by include paths are considered as static libraries because they are provided by external parties. The header files are not rescanned as the content must not have changed for external header files. If external libraries must be treated as normal source folders, the folders must also be added as source folders to the project.

Refer to [Section 2.2.1.9: Referring to projects](#) for more information if a project is referring to another project, a library or a normal project.


2.2.1.9 Referring to projects

Whenever a project is using code from another project, both projects must be referring to each other.

For a project to refer to a specific build of another project:

1. Select instead [Project]>[Properties]
2. Select [C/C++ General]>[Paths and Symbols]
3. Open the *References* tab
4. select the [Configuration] that the current project is referring to

Figure 85. Set project references



Note: When multiple projects are used as references, use the **[Move Up]** and **[Move Down]** buttons to setup the priorities.

There are many advantages to set project references correctly:

- The projects involved are not rebuilt more than necessary.
- The indexer is able to find functions from the library and open them. To use this possibility, press the **Ctrl** key and, in the editor, click the library function where it is used to open the library source file in the editor.
- It is possible to create the call hierarchy for the functions in the library. To find the call hierarchy, mark the function name and press **Ctrl+Alt+H** to display the call hierarchy in the *Call Hierarchy* view.

If a library project is added as a reference, all the correct settings in the *Paths and Symbols* property page for the library is set. The tool settings that depend on this property page are adjusted also.

This is the recommended method of adding libraries developed locally. For more information about adding libraries, refer to [Section 2.2.1.8: Include libraries](#).

Another way to have projects referring to each other is as follows:

1. Select **[Project]>[Properties]**
2. Select **[Project References]**
3. Select and mark the project for reference

With this method, however, it is not possible to refer to different build configurations and libraries are not set up automatically.

2.2.2 I/O redirection

The C run time library contains many functions, including some to handle I/Os. The I/O-related run time functions include `printf()`, `fopen()`, `fclose()`, and many others. It is common practice to redirect the I/O from these functions to the actual embedded platform. For instance, the `printf()` output can be redirected to an LCD display or serial cable while file operations like `fopen()` and `fclose()` can be redirected to a flash memory file system middleware.

2.2.2.1

printf() redirection

There are several ways to perform `printf()` redirection, such as using UART or SWV/ITM. Another solution is the Real-Time Transfer technology (RTT) provided by SEGGER.

The three techniques compare as follows:

- The UART output is maybe the most commonly used method, where the output from the embedded system is sent for instance to a terminal using RS-232. It requires some CPU overhead and medium bandwidth.
- The Instrumentation Trace Macrocell (ITM) output is efficient but requires that the Arm® CoreSight™ debugger technology with Serial Wire Viewer (SWV) is supported by the device. This is normally the case for Cortex®-M3, Cortex®-M4, Cortex®-M7, and Cortex®-M33 based devices. However, the SWV signals must be available and connected to the board also. It requires low CPU overhead but limited bandwidth. ITM output is explained in [Section 3.2: Debug with Serial Wire Viewer tracing \(SWV\)](#).
- The RTT solution is described by SEGGER on their website. RTT is a fast solution but requires SEGGER J-LINK debug probe.

To enable I/O redirection with UART or ITM output, the file `syscalls.c` must be included and built into the project. When `printf()` is used, it calls the `_write()` function, which is implemented in `syscalls.c`.

The `syscalls.c` file is normally created and included in the project when creating a new STM32CubeIDE project. The `_write()` function in this file must be modified to enable `printf()` redirection by modifying the call to `__io_putchar()`. The way to modify `_write()` depends on the hardware and library implementation.

The example below shows how to update `syscalls.c` so that `printf` output is redirected to ITM with an STM32F4 Series device. This is done by adding some header files to access `ITM_SendChar()` and make a call to `ITM_SendChar()`.

```
Original _write() function

__attribute__((weak)) int _write(int file, char *ptr, int len)
{
    int DataIdx;

    for (DataIdx = 0; DataIdx < len; DataIdx++)
    {
        __io_putchar(*ptr++);
    }
    return len;
}

Modified with added header files calling ITM_SendChar(*ptr++);

#include "stm32f4xx.h"
#include "core_cm4.h"

__attribute__((weak)) int _write(int file, char *ptr, int len)
{
    int DataIdx;

    for (DataIdx = 0; DataIdx < len; DataIdx++)
    {
        //__io_putchar(*ptr++);
        ITM_SendChar(*ptr++);
    }
    return len;
}
```

It can be noticed that the `_write` function in `syscalls.c` contains a weak attribute. This means that the `_write` function can be implemented in any C file used by the project.

For instance, the new `_write()` function can be added directly into `main.c`. Omit the weak attribute in that case, as shown in the example below.

```
int _write(int file, char *ptr, int len)
{
    int DataIdx;

    for (DataIdx = 0; DataIdx < len; DataIdx++)
    {
        //__io_putchar(*ptr++);
        ITM_SendChar(*ptr++);
    }
    return len;
}
```

2.2.3 Thread-safe wizard for empty projects and CDT™ projects

STM32CubeIDE includes a thread-safe wizard to generate files to support the use of resources that can be updated by application code and interrupts or when using a real-time operating system.

Note: *The thread-safe wizard may only be used for STM32CubeIDE empty projects. For projects managed by STM32CubeMX, the thread-safe implementation configuration must be made using STM32CubeMX dialogs.*


The thread-safe wizard creates three files and adds the `STM32_THREAD_SAFE_STRATEGY` define to the project. The files are:

- `newlib_lock_glue.c`
- `stm32_lock_user.h`
- `stm32_lock.h`

First, in the example below, a `myThreadSafe` folder is created in the empty project. This folder is selected in the *Thread-Safe Solution* wizard so that files are generated in this folder.


Open the menu [File]>[New]>[Other...] to obtain the wizard selection window shown in Figure 86.

Figure 86. Select a wizard



In the [ST] node select [Thread-Safe Solution] and press [Next >] to open the *Thread-Safe Solution* wizard.


Figure 87. Thread-Safe Solution wizard



The image shows a dialog box titled "Generate Thread-Safe Solution" with the IDE logo in the top right corner. The main heading is "Thread-Safe Solution". Below it, a red error icon and text state: "Folder 'STM32F401RE_empty' is not in a source folder." The "Source folder:" label is followed by a text input field containing "STM32F401RE_empty" and a "Browse..." button. Below this, the "Strategy:" label is followed by a dropdown menu. At the bottom, there is a help icon (?) and four buttons: "< Back" (highlighted with a blue border), "Next >", "Finish", and "Cancel".

Press **[Browse]** to open the *Generate Into Source Folder* dialog.

Figure 88. Thread-safe source folder location



Select the source folder to generate the files into and press **[OK]**.

The wizard proposes to select among five different thread-safe strategies:

1. User-defined thread-safe implementation.
2. Allow lock usage from interrupts.
3. Deny lock usage from interrupts.
4. Allow lock usage from interrupts. Implemented using FreeRTOS™ locks.
5. Deny lock usage from interrupts. Implemented using FreeRTOS™ locks.

The different strategies are explained in file `stm32_lock.h`.

```
* 1. User defined thread-safe implementation.
*   User defined solution for handling thread-safety.
*   NOTE: The stubs in stm32_lock_user.h needs to be implemented to gain
*   thread-safety.
*
* 2. Allow lock usage from interrupts.
*   This implementation will ensure thread-safety by disabling all interrupts
*   during e.g. calls to malloc.
*   NOTE: Disabling all interrupts creates interrupt latency which
*   might not be desired for this application!
*
* 3. Deny lock usage from interrupts.
*   This implementation assumes single thread of execution.
*   Thread-safety dependent functions will enter an infinity loop
*   if used in interrupt context.
*
* 4. Allow lock usage from interrupts. Implemented using FreeRTOS locks.
*   This implementation will ensure thread-safety by entering RTOS ISR capable
*   critical sections during e.g. calls to malloc.
*   By default this implementation supports 2 levels of recursive locking.
*   Adding additional levels requires 4 bytes per lock per level of RAM.
*   NOTE: Interrupts with high priority are not disabled. This implies
*   that the lock is not thread-safe from high priority interrupts!
*
* 5. Deny lock usage from interrupts. Implemented using FreeRTOS locks.
*   This implementation will ensure thread-safety by suspending all tasks
*   during e.g. calls to malloc.
*   NOTE: Thread-safety dependent functions will enter an infinity loop
*   if used in interrupt context.
```

Select a strategy as shown in Figure 89.

Figure 89. Thread-safe strategy selection

IDE Generate Thread-Safe Solution

Thread-Safe Solution

Generate a set of files that provide the ST thread-safe solution.

Source folder:

Strategy: Generic Strategy #3 - Deny lock usage from interrupts


- Generic Strategy #1 - Custom implementation
- Generic Strategy #2 - Allow lock usage from interrupts
- Generic Strategy #3 - Deny lock usage from interrupts
- FreeRTOS Strategy #4 - Allow lock usage from interrupts
- FreeRTOS Strategy #5 - Deny lock usage from interrupts

Select a strategy and press **[Finish]** to generate the files into the selected source folder.

Note: *The files generated are the same and contain the same information independently of the selected strategy.*

A new define, `STM32_THREAD_SAFE_STRATEGY=3`, is added by the wizard to the project for use by the preprocessor when building the project. The define value is set according to the strategy selected in the wizard. The define can be observed by opening the project properties and looking into the *Tool Settings* tab.


Figure 90. Thread-safe properties



The generated files are shown in the *Project Explorer*.


Note: *The generated files require that some CMSIS header files are included in the project. The files must be copied and added manually into the project if they are missing.*

Figure 91. Thread-safe files



If the wizard is started while the project is managed by STM32CubeMX, an error is displayed stating that STM32CubeMX must be used to manage the thread-safe strategy.

Figure 92. Thread-safe error dialog



2.2.4

Position-independent code

This section is of interest to users working on applications where the final address location is not defined in the system. This occurs for instance when using a bootloader: the system designer must be able to define the final location of the application. In such case, position-independent code (PIC) can be used. The `-fPIE` compiler option enables the compiler/linker to generate position-independent executable.

Compiling with option `-fPIE` generates position-independent executable so that if the application is linked for address `0x800 0000` but placed at `0x800 1000`, it still runs.

However, the information in this section is not complete. The solution it describes works when using global data initialized to zero (`.bss`) but it does not work when using initialized data and has several other limitations. One such limitation is that run time libraries included in the STM32 toolchain cannot be used as these libraries are built without the `-fPIE` option for optimization. Instead of using position-independent code in a system, it is worth considering other solutions.

Alternate solution example:

If a system is designed to have a bootloader and multiple versions of an application in flash memory at different slots, it may be easier to setup multiple build configurations for the application. Each build configuration is based on its own linker script file. In this case, there is no need to use position-independent code since run time libraries can be used. Each build configuration links the application to a unique slot in flash memory, generating one single `elf` file per slot. When downloading a new version of the application into a slot, the correct `elf` file must be used. The bootloader can be designed to validate the addresses in the `elf` file and generate an error if it contains addresses that are out of the slot. The application can copy the interrupt vector table to RAM and update vector copies depending on the slot where the application is stored.


2.2.4.1

Adding the `-fPIE` option

To add the `-fPIE` option into the tool settings:

1. Right-click the project in the *Project Explorer* view and select **[Properties]**
2. In the dialog, select **[C/C++ Build]>[Settings]**
3. Select the *Tool Settings* tab in the panel
4. Select **[MCU GCC Compiler]>[Miscellaneous]**
5. Add `-fPIE` to the **[Other flags]** field.

Figure 93. Position independent code, `-fPIE`



2.2.4.2 Run time library

The C run time library is compiled without using the `-fPIE` option. So any call to the library must be avoided when generating position-independent executable. The startup code normally has a call to `__libc_init_array`. This call must be removed as in the example below:

```
/* Call static constructors */
/* bl __libc_init_array */
```

2.2.4.3 Stack pointer configuration

Make sure that the stack pointer is set up correctly. The stack pointer must be set in the `Reset_Handler` in the startup file as shown in the example below. It must not be assumed that the stack pointer is set by a reset reading it from the vector table.

```
Reset_Handler:
    ldr    sp, =_estack          /* set stack pointer */
```

2.2.4.4

Interrupt vector table

The vectors in the vector table must be updated if the program is loaded to an offset address. If a program needs to add the offset to each vector in the table, it can copy the interrupt vector table to the RAM and add the offset to this vector table.

The vector base register must also be changed so that it points to the new located vector table as shown in the example below:

```
/* Set Vector Base Address */
SCB->VTOR=RAM_VectorTable;
```

2.2.4.5

Global offset table

The global offset table (GOT) is a table of addresses normally stored in the data section when building and using the `-fPIE` option. It is used by the executed program to find, during run time, addresses of global variables, unknown at compile time. If no global variable location change is needed, the variables can be located at same place as located when linking the program. Then the GOT table can be placed in the `.text` section in the flash memory area instead.

The example below shows how to update the linker script with the `.got*` section. In this case the `GOT_START` and `GOT_END` symbols are added also so that the tools are able to know the GOT location and size.

```
/* The program code and other data into "ROM" Rom type memory */
.text :
{
    . = ALIGN(4);
    *(.text)           /* .text sections (code) */
    *(.text*)          /* .text* sections (code) */
    GOT_START = .;
    *(.got*)
    GOT_END = .;
    *(.glue_7)         /* glue arm to thumb code */
    *(.glue_7t)        /* glue thumb to arm code */
    *(.eh_frame)

    KEEP (*(init))
    KEEP (*(fini))

    . = ALIGN(4);
    _etext = .;        /* define a global symbols at end of code */
} >ROM
```

2.2.4.6 *Interrupt vector table and symbols*

When debugging the code with an offset, both the load offset and the new symbol address must be specified. The symbol address to provide is the `.text` section address. The linker script can be updated by defining `.isr_vector` to be located into `.text`. This avoids the issue of finding the location of `.text`.

Remove the following

```
.isr_vector :
{
  . = ALIGN(4);
  KEEP(*(.isr_vector)) /* Startup code */
  . = ALIGN(4);
} >FLASH
```

Add `KEEP(*(.isr_vector))` instead to first location of `.text`

```
/* The program code and other data into "FLASH" Rom type memory */
.text :
{
  . = ALIGN(4);
  KEEP(*(.isr_vector)) /* Startup code */
  *(.text)              /* .text sections (code) */
  *(.text*)             /* .text* sections (code) */
  GOT_START = .;
  *(.got*)
  GOT_END = .;
  *(.glue_7)            /* glue arm to thumb code */
  *(.glue_7t)           /* glue thumb to arm code */
  *(.eh_frame)

  KEEP (*(.init))
  KEEP (*(.fini))

  . = ALIGN(4);
  _etext = .;           /* define a global symbols at end of code */
} >FLASH
```

2.2.4.7 *Debugging position-independent code*

When debugging position-independent code located at an offset, the download offset and new symbol address must be set.

Figure 94. Debugging position independent code




Figure 94 illustrates an example where the download offset is 0x1000 and the symbol address is 0x800 1000. It is possible to set the symbol address to 0x800 1000 in this case because the `.isr_vector` is added into the `.text` section as described in [Section 2.2.4.6: Interrupt vector table and symbols](#).

If instead the `.isr_vector` is located in another section outside `.text`, the start address of the `.text` section must be used with the offset added. For instance, if the map file states that `.text` starts at 0x0000 0000 0800 0194, the symbol address in this case must be set to 0x800 1194.


Figure 94 shows that the breakpoint is set at `main` and that the program counter (`$pc`) is set to the `Reset_Handler` symbol into **[Run Commands]**. This symbol contains the correct address to the `Reset_Handler` because gdb uses the base symbol address 0x800 1000. If `$pc` is not setup during this debug configuration, the **[Resume]** checkbox must be disabled to make the program stop after load. In this case, the program counter must be set manually in the *Registers* view before starting the program.

2.2.5 Exporting projects

A project can be exported in many different ways. This section shows how to export a project as a compressed zip file.


Right-click the project in the *Project Explorer* view and select **[Export...]**.

Figure 95. Export project




The *Export* dialog opens. Select **[General]>[Archive File]** and press **[Next >]**.

Figure 96. Export dialog



The *Export* dialog is updated. Select the project to be exported. It is possible to exclude some project files from the export. In the example in Figure 97, all project and library files are included. A file name must be entered into the **[To archive file]** field, possibly browsing to a folder location for the file with the **[Browse...]** button. In the example, the default options values are kept unchanged. Press **[Finish]** to export the project and create the zip file.

Figure 97. Export archive



2.3 Build and compile C/C++ projects


2.3.1 Toolchain Manager

The *Toolchain Manager* is used to install toolchains, uninstall toolchains and select the default workspace toolchain when building a project.

To open the *Toolchain Manager* from the *Tool Settings* tab in project properties:

1. Select the **[MCU Toolchain]** node

Figure 98. Open Toolchain Manager




2. Click on **[Open Toolchain Manager...]**

The *Toolchain Manager* can also be opened from the **[Window]>[Preferences]** menu:

1. Select **[STM32Cube]>[Toolchain Manager]**

Figure 99. Toolchain Manager



The columns in the *Toolchain Manager* are described in Table 4.

Table 4. Toolchain Manager column details

Name	Description
Default	A green/grey arrow symbol indicates the default workspace toolchain. The arrow color is: <ul style="list-style-type: none"> green when the toolchain is manually set as default by the user grey when the toolchain is selected as default by STM32CubeIDE logic
Name	The name of the toolchain.
State	The state of the toolchain. Toolchains available for download from STMicroelectronics online repository are listed as “installed” or “not installed”. Local toolchains added by the user are listed as “local”.

The buttons in the *Toolchain Manager* are described in Table 5.


Table 5. Toolchain Manager button information

Name	Description
Add Local...	Add reference to local toolchain.
Edit Local...	Edit reference to local toolchain.
Install... Uninstall... Remove...	The button text depends on the type of the selected toolchain. It is used to: <ul style="list-style-type: none"> Install / Uninstall the selected toolchain provided by the repository Remove the selected local toolchain
Reload	Reload the toolchain list from the repository.
Set Default	Set selected toolchain to be used by default.
Restore Defaults	Restore and use the default toolchain.
Apply and Close	Apply selection and close dialog.
Cancel	Cancel dialog.

2.3.1.1 Install a new toolchain


Open the *Toolchain Manager* to install a new toolchain.

Figure 100. Install toolchain




Select the toolchain to install and click on **[Install...]**. The *Install* dialog opens and displays the items to be installed.

Figure 101. Check items to install




Check the items to install and click on **[Next]**.

Figure 102. Review items to install




Review the items and click on **[Next]**.

Figure 103. Review and accept licenses




Review the licenses, select **[I accept the terms of the license agreements]** and click on **[Finish]**.
At this point, the software installation starts. The progress bar displayed at the bottom of the STM32CubeIDE window shows the installation completion rate. Wait until the installation is completed.
The following warning may appear before the installation is finished.

Figure 104. Security warning



In this case, to finalize the installation, click on **[Install anyway]**. After some time, the following dialog is displayed.


Figure 105. Restart to apply software update



Click on **[Restart Now]** to be able to use the installed toolchain in STM32CubeIDE. STM32CubeIDE is restarted and the new toolchain can be used.

Open the *Toolchain Manager* to verify the installation.

Figure 106. Toolchain installed




In this case, [Figure 106](#) shows that two versions of *GNU Tools for STM32* are installed.

2.3.1.2 Manage the default toolchain

The *Toolchain Manager* highlights the default workspace toolchain with an arrow in the *Default* column.


Figure 107. Default toolchain



[Figure 107](#) shows that *GNU Tools for STM32* version 9-2020-q2-update is the default workspace toolchain. The *GNU Tools for STM32* version 7-2018-q2-update line is marked in blue, which indicates that this toolchain selected. Any line in the table can be selected with the mouse.

Click on **[Set default]**: the selected toolchain to be used as the default workspace toolchain is highlighted with an arrow symbol in the *Default* column of the *Toolchain Manager*.

Figure 108. Default toolchain updated




Click on **[Apply and Close]** to apply the setting and update which toolchain is set to be the default workspace toolchain.

2.3.1.3 Uninstall a toolchain

It is not possible to uninstall the *GNU Tools for STM32* toolchain, which is installed by default with STM32CubeIDE. Any other installed toolchain can be uninstalled.


Figure 109. Uninstall toolchain



To uninstall a toolchain, select it in the *Toolchain Manager* and click on **[Uninstall...]**.


This opens the *Uninstall* dialog.

Figure 110. Uninstall details



Click on **[Finish]** to start the software uninstallation. The *Software Updates* dialog is displayed.

Figure 111. Software updates




Click on **[Restart Now]** to apply the software update.

The product is restarted.

Open the *Toolchain Manager* to verify the installation.

Figure 112. Toolchain uninstalled



In this case, Figure 112 shows that only one version of *GNU Tools for STM32* is installed.

2.3.1.4

Using a toolchain

It is possible to add and use an already installed local GNU ARM toolchain. To add a local toolchain, follow the steps below:

1. Open *Toolchain Manager* and press the **[Add Local...]** button.

Figure 113. Add local toolchain

IDE

Add local toolchain

Give the toolchain a name

Name:

Prefix:

Location:

2. Add a name and specify location.

Figure 114. Specify local toolchain location

Add local toolchain

The following toolchain applications are missing: arm-none-eabi-addr2line.exe, arm-none-eabi-gcc.exe, arm-none-eabi-nm.exe, arm-none-eabi-objcopy.exe, arm-none-

Name: TrueSTUDIO


Prefix: arm-none-eabi-

Location: C:\Program Files (x86)\Atollic\TrueSTUDIO for STM32 9.3.0\ARMTools\bin [Browse...](#)

[?](#) [Finish](#) [Cancel](#)

As seen in [Figure 114](#), some naming problems can occur. In this case, the problem results from a wrong prefix that prevents the toolchain application validation.
Update the toolchain prefix. The prefix must end with a dash (-).

Figure 115. Specify local toolchain prefix



IDE

Add local toolchain

Name: TrueSTUDIO


Prefix: arm-atollic-eabi-

Location: C:\Program Files (x86)\Atollic\TrueSTUDIO for STM32 9.3.0\ARMTools\bin Browse...

? Finish Cancel


3. Press **[Finish]**.

Figure 116. Local toolchain added



4. Use the **[Edit Local...]** button to edit local toolchain. The *Edit local toolchain* dialog opens, and it is possible to update *Prefix* and *Location*.

Figure 117. Edit local toolchain




5. Update *Prefix* or *Location* and press **[Finish]** to update local toolchain settings.

2.3.1.5 Network error

In case of problem to access the update site, the *Network error...* dialog is displayed.

Figure 118. Toolchain network error



Check the network settings. Information on how to configure network proxy settings are described in [Section 1.5.3: Preferences - Network proxy settings](#).

2.3.2 Configure the project build setting

When an STM32 project is created, it contains default C/C++ build settings for the project. There are however a lot of different options that can be used by GCC, each embedded system having its own requirements. It is therefore possible to configure the project build settings further than the default build settings.

It is also common to have different requirements on build settings during different phases of the project development; for instance during the debugging and release phases. To handle this, different build configurations for each project are supported by STM32CubeIDE. This section presents the build configurations first, and then the project build settings.

2.3.2.1 Project build configuration

Each build configuration allows different variants of a project and contains a specific build setting. When an STM32 project is created in STM32CubeIDE, two build configurations, *Debug* and *Release*, are created by default. The *Debug* configuration makes the project built with debug information and without any optimization. The *Release* configuration makes the project optimized for smaller code size and with no debug information. By default, the *Debug* configuration is set as the active build configuration when the project is created.


It is possible to create new build configurations for a project at any time. Such new build configuration can be based on an earlier available build configuration.

When building the project, the active build configuration is used and during build the files generated are written into a folder with the same name as the active build configuration.

Note: *The build configuration only handles the build settings. How to configure debug settings is described later in this manual.*


2.3.2.1.1 Change the active build configuration

To change the active build configuration:

1. Select the project name in the *Project Explorer*
2. Use the toolbar in the C/C++ perspective and click on the arrow to the right of the **[Build]** toolbar button 
3. The build configurations are listed


Select the build configuration to use from the list.

Figure 119. Set the active build configuration using the toolbar




Another way to change the active build configuration is to right-click on the project name in the *Project Explorer* view, select **[Build Configurations]>[Set Active]**, and select the preferred build configuration.

Figure 120. Set active build configuration using right-click



It is also possible to select the active build configurations using the menu **[Project]>[Build Configurations]>[Set Active]** and select the chosen build configuration.

Figure 121. Set active build configuration using menu




2.3.2.1.2 Create a new build configuration

To create a new build configuration:

1. Right-click on the project name in the *Project Explorer* view
2. Either:
 - Select **[Build Configurations]>[Manage...]**
 - Use the menu **[Project]>[Build Configurations]>[Manage...]**

Both methods open the *Manage Configurations* dialog.

Figure 122. Manage Configurations dialog



As shown in Figure 122, some buttons in the dialog are used to manage the configurations:

- **[Set Active]** is used to change and select another configuration to be active
- **[New...]** is used to create a new build configuration
- **[Delete]** is used to delete an existing build configuration
- **[Rename...]** is used to rename the build configuration

To create a new build configuration, press the **[New...]** button. This opens the *Create New Configuration* dialog. In this dialog, a name and description is entered. The name must be a valid directory name since it is used as the directory name when building the project with the new configuration.

Figure 123. Create a new build configuration

The dialog box titled "IDE Create New Configuration" contains a note: "Note: The configuration name will be used as a directory name in the file system. Please ensure that it is valid for your platform." Below the note are two text input fields: "Name:" with the value "Debug2" and "Description:" with the value "My own debug configuration". Under the heading "Copy settings from", there are four radio button options: "Existing configuration" (selected), "Default configuration", "Import from projects", and "Import predefined". To the right of these options are three dropdown menus. The first dropdown menu is open, showing "Debug" (selected), "Debug", and "Release". The second and third dropdown menus show "-- not selected --". At the bottom right are "OK" and "Cancel" buttons.

As seen in Figure 123, the new build configuration is based on an existing build configuration. In the case illustrated, the new configuration is based on the existing *Debug* configuration. Press **[OK]** when finished with the settings.

The *Manage Configurations* dialog opens and the new debug configuration is displayed.

Figure 124. Updated Manage Configurations dialog

The dialog box titled "IDE NUCLEO-F401RE: Manage Configurations" displays a table with three columns: "Configuration", "Description", and "Status". The table contains three rows: "Debug" (Status: Active), "Debug2" (Description: My own debug con...), and "Release". Below the table are four buttons: "Set Active", "New...", "Delete", and "Rename...". At the bottom right are "OK" and "Cancel" buttons.

Configuration	Description	Status
Debug		Active
Debug2	My own debug con...	
Release		

Change the active configuration to another configuration if needed and press **[OK]** to save and close the configurations dialog when finished managing configurations.


2.3.2.1.3 Delete a build configuration

To delete a build configuration:

1. Open the *Manage Configurations* dialog
2. Select the configuration to be deleted
3. Press the **[Delete]** button

For instance, if the *Debug2* configuration is selected and **[Delete]** button is pressed, the following confirmation dialog opens.

Figure 125. Configuration deletion dialog



In this case, select **[No]** to keep the *Debug2* configuration.


2.3.2.1.4 Rename a build configuration

To rename a build configuration:

1. Open the *Manage Configurations* dialog
2. Select the configuration to be renamed
3. Press the **[Rename...]** button

For instance, if the *Debug2* configuration is selected and **[Rename...]** button is pressed, the following confirmation dialog opens.

Figure 126. Configuration renaming dialog




Update the name, description, or both and press **[OK]** to rename the *Debug2* configuration. In this case, press **[Cancel]** and keep the name.

2.3.2.2 Project C/C++ build settings

Each build configuration contains one project C/C++ build setting. The project C/C++ build setting is updated in project properties. To update the build setting, right-click on the project name in the *Project Explorer* view and select **[Properties]** or use the menu **[Project]>[Properties]**. Both these ways open the *Properties* window for the project.

Select **[C/C++ Build]>[Settings]** in the *Properties* left pane. The right part is then filled with tabs *Tool Settings*, *Build Steps*, *Build Artifact*, *Binary Parsers*, and *Error Parsers*. The first two tabs are the most useful ones.


Figure 127. Properties tabs



Note: *Resize the dialog window or use the top-right arrow buttons if all tabs are not visible.*

The *Settings* pane contains a **[Configuration]** selection to decide if new selections are used in the active configuration only, in another configuration, in all configurations or in multiple configurations. Press **[Manage Configurations]** to open the *Manage Configurations* dialog.

Figure 128. Properties configurations




The *Tool Settings* tab is further split into *MCU Toolchain*, *MCU Settings*, *MCU Post build outputs*, *MCU GCC Assembler*, *MCU GCC Compiler* and *MCU GCC Linker*.

MCU Toolchain is used to change toolchains. *STM32CubeIDE* includes one version of the *GNU Tools for STM32* toolchain. The *Toolchain Manager* is used to download other *GNU ARM Embedded* toolchains and to configure to use local *GNU ARM Embedded* toolchains.


Information about patches made in *GNU Tools for STM32* can be read in [EXT-12]. The document can be opened from the *Technical Documentation* page in the *Information Center*.

Figure 129. Properties toolchain version



Select **[Fixed]** to enable the toolchain selection.


Figure 130. Properties toolchain selection



As shown in Figure 130, only the default toolchain *GNU Tools for STM32* is available by default. To install additional toolchains, click on the **[Open Toolchain Manager...]** button to open the *Toolchain Manager*. [Section 2.3.1: Toolchain Manager](#) contains detailed information on how to install, uninstall toolchains and select the default workspace toolchain.

MCU Settings displays the selected MCU and board for the project and proposes to select how to handle floating point, instruction set and runtime library.


Figure 131. Properties tool MCU settings



MCU Post build outputs proposes to convert the `elf` file to another file format, show build size information, and generate list file. The output file can be converted to:


- Binary file
- Intel Hex file
- Motorola S-record file
- Motorola S-record symbols file
- Verilog file

Figure 132. Properties tool MCU post-build settings




The *MCU GCC Assembler* settings contains selections for the assembler. The main node presents all the assembler command-line options that are currently enabled in the sub-node settings. The sub-nodes are used to view the current settings or change any settings for the assembler.

Figure 133. Properties tool GCC assembler settings




The *MCU GCC Compiler* settings contains selections for the compiler. The main node presents all the compiler command-line options that are currently enabled in the sub-node settings. The sub-nodes are used to view the current settings or change any settings for the compiler.

Figure 134. Properties tool GCC compiler settings




The *MCU GCC Linker* settings contains selections for the linker. The main node presents all the linker command-line options that are currently enabled in the sub-node settings. The sub-nodes are used to view the current settings or change any settings for the linker.

Figure 135. Properties tool GCC linker settings



The *Build Steps* settings contains fields used to provide pre-build and post-build steps, which run before and after building the project. Edit the fields to run any pre-build or post-build step.

Figure 136. Properties build steps settings




Note: It is possible to add more advanced post-build operations using makefile targets as described in [Section 2.3.3.7](#).

2.3.3 Building the project

To start a build, select the corresponding project in the *Project Explorer* view and click on the **[Build]** toolbar button.

Figure 137. Project build toolbar




The build can also be started from menu **[Project]>[Build Project]**. The **[Project]** menu contains also some other usable build commands such as **[Build All]**, **[Build Project]** or **[Clean]**.


Another way to start a build is to right-click on the project in the *Project Explorer* view. This opens the context menu with the **[Build]** command and some other build options.

During the build, the *Console* view lists the build process. At the end, when the `elf` file is created normally, it lists size information.

Figure 138. Project build console




2.3.3.1 Building all projects

The toolbar contains the **[Build all]**  button, which is used to build the active build configuration for all open projects in workspace.

It is also possible to use the menu **[Project]>[Build All]** to start a build of all projects.


Figure 139. Project build all



2.3.3.2 Build all build configurations

To build all build configurations for a project, right-click the project and select **[Build Configurations]>[Build All]** in the context menu.

Figure 140. Project build-all configurations



2.3.3.3 Headless build

Headless build is intended to be used to build projects that must be integrated into script-controlled builds, such as nightly builds on build servers for continuous integration process methods or others. The STM32CubeIDE GUI is never displayed in this case, and the user is not requested any manual interaction with STM32CubeIDE.

STM32CubeIDE includes a `headless-build` command file to run headless builds. For instance, when using Windows®, it is located in the `C:\ST\STM32CubeIDE_1.7.0\STM32CubeIDE\STM32CubeIDE` STM32CubeIDE installation folder. The `headless-build.bat` file is intended to be run from a command prompt.

Note: Before running any headless build, make sure that the workspace is not opened by STM32CubeIDE. If there is an STM32CubeIDE running already using the workspace, it is not possible for the headless-build process to open and build the project.

To run headless build in Windows®, use the following procedure:

1. Open a command prompt.
2. Navigate to the STM32CubeIDE installation directory. Open the folder in which the IDE is stored.
For example: `cd C:\ST\STM32CubeIDE_1.7.0\STM32CubeIDE`
3. Enter the following command to build the NUCLEO-F401RE project in the workspace

```
C:\Users\Name\STM32CubeIDE\workspace_1.7.0:
$ headless-build.bat -data C:\Users\Name\STM32CubeIDE\workspace_1.7.0
-cleanBuild NUCLEO-F401RE
```

To get help on headless build parameters, use headless build with option `-help`. Figure 141 shows the result of command `$ headless-build.bat -help`.

Figure 141. Headless build

```

C:\ST>cd STM32CubeIDE_1.7.0.21alpha1
C:\ST\STM32CubeIDE_1.7.0.21alpha1>headless-build.bat -help
Usage: PROGRAM -data <workspace> -application org.eclipse.cdt.managedbuilder.core.headlessbuild [ OPTIONS ]

-data      {/path/to/workspace}
-import    {[uri:/]path/to/project}
-importAll {[uri:/]path/to/projectTreeURI} Import all projects under URI
-build     {project_name_reg_ex{/config_reg_ex} | all}
-cleanBuild {project_name_reg_ex{/config_reg_ex} | all}
-markerType Marker types to fail build on {all | cdt | marker_id}
-no-indexer Disable indexer
-printErrorMarkers Print all error markers
-I         {include_path} additional include_path to add to tools
-include   {include_file} additional include_file to pass to tools
-D         {preproc_define} addition preprocessor defines to pass to the tools
-E         {var=value} replace/add value to environment variable when running all tools
-Ea        {var=value} append value to environment variable when running all tools
-Ep        {var=value} prepend value to environment variable when running all tools
-Er        {var} remove/unset the given environment variable
-T         {toolid} {optionid=value} replace a tool option value in each configuration build
-Ta        {toolid} {optionid=value} append to a tool option value in each configuration build
-Tp        {toolid} {optionid=value} prepend to a tool option value in each configuration build
-Tr        {toolid} {optionid=value} remove a tool option value in each configuration build
           Tool option values are parsed as a string, comma separated list of strings or a boolean based on the options type
  
```

2.3.3.4 Temporary assembly file and preprocessed C code

Save the temporary assembly file by adding the `-save-temps` flag to the compiler:

1. In the menu, select **[Project]>[Properties]**
2. Select **[C/C++ build]>[Settings]**
3. Open the *Tool Settings* tab
4. Add `-save-temps` in the **[C Compiler]>[Miscellaneous]** settings
5. Rebuild the project

The assembler file is located in the build output directory with name `filename.s`.

The file `filename.i` containing the preprocessed C code is generated also. It shows the code after the preprocessor but before the compilation. It is advise to examine the content of this file in case of problems with defines.

2.3.3.5 Build logging

To enable or disable project build logging, right-click on the project in the *Project Explorer* view and select **[Properties]**. Then, select **[C/C++ Build]>[Logging]**. The log file location and name are also specified.

To enable a global build log for all projects in a workspace, select **[Window], [Preferences]**, and open **[C/C++, Build, Logging]>[Enable global build logging]**.

2.3.3.6 Parallel build and build behaviour


Parallel build occurs when more than one thread is used at the same time to compile and build the code. Most often, it reduces build time significantly. The optimal number of threads to use is usually equal to the number of CPU cores of the computer. Parallel build can be enabled and disabled.

To configure parallel build:

1. Right-click on the project in the *Project Explorer* view
2. Select menu **[Project]>[Properties]**
3. Select **[C/C++ Build]** in the *Properties* panel
4. Open the *Behavior* tab and configure **[Enable parallel build]**

The *Behavior* tab also contains build settings on how to behave on errors, build on resource save, incremental build, and clean.

Figure 142. Parallel build



2.3.3.7 Post-build with makefile targets

It is possible to add advanced post-build scripts by using makefile targets. To do this:

1. Create a new file
2. Name it `makefile.targets`
3. Place it in the root directory of the project

The content of the file must be similar to the example presented below. The example just copies the `elf` generated file to a new file and uses macros `BUILD_ARTIFACT`, `BUILD_ARTIFACT_PREFIX`, `BUILD_ARTIFACT_NAME`, and `BUILD_ARTIFACT_EXTENSION`, which are generated into the makefile by STM32CubeIDE from v1.5.0.

```
secure_target := \
    $(BUILD_ARTIFACT_PREFIX)$(BUILD_ARTIFACT_NAME)-secure.$(BUILD_ARTIFACT_EXTENSION)
main-build: $(secure_target)

$(secure_target): $(BUILD_ARTIFACT)
    # Do what you want here... simple copy file for demo
    cp "$$<" "$@"
```

Note: *make* requires that tabs are used instead of spaces.

2.4 Build Analyzer

2.4.1 Introduction to the Build Analyzer

The STM32CubeIDE Build Analyzer feature interprets program information from the `elf` file in detail and presents the information in a view. If a `map` file, with similar name, is found in the same folder as the `elf` file the information from the `map` file is also used and even more information can be presented.

The *Build Analyzer* view is useful to optimize or simplify a program. The view contains two tabs, the *Memory Regions* and *Memory Details* tabs:

- The *Memory Regions* tab is populated with data if the `elf` file contains a corresponding `map` file. When the `map` file is available, this tab can be seen as a brief summary of the memory regions with information about the region name, start address and size. The size information also comprises the total size, free and used part of the region, and usage percentage.
- The *Memory Details* tab contains detailed program information based on the `elf` file. The different section names are presented with address and size information. Each section can be expanded and collapsed. When a section is expanded, functions/data in this section is listed. Each presented function/data contains address and size information.

2.4.2 Using the *Build Analyzer*

The *Build Analyzer* view is by default open in the C/C++ perspective. If the view is closed it can be opened from the menu. Select the menu command **[Window]>[Show View]>[Build Analyzer]** or use the **[Quick Access]** field, search for “*Build Analyzer*” and select it from the views.

When the *Build Analyzer* view is open, select an `elf` file in the *Project Explorer* view. The *Build Analyzer* view is then updated with the information from this file. When an `elf` file is selected and a `map` file, with similar name, is found in the same folder, additional information from the `map` file is also used by the view.

The *Build Analyzer* view is also updated if a project node in the *Project Explorer* view is selected. In this case the *Build Analyzer* uses the `elf` file that corresponds to the current active build configuration of the project.

Figure 143. Build analyzer

Region	Start address	End address	Size	Free	Used	Usage (%)
FLASH	0x08000000	0x08080000	524288	518840	5448	1.04%
RAM	0x20000000	0x20018000	98304	96604	1700	1.73%

2.4.2.1 *Memory Regions* tab

The *Memory Regions* tab in the *Build Analyzer* view displays information based on the corresponding `map` file. If no information is displayed, it means that there is no corresponding `map` file found. When a `map` file is found, the region names, start address, end address, total size of region, free size, used size and usage information are presented.

These regions are usually defined in the linker script file (`.ld`) used when building the program. Update the linker script file if a memory region location or size must be changed.

Note: The *Memory Regions* tab is empty if the `elf` file has no corresponding `map` file.

Figure 144. Memory Regions tab

Region	Start address	End address	Size	Free	Used	Usage (%)
RAM	0x20000000	0x20018000	96 KB	16.23 KB	79.77 KB	83.09%
FLASH	0x08000000	0x08040000	256 KB	236.17 KB	19.83 KB	7.75%
FLASH_ICONS	0x08040000	0x08050000	64 KB	44.47 KB	19.53 KB	30.52%
FLASH_IMAGES	0x08050000	0x08070000	128 KB	10.81 KB	117.19 KB	91.55%
FLASH_SOUND	0x08070000	0x0807f000	60 KB	7.75 KB	52.25 KB	87.08%
FLASH_D	0x0807f000	0x0807f800	2 KB	1.99 KB	8 B	0.39%
FLASH_V	0x0807f800	0x08080000	2 KB	1.99 KB	12 B	0.59%

The column information is described in the Table 6.

Table 6. Memory Regions tab information

Name	Description
Region	Name of memory region (if a corresponding <code>map</code> file is found).
Start address	The start address of the region, defined in the linker script.
End address	End address of the region.
Size	The total size of memory region.
Free	The free size in the memory region.
Used	The used size in the memory region.
Usage %	The percentage of used size relative to the total memory region size. See Table 7 for the bar icon color information.

The *Usage (%)* column contains a bar icon corresponding to the percentage value. The bar has different colors depending on the percentage of used memory.

Table 7. Memory Regions usage color

Usage color	Description
Green	Less than 75% of memory used.
Yellow	75% to 90% of memory used.
Red	More than 90% of memory used.

2.4.2.2

Memory Details tab

The *Memory Details* tab of the *Build Analyzer* view contains information for the `elf` file. Each section in the *Memory Details* tab can be expanded so that individual functions and data can be seen. The tab presents columns with name, run address, load address, and size information.

Figure 145. Memory Details tab

Name	Run address (VMA)	Load address (LMA)	Size
RAM	0x20000000		96 KB
> .data	0x20000000	0x08004f49	12 B
> .bss	0x2000000c		78.25 KB
_user_heap_stack	0x2001390c		1.5 KB
FLASH	0x08000000		256 KB
> FLASH_ICONS	0x08040000		64 KB
> FLASH_IMAGES	0x08050000		128 KB
> .flash_images	0x08050000	0x08050000	117.19 KB
image3	0x08064c08	0x08064c08	34.18 KB
image2	0x080561a8	0x080561a8	58.59 KB
image1	0x08050000	0x08050000	24.41 KB
> FLASH_SOUND	0x08070000		60 KB
> .flash_sound	0x08070000	0x08070000	52.25 KB
> FLASH_D	0x0807f000		2 KB
> .flash_d	0x0807f000		8 B
> FLASH_V	0x0807f800		2 KB
> .flash_v	0x0807f800	0x0807f800	12 B

The column information is described in Table 8.

Table 8. Memory Details tab information

Name	Description
Name	Name of memory region, section, function, and data. A green icon is used to mark functions while the blue icon is used for data variables.
Run Address (VMA)	The Virtual Memory Address contains the address used when the program is running.
Load Address (LMA)	The Load Memory Address is the address used for load, for instance for the initialization values of global variables.
Size	Used size (total size for <i>Memory Regions</i>).

Note: The memory region name is only displayed if a corresponding *map* file is found.

2.4.2.2.1 Size information

The size information in the *Memory Details* tab is calculated from the symbol size in the *elf* file. If a corresponding *map* file is investigated, it may contain a different size value. The size is usually correct for C files but the value presented for assembler files depends on how the size information is written in the assembler files. The constants used by the function must be defined within the section definition. At the end of the section, the size directive is used by the linker to calculate the size of the function.

Example: Reset_Handler in startup.s file

This example shows how to write the `Reset_Handler` in an assembler startup file to include the constants `_sdata`, `_sdata`, `_edata`, `_sbss`, and `_ebss` in the `Reset_Handler` size information in the `elf` file. If these constants are defined out of the `Reset_Handler` section definition, their sizes are not included in the calculated size of the `Reset_Handler`. To include them in the size of the `Reset_Handler`, these definitions must be placed inside the `Reset_Handler` section as presented in the code example below.

```
.section .text.Reset_Handler
.weak Reset_Handler
.type Reset_Handler, %function

Reset_Handler:
ldr sp, =_estack /* set stack pointer */

/* Copy the data segment initializers from flash to SRAM */
movs r1, #0
b LoopCopyDataInit

CopyDataInit:
ldr r3, =_sdata

/* initialization code data, bss, ... */
...

/* Call the application's entry point */
bl main
bx lr

/* start address for the initialization values defined in linker script */
.word _sdata
.word _sdata
.word _edata
.word _sbss
.word _ebss

.size Reset_Handler, .-Reset_Handler
```

2.4.2.2.2

Sorting

The sort order of a *Memory Details* tab column can be changed by clicking on the column name.

Figure 146. *Memory Details* sorted by size

Name	Run address (VMA)	Load address (LMA)	Size
> FLASH	0x08000000		256 KB
▼ FLASH_IMAGES	0x08050000		128 KB
▼ .flash_images	0x08050000	0x08050000	117.19 KB
image2	0x080561a8	0x080561a8	58.59 KB
image3	0x08064c08	0x08064c08	34.18 KB
image1	0x08050000	0x08050000	24.41 KB
▼ RAM	0x20000000		96 KB
> .bss	0x2000000c		78.25 KB
_user_heap_stack	0x2001390c		1.5 KB
> .data	0x20000000	0x08004f49	12 B
> FLASH_ICONS	0x08040000		64 KB
> FLASH_SOUND	0x08070000		60 KB
▼ FLASH_D	0x0807f000		2 KB
> .flash_d	0x0807f000		8 B
▼ FLASH_V	0x0807f800		2 KB
> .flash_v	0x0807f800	0x0807f800	12 B

2.4.2.2.3

Search and filter

The information in the *Memory Detailstab* can be filtered by entering a string in the search field.

Figure 147 shows a search example for names including the string “sound”.

Figure 147. *Memory Details* search and filter

Name	Run address (VMA)	Load address (LMA)	Size
▼ FLASH_SOUND	0x08070000		60 KB
▼ .flash_sound	0x08070000	0x08070000	52.25 KB
sound1	0x08070000	0x08070000	19.53 KB
sound2	0x08074e20	0x08074e20	19.53 KB
sound4	0x0807afc8	0x0807afc8	8.3 KB
sound3	0x08079c40	0x08079c40	4.88 KB

2.4.2.2.4 Calculate the sum of sizes

The sum of the sizes of several lines in the *Memory Details* tab can be calculated by selecting these lines in the view. The sum of the selection is presented above the *Name* column in the view.

Figure 148. Sum of sizes

Name	Run address (VMA)	Load address (LMA)	Size
> FLASH	0x08000000		256 KB
▼ FLASH_IMAGES	0x08050000		128 KB
▼ .flash_images	0x08050000	0x08050000	117.19 KB
image2	0x080561a8	0x080561a8	58.59 KB
image3	0x08064c08	0x08064c08	34.18 KB
image1	0x08050000	0x08050000	24.41 KB
> RAM	0x20000000		96 KB
> FLASH_ICONS	0x08040000		64 KB
▼ FLASH_SOUND	0x08070000		60 KB
> .flash_sound	0x08070000	0x08070000	52.25 KB
> FLASH_D	0x0807f000		2 KB
> FLASH_V	0x0807f800		2 KB

2.4.2.2.5 Display the size information in byte format

The *Build Analyzer* view can display size information in different format according to the [Show Byte], [Show Hex] or [Show Human] selection. The icon in the *Build Analyzer* toolbar is used to switch between these formats. Prefer [Show Byte] or [Show Hex] when copying and pasting of data into an Excel® document for later calculations.

Figure 149. Show byte count

Name	Run address (VMA)	Load address (LMA)	Size
> RAM	0x20000000		98304
> FLASH_V	0x0807f800		2048
▼ FLASH_SOUND	0x08070000		61440
> .flash_sound	0x08070000	0x08070000	53500
▼ FLASH_IMAGES	0x08050000		131072
▼ .flash_images	0x08050000	0x08050000	120000
image3	0x08064c08	0x08064c08	35000
image2	0x080561a8	0x080561a8	60000
image1	0x08050000	0x08050000	25000
> FLASH_ICONS	0x08040000		65536
> FLASH_D	0x0807f000		2048
> FLASH	0x08000000		262144

Figure 150. Show hex count

Build Analyzer

NUCLEO-F401RE.elf - NUCLEO-F401RE/Debug - Oct 25, 2019 11:15:52 AM

Memory Regions Memory Details

Selection: 0x14c08

Search

Name	Run address (VMA)	Load address (LMA)	Size
> RAM	0x20000000		0x18000
> FLASH_V	0x0807f800		0x800
> FLASH_SOUND	0x08070000		0xf000
> .flash_sound	0x08070000	0x08070000	0xd0fc
> FLASH_IMAGES	0x08050000		0x20000
> .flash_images	0x08050000	0x08050000	0x1d4c0
image3	0x08064c08	0x08064c08	0x88b8
image2	0x080561a8	0x080561a8	0xea60
image1	0x08050000	0x08050000	0x61a8
> FLASH_ICONS	0x08040000		0x10000
> FLASH_D	0x0807f000		0x800
> FLASH	0x08000000		0x40000

Context Menu:

- Show Byte
- Show Hex
- Show Human

2.4.2.2.6 Copy and paste

The data in the *Memory Details* tab can be copied to other applications in CSV format by selecting the rows to copy and typing **Ctrl+C**. The copied data can be pasted into another application with the **Ctrl+V** command.

Figure 151. Copy and paste

Build Analyzer

NUCLEO-F401RE.elf - NUCLEO-F401RE/Debug - Oct 25, 2019 11:15:52 AM

Memory Regions Memory Details

Selection: 193500

Search

Name	Run address (VMA)	Load address (LMA)	Size
> RAM	0x20000000		98304
> FLASH_V	0x0807f800		2048
> FLASH_SOUND	0x08070000		61440
> .flash_sound	0x08070000	0x08070000	53500
sound4	0x0807afc8	0x0807afc8	8500
sound3	0x08079c40	0x08079c40	5000
sound2	0x08074e20	0x08074e20	20000
sound1	0x08070000	0x08070000	20000
> FLASH_IMAGES	0x08050000		131072
> .flash_images	0x08050000	0x08050000	120000
image3	0x08064c08	0x08064c08	35000
image2	0x080561a8	0x080561a8	60000
image1	0x08050000	0x08050000	25000
> FLASH_ICONS	0x08040000		65536
> .flash_icons	0x08040000	0x08040000	20000
icons	0x08040000	0x08040000	20000
> FLASH_D	0x0807f000		2048
> FLASH	0x08000000		262144

The **Ctrl+C** copy of the lines selected in [Figure 151](#) provides the **Ctrl+V** results below:

```
"sound4";"0x0807afc8";"0x0807afc8";"8500"
"sound3";"0x08079c40";"0x08079c40";"5000"
"sound2";"0x08074e20";"0x08074e20";"20000"
"sound1";"0x08070000";"0x08070000";"20000"
"image3";"0x08064c08";"0x08064c08";"35000"
"image2";"0x080561a8";"0x080561a8";"60000"
"image1";"0x08050000";"0x08050000";"25000"
"icons";"0x08040000";"0x08040000";"20000"
```

2.5 Build view setting

The build views require some setting. To apply manual refresh, follow the steps below:

1. Select the **[Window]>[Preferences]** menu.
2. Select the *Build Views settings* option of *STM32Cube* in the left pane.
3. Select **[On request]** for the *Build Views Refresh Mode* option as shown in [Figure 152](#).
4. Use the refresh button of the build view each time a refresh is required as illustrated in [Figure 153](#).


Once the refresh on request is selected for the build views, the values in the build views are updated only once the refresh button is pressed.

This setting applies to:

- The *Build Analyzer* view
- The *Static Stack Analyzer* view
- The *Cyclomatic Complexity* view


On the contrary, if the **[Auto]** option is selected for the refresh mode, the build values are automatically refreshed.

Figure 152. On request build view refresh mode



DT73562V1

Figure 153. Build view refresh button



2.6 Static Stack Analyzer

2.6.1 Introduction to the Static Stack Analyzer

The [STM32CubeIDE Static Stack Analyzer](#) calculates the stack usage based on the built program. It analyzes the `.su` files, generated by `gcc`, and the `elf` file in detail, and presents the resulting information in the view.

The view contains two tabs, the *List* and *Call Graph* tabs.

The *List* tab is populated with the stack usage for each function included in the program. The tab lists one line per function, each line consisting of the *Function*, *Local cost*, *Type*, *Location* and *Info* columns.

Figure 154. Static Stack Analyzer List tab

Function	Local cost	Type	Location	Info
main	88	STATIC	main.c:79	
TIM_TI1_SetConfig	16	STATIC	stm32f4xx_hal_tim.c:4540	
TIM_SlaveTimer_SetConfig	12	STATIC	stm32f4xx_hal_tim.c:4983	
TIM_CCxChannelCmd	8	STATIC	stm32f4xx_hal_tim.c:4739	
TIM_Base_SetConfig	0	STATIC	stm32f4xx_hal_tim.c:4481	
SystemInit	0	STATIC	system_stm32f4xx.c:148	
HAL_TIM_TriggerCallback	0	STATIC	stm32f4xx_hal_tim.c:4364	
HAL_TIM_SlaveConfigSync...	16	STATIC	stm32f4xx_hal_tim.c:4143	
HAL_TIM_ReadCapturedVal...	0	STATIC	stm32f4xx_hal_tim.c:4217	
HAL_TIM_PeriodElapsedCal...	0	STATIC	stm32f4xx_hal_tim.c:4304	
HAL_TIM_PWM_PulseFinish...	0	STATIC	stm32f4xx_hal_tim.c:4349	
HAL_TIM_OC_DelayElapsed...	0	STATIC	stm32f4xx_hal_tim.c:4319	
HAL_TIM_IRQHandler	8	STATIC	stm32f4xx_hal_tim.c:2809	
HAL_TIM_IC_Start_IT	8	STATIC	stm32f4xx_hal_tim.c:1672	

The *Call Graph* tab contains an expandable list with functions included in the program. Lines representing functions calling other functions can be expanded to see the call hierarchy.


Figure 155. Static Stack Analyzer Call Graph tab

Function	Depth	Max cost	Local cost	Type	Location	Info
main						
UsageFault_Handler	?	?	0	STATIC	stm32f4xx_it.c:116	Max cost uncertain. Recursive
ADC_IRQHandler	?	?	0	STATIC	stm32f4xx_it.c:103	Max cost uncertain. Recursive. No stack usage information available for this ...
BusFault_Handler	?	?	0	STATIC	stm32f4xx_it.c:77	Max cost uncertain. Recursive
HardFault_Handler	?	?	0	STATIC	stm32f4xx_it.c:90	Max cost uncertain. Recursive
MemManage_Handler	?	?	0	STATIC	stm32f4xx_it.c:147	Max cost uncertain. Recursive
Reset_Handler	7	184	0			Max cost uncertain. No stack usage information available for this function
TIM4_IRQHandler	3	8	0	STATIC	stm32f4xx_it.c:173	Max cost uncertain
NMI_Handler	0	0	0	STATIC	stm32f4xx_it.c:68	
PendSV_Handler	0	0	0	STATIC	stm32f4xx_it.c:129	
frame_dummy	0	0	0			Max cost uncertain. No stack usage information available for this function
SysTick_Handler	1	0	0	STATIC	stm32f4xx_it.c:156	
SVC_Handler	0	0	0	STATIC	stm32f4xx_it.c:129	
DebugMon_Handler	0	0	0	STATIC	stm32f4xx_it.c:138	
_do_global_dtors_aux	0	0	0			Max cost uncertain. No stack usage information available for this function
_fini	0	0	0			Max cost uncertain. No stack usage information available for this function

2.6.2 Using the Static Stack Analyzer

The *Static Stack Analyzer* view is by default open in the C/C++ perspective. If the view is closed, it can be opened from the menu. Select the menu command **[Window]>[Show View]>[Static Stack Analyzer]**. Another way to open the *Static Stack Analyzer* view is to type “Static Stack Analyzer” in the **[Quick Access search bar]** and select it from the views.

Figure 156. Open the Static Stack Analyzer view



The *Static Stack Analyzer* view is populated when a built project is selected in the *Project Explorer*. The project must be built with option **[Generate per function stack usage information]** enabled, otherwise the view cannot present any stack information.


How to setup the compiler to generate stack usage information is explained in the next section.

2.6.2.1 Enable stack usage information

If the top of the view displays the message **No stack usage information found, please enable in the compiler settings**, the build configuration must be updated for the compiler to generate stack information:

1. Open the project properties, for instance with a right-click on the project in the *Project Explorer* view
2. Select *Properties* and, in the dialog, select **[C/C++ Build]>[Settings]**
3. Select the *Tool Settings* tab
4. Select **[MCU GCC Compiler]>[Miscellaneous]**
5. Select **[Enable stack usage information (-fstack-usage)]** as shown in Figure 157
6. Save the setting and rebuild the program

Figure 157. Enable generate per function stack usage information



2.6.2.2


List tab

The **List** tab contains a list of all functions included in the selected program with options to **[Hide dead code]** functions and **[Filter]** visible functions.

Use the **[Hide dead code]** selection to enable or disable the listing of dead code functions.

If used, the **[Filter]** field restricts the display to functions matching the characters it contains.

Figure 158. Static Stack Analyzer List tab



The column information in the *List* tab is described in Table 9.

Table 9. Static Stack Analyzer List tab details

Name	Description
Function	Function name.
Local cost	The number displays how many bytes of stack the function uses.
Type	Tells if the function uses a STATIC or DYNAMIC stack allocation. When DYNAMIC allocation is used the actual stack size is run-time dependent and the the <i>Local cost</i> value is uncertain due to the dynamic size of stack.
Location	Indicates where the function is declared. It is possible to double-click on a line and open the file with the defined function in the editor.
Info	Additional information about the calculation.

The *List* tab sort order can be changed by clicking on a column name.

Note: By double-clicking on a line that displays the file location and line number in the *List* tab, the function is opened in the Editor view.

2.6.2.3 Call Graph tab

The *Call Graph* tab contains detailed program information in a tree view. Each function included in the program but not called by any other function is presented at the top level. It is possible to expand the tree to see called functions. Only functions available in the `elf` file can be visible in the tab.

When used, the [Search...] button triggers the display of the functions matching the characters in the search field. The search can be made case sensitive or not depending on the selection in checkbox [Case sensitive].

Figure 159. Static Stack Analyzer Call Graph tab

Function	Depth	Max cost	Local cost	Type	Location	Info
ADC_IRQHandler	?	?	0			Max cost uncertain. Recursive. No stack usage information available for this...
Reset_Handler	16	248	0			Max cost uncertain. No stack usage information available for this function
__write	3	48	0			Max cost uncertain. No stack usage information available for this function
__read	2	32	0			Max cost uncertain. No stack usage information available for this function
__seek	2	24	0			Max cost uncertain. No stack usage information available for this function
__close	2	16	0			Max cost uncertain. No stack usage information available for this function
SysTick_Handler	1	12	8	STATIC	stm32f4xx_it.c:182	
NMI_Handler	0	4	4	STATIC	stm32f4xx_it.c:70	
DebugMon_Handler	0	4	4	STATIC	stm32f4xx_it.c:156	
MemManage_Handler	0	4	4	STATIC	stm32f4xx_it.c:98	
UsageFault_Handler	0	4	4	STATIC	stm32f4xx_it.c:128	
PendSV_Handler	0	4	4	STATIC	stm32f4xx_it.c:169	
BusFault_Handler	0	4	4	STATIC	stm32f4xx_it.c:113	
HardFault_Handler	0	4	4	STATIC	stm32f4xx_it.c:83	
SVC_Handler	0	4	4	STATIC	stm32f4xx_it.c:143	
frame_dummy	0	0	0			Max cost uncertain. No stack usage information available for this function

The column information in the *Call Graph* tab is described in Table 10.

Table 10. Static Stack Analyzer Call Graph tab details

Name	Description
Function	Function name.
Depth	Specifies the call stack depth this function uses: <ul style="list-style-type: none"> 0: the function does not call any other functions Number ≥ 1: the function calls other functions ?: the function makes recursive calls or the depth cannot be calculated
Max cost	Specifies how many bytes of stack the function uses including stack needed for called functions.
Local cost	Specifies how many bytes of stack the function uses. This column does not take into account any stack that may be needed by the functions it may call.
Type	Specifies if the function uses a STATIC or DYNAMIC stack allocation. <ul style="list-style-type: none"> STATIC: the function uses a fixed stack DYNAMIC: the function uses a run-time dependent stack Empty field: no stack usage information available for the function
Location	Indicates where the function is declared. It is possible to double-click on a line and open the file with the defined function in the editor.
Info	Contains specific information about the stack usage calculation. For instance, it can hold a combination of the following messages: <ul style="list-style-type: none"> Max cost uncertain: the reason can be that the function makes a call to some sub-function where the stack information is not known, the function makes recursive calls, or others Recursive: the function makes recursive calls No stack usage information available for this function: no stack usage information available for this function Local cost uncertain due to dynamic size, verify at run-time: the function allocates stack dynamically, for instance depending on a parameter

The *Call Graph* tab sort order can be changed by clicking on a column name.

By double-clicking on a line that displays the file location and line number in the tab, the function is opened in the *Editor* view.

Note: The *main* function is usually called by the *Reset_Handler* and can in those cases be seen when expanding the *Reset_Handler* node.

If unused functions are listed in the tab, check if linker option **[dead code removal]** is enabled to remove unused code from the program. Read more on this in [Section 2.2.1.2: Discard unused sections](#).

The small icon left of the function name in column *Function* column indicates the following:

- Green dot: the function uses STATIC stack allocation (fixed stack).
- Blue square: the function uses DYNAMIC stack allocation (run-time dependent).
- 010 icon: used if the stack information is not known. This can be the case for library functions or assembler functions.
- Three arrows in a circle: used in the *Call Graph* tab when the function makes recursive calls.

Figure 160. Function symbols in Static Stack Analyzer

Function	Depth
ADC_IRQHandler	?
Reset_Handler	16
LoopCopyDataInit	15
LoopFillZeroBss	14
main	13
SystemClock_Config	5
MX_USART2_UART_Init	4
MX_GPIO_Init	1
SystemCoreClockUpdate	0
iprintf	12
readTemp	0
readSpeed	0
writeSpeed	0
writeTemp	0
SystemInit	0
FillZeroBss	0

2.6.2.4 Using the filter and search field

The *List* and *Call Graph* tabs contain a filter/search field, which can be used to search a specific function or functions matching the characters entered in the field.

Figure 161 displays the *List* tab where the [Filter] field is used to seek functions containing the “read” string in their name.

Figure 161. Static Stack Analyzer List tab using search





Figure 162 shows a use example of the [Search...] field in the *Call Graph* tab for filtering functions with name matching the “read” string.

Figure 162. Static Stack Analyzer Call Graph using search




2.6.2.5

Copy and paste

The data in the *List* tab can be copied to other applications in CSV format by selecting the rows to copy and typing **Ctrl+C**. The copied data can be pasted into another application with the **Ctrl+V** command.

Figure 163. Copy and paste



The **Ctrl+C** copy of the lines selected in Figure 163 provides the **Ctrl+V** results below:

```
"SystemClock_Config";"88";"STATIC";"main.c:410";""
"main";"40";"STATIC";"main.c:183";""
"HAL_GPIO_Init";"40";"STATIC";"stm32f4xx_hal_gpio.c:171";""
```

3 Debug

3.1 Basic debug functions

3.1.1 Introduction to debugging

STM32CubeIDE includes a powerful graphical debugger based on the GDB command-line debugger. It also bundles GDB servers for the ST-LINK and SEGGER J-Link JTAG probes.

The GDB server is a program that connects GDB on the PC to a target system. The STM32CubeIDE debug session can autostart a local GDB server or connect to a remote GDB server.

The remote GDB server can be running on the same PC, or on a PC that is accessible via the network and specified with *Host name* or *IP address* and a *Port number*. When connecting to a remote GDB server, this GDB server must be started first before a debug session is started in STM32CubeIDE.

When autostart local debugging is selected, STM32CubeIDE automatically starts and stops the GDB server as required during debugging, thus integrating the GDB server seamlessly.

Note: *It is recommended to use compiler optimization level `-O0` when building a project that must be debugged. Debugging with optimization level `-Og` may work but higher optimization level is hard to debug because of compiler code optimization.*

It is also possible to use the GDB server only to download the application into the target system and run it without starting a debug session. This is performed by creating run configurations, which is described later in this chapter (refer to [Section 3.1.7: Program and reset the device](#)).


STM32CubeIDE can be used to debug an existing `elf` file developed with another IDE or toolchain by importing the `elf` file using the import of STM32 Cortex[®]-M executable. This is described in [Section 3.1.9: Import STM32 Cortex[®]-M executable](#).

3.1.1.1

General debug and run launch flow

Debug configurations are used to debug an STM32 program. Run configurations are used to flash a new program into the STM32 and start it. The flowchart in Figure 164 presents the order of starting the GDB server, reset the device, load the program, set run time options, exceptions, program counter, breakpoints, Standby/Stop/Sleep, watchdog, and external loader initialization when starting a debug session. It also displays the differences between debug and run sessions.

Figure 164. General debug and run launch flowchart




DT67147V1

3.1.2

Debug configurations


A debug configuration for the project is needed before a debug session can be started. To create the first debug configuration for the project, right click on the project name in the *Project Explorer* view and select **[Debug As]>[STM32 C/C++ Application]**.

Figure 165. Debug as STM32 MCU



Another way to create a new debug configuration is to select the project name in the *Project Explorer* view and use the menu [Run]>[Debug As]>[STM32 C/C++ Application].

Figure 166. Debug as STM32 MCU menu



A third way to create a new debug configuration is to select a project name in the *Project Explorer* view and press [F11].

All three different ways open the *Debug Configuration* dialog.

3.1.2.1 Debug configuration

The *Debug Configuration* dialog contains the following tabs:


- *Main*
- *Debugger*
- *Startup*
- *Source*
- *Common*

The *Debugger* and *Startup* tabs must be updated when creating a new debug configuration while the others do not require update.

3.1.2.2 Main tab

The *Main* tab contains the configuration of the C/C++ application to debug. Usually, when creating a debug configuration using the sequence described earlier in this chapter, there is no need to make any change in the *Main* tab. Make sure the correct `elf` file and project are selected.

Figure 167. Debug configuration main tab



Note: It is possible in the Main tab to define if a build must be made before the debug session is started.

3.1.2.3 Debugger tab

The *Debugger* tab configures how to start the GDB server and connect to it. It also defines which GDB server must be used if [Autostart local GDB server] is selected.

Figure 168. Debug configuration debugger tab

IDE Edit Configuration

Edit launch configuration properties

Name: NUCLEO-F401RE

Main Debugger Startup Source Common

GDB Connection Settings

☒ Autostart local GDB server Host name or IP address localhost

☐ Connect to remote GDB server Port number 61234

Debug probe ST-LINK (ST-LINK GDB server)

GDB Server Command Line Options

Show Command Line

Interface

☒ SWD ☐ JTAG

☐ ST-LINK S/N Scan

Frequency (kHz): Auto

Access port: 0 - Cortex-M4

Reset behaviour

Type: Connect under reset

Device settings

Debug in low power modes: Enable

Suspend watchdog counters while halted: Disable

Serial Wire Viewer (SWV)

☐ Enable

Core Clock (MHz): 16.0

☐ Limit SWO clock

Maximum SWO clock (kHz): auto detect

Port number: 61235

RTOS Kernel Awareness

☐ Enable RTOS Proxy

Driver settings

Driver: ThreadX

Port: cortex_m0

Port number: 60000

External loaders

Loader	Enabled	Initialize

Add... Edit... Remove

Misc

☒ Verify flash download

☒ Enable live expressions

☐ Log to file: C:\Users\...\STM32CubeIDE\workspace_1.12.0\NUCLEO-F401RE\Debug\st-li Browse...

☐ Shared ST-LINK

☐ Max halt timeout(s): 2

Revert Apply

OK Cancel


The [Port number] edit field contains the default value used by the GDB server selected in the field [Debug probe].

Field [Host name or IP address] must be set when [Connect to remote GDB server] is selected.

Field **[Debug probe]** selects the probe and GDB server to be used for debugging. When using an ST-LINK debug probe, the *ST-LINK GDB server* or *OpenOCD* can be used. When using a SEGGER J-LINK probe, use the *SEGGER J-LINK GDB server*.

Pressing the **[Show Command Line]** button opens the *GDB Server command line* dialog. The dialog displays how the GDB server is started according to the current **[GDB Server Command Line options]** settings.

Figure 169. GDB server command line dialog



Use the **[Copy & Close]** button to copy the current command line settings to the clipboard, for instance to start the GDB server manually in a command line window by pasting the command.

The **[GDB Server Command Line options]** selections are updated as a function of the **[Debug probe]** selected. Detailed information about these settings is available in [Section 3.1.4: Debug using different GDB servers and subsections](#).

Debug authentication

Several STM32 products support the Arm® TrustZone® technology, which partitions the system into secure and nonsecure regions. When the CPU is in the secure state, it is not possible to connect to the target through JTAG/SWD. TZEN/RDP regression is not possible and software developers must authenticate to handle the debug. STMicroelectronics provides the STM32 Trusted Package Creator tool with its graphical user interface to generate the authentication key and certificate or password. Refer to the section about certificate generation for debug authentication in the tool user manual [\[ST-18\]](#).

Note: *TrustZone is a registered trademark of Arm Limited (or its subsidiaries) in the US and/or elsewhere.*

The user must enable the debug authentication during the project creation to be able to use it afterwards. Once the key and the certificate are generated, the user must indicate their locations in the fields **[Key path]** and **[Certificate path]**, as shown in Figure 170. The user must also define the permission type in the field **[Permissions]**. If the device supports only debug authentication via password, the user must indicate the location of the field **[Password file]** as shown in Figure 171.

Figure 170. Debug configuration debugger tab (secure)





Figure 171. Debug configuration - Debugger tab (debug authentication with password file)



3.1.2.4

Startup tab

The *Startup* tab configures how to start a debug session.

Figure 172. Debug configuration startup tab

IDE Edit Configuration

Edit launch configuration properties

Name: NUCLEO-F401RE

Main Debugger Startup Source Common

Initialization Commands

Load Image and Symbols

File	Build	Download	Load symbols
Debug\NUCLEO-F401RE.elf [NUCLEO-F401RE]	See Main tab	✓ true	✓ true

Runtime Options

Start Address

☒ Default start address

☐ Set program counter (hex):

☐ Specify vector table (hex):

☒ Set breakpoint at: main

☒ Exception on divide by zero

☐ Exception on unaligned access

☒ Halt on exception

☒ Resume

Run Commands

Revert Apply

? OK Cancel

The **[Initialization Commands]** edit field can be updated with any kind of GDB or GDB server monitor commands if there is any special need to send some commands to the GDB server before load commands are sent. For instance, when using ST-LINK GDB server a `monitor flash mass_erase` command can be entered here if a flash memory erase is needed before load.

The **[Load Image and Symbols]** list box must contain the file(s) to debug. This list is associated with the following command buttons:

- **[Add...]**: Add new lines for files for download and/or load symbols
- **[Edit...]**: Edit the selected line
- **[Remove]**: Remove the selected line from the list
- **[Move up]**: Move the selected line upwards
- **[Move down]**: Move selected line downwards

The **[Runtime Options]** section contains checkboxes to set the start address and breakpoint, and enable exception handling and resume.

The start address can be selected as:

- **[Default start address]**: `$pc` is set to the start address found in the last loaded `elf` file
- **[Set program counter (hex)]**: `$pc` is set to the hex value specified in the edit field
- **[Specify vector table (hex)]**: `$pc` is updated with the value found in memory using specified address + offset of 4. This is similar to how `$pc` is set by a reset using vector table in a Cortex[®]-M device

The **[Set breakpoint at:]** checkbox is enabled by default and the edit field displays `main`. It means that, by default, a breakpoint is set at `main` when the program is debugged.

Three exception checkboxes, **[Exception on divide by zero]**, **[Exception on unaligned access]** and **[Halt on exception]**, are used to make it easier to find problems when debugging an application.


- **[Exception on divide by zero]** is enabled by default to make it easier to trap a divide-by-zero error when debugging
- **[Exception on unaligned access]** can be enabled to get exceptions if there are any unaligned accesses
- **[Halt on exception]** is enabled by default so that program execution halts when an exception error occurs during debugging. If an exception occurs, the *Fault Analyzer* view can be used to find the location of the problem

Note: *The application software needs to enable **Exception on divide by zero** and **Exception on unaligned access** if they must be issued also when running the application and not only during debugging. The CMSIS Cortex[®]-M header files contain defines to update the SCB Configuration Control Register. For instance, `core_cm4.h` contains the `SCB->CCR` register, and `SCB_CCR_DIV_0_TRP` and `SCB_CCR_UNALIGN_TRP` defines.*

When the **[Resume]** selection is enabled, a `continue` command is issued to GDB after load to start the program. Usually, in this case, the program breaks at `main` if a breakpoint at `main` is set. Otherwise, when the **[Resume]** selection is disabled, the program stays at the `ENTRY` location specified in the linker script, normally the `Reset_Handler` function. A step may be needed in this case to display the `Reset_Handler` function in the editor.

When a line in the listbox is selected and **[Edit...]** is pressed, the following dialog appears for selecting if the file must be downloaded and if symbols must be loaded.

Figure 173. Add/Edit item




3.1.3 Manage debug configurations

Each project can have several debug configurations. It is easy to create a copy of an existing debug configuration and update it with some changes. For instance, one configuration may contain flash memory loading of new programs while another does not load any program.

When opening debug configurations from the menu [Run]>[Debug Configurations...], the *Debug Configurations* dialog opens. This dialog contains a navigation window on the left side with a toolbar, and the debug configuration on the right side with the tabs and fields described in Section 3.1.2: Debug configurations.


Figure 174. Manage debug configurations



The [Name] field on top of the right pane can be edited using a name for the debug configuration, which reflects the configuration. This name then appears in the navigation window under the [STM32 C/C++ Application] node to the left when pressing [Apply].

The toolbar left of the navigation window contains icons to manage configurations, for instance to duplicate or delete a selected configuration.

Figure 175. Manage debug configurations toolbar



These icons are used for the following purpose, from left to right:

- Create new launch configuration
- New launch of configuration prototype
- Export launch configuration
- Duplicate currently selected launch configuration
- Delete selected launch configuration(s)
- Collapse all expanded launch configurations
- Filter launch configurations

3.1.4 Debug using different GDB servers

STM32CubeIDE includes the following GDB servers:

- ST-LINK GDB server
- OpenOCD GDB server
- SEGGER J-Link GDB server


All three GDB servers support normal debug, live expressions and SWV.

All GDB servers also support RTOS Kernel Awareness debugging for Microsoft® Azure® RTOS ThreadX and FreeRTOS™ operating systems using an RTOS proxy. The RTOS proxy is included in STM32CubeIDE.

Different command-line options are used when starting these GDB servers. Therefore the *Debugger* tab in the *Debug Configurations* dialog displays different settings depending on the GDB server selected. This section describes the individual settings for each server.

3.1.4.1 Debug using the ST-LINK GDB server

Usually, when the ST-LINK GDB server is used for debugging, there is no need to update the [GDB Server Command Line Options] in the *Debugger* tab. In some cases, the default configuration must be updated, for instance if SWV is used or if several STM32 boards are connected to the PC.

Figure 176. ST-LINK GDB server debugger tab


Select **[SWD]** or **[JTAG]** in **[Interface]** to define how the ST-LINK probe must connect with the microcontroller. The SWD interface is usually the preferred choice. It must be selected if SWV is to be used.

When **[ST-LINK S/N]** is enabled, the serial number of the ST-LINK probe to be used must be entered in the edit/list field. The **[Scan]** button can be used to scan and list all detected ST-LINK devices connected to the PC. After a scan, the S/N of these ST-LINK devices are listed in the list box from which the desired ST-LINK can be selected. When **[Use specific ST-LINK S/N]** is enabled, the ST-LINK GDB server is started and connects only to the ST-LINK with the selected S/N.

The **[Frequency (kHz)]** selection defines the communication speed between the ST-LINK and STM32 device. When **[Auto]** is selected, the maximum speed provided by ST-LINK is used. Reduce the frequency in case of hardware limitations.

The **[Access port]** selection is used only when debugging a multi-core STM32 device. In such case, the ST-LINK is connected to the device and the ST-LINK GDB server must be informed of the core to debug.

The **[Reset behaviour]** contains selections for **[Type]** and **[Halt all cores]**. The **[Halt all cores]** selection is only visible for multi-core devices.

The **[Type]** can be set as follows:

- **[Connect under reset]** (default): ST-LINK reset line is activated and ST-LINK connects in the SWD or JTAG mode while reset is active. Then the reset line is deactivated.
- **[Software system reset]**: System reset is activated by software writing in a register. This resets the core and peripherals, and can reset the whole system as the reset pin of the target is asserted by itself.
- **[Hardware reset]**: ST-LINK reset line is activated and deactivated (pulse on reset line), then ST-LINK connects in the SWD or JTAG mode.
- **[Core reset]**: Core reset is activated by software writing in a register (not possible on Cortex[®]-M0, Cortex[®]-M0+, and Cortex[®]-M33 cores). This only resets the core, not the peripherals or the reset pin.
- **[None]**: For attachment to a running target where the program is downloaded into the device already. There must not be any file program command in the *Startup* tab.

Note:

The selected reset behavior is overridden if the debug configuration includes flash memory programming, in which case the ST-LINK GDB server uses the STM32CubeProgrammer (STM32CubeProg) command-line program STM32_Programmer_CLI to program the flash memory. This program is always started by the ST-LINK GDB server with mode=UR reset=hwRst so that a device reset is done when loading a new program, disregarding the selection of the [None] option. This ensures that device programming is made correctly.

[Halt all cores] can be used only when debugging multi-core devices. The **[Halt all cores]** selection is not visible for single-core devices.

[Device settings] contains selections for **[Debug in low power modes]** and **[Suspend watchdog counters while halted]**. These can be defined as:

- **[No configuration]**
- **[Enable]**
- **[Disable]**

The **[Serial Wire Viewer (SWV)]** selections can be used only when the **[SWD]** interface is selected. When **[SWV]** is enabled, it is required to configure the **[Clock Settings]**. The **[Core Clock]** must be set to the device speed. More information about SWV configuration is available in [Section 3.2.2.1: SWV debug configuration](#).

The **[RTOS Kernel Awareness]** selections are used to enable RTOS-kernel-aware debugging with the ThreadX and FreeRTOS[™] operating systems. When RTOS-kernel-aware debugging is enabled and a debug session is started, all threads are listed in the *Debug* view. By selecting a thread in the *Debug* view the current line executed by the thread is displayed in the editor. More information about RTOS-kernel-aware debugging is available in [Section 3.4.3](#).

The **[Misc]** selections contain:


- The **[External Loaders]** selections can be used to add one or more external loaders to extend the memory programming capabilities and cover non-internal STM32 memories.
The **[Add]** button allows the selection of both built-in STM32CubeProgrammer external loader files and custom external loaders available on the disk or in the workspace.
When the **[Initialize]** property of an external loader is enabled, the loaders `Init()` function is automatically called after reset operations. It can be used to configure the device for external memory access. Usually, the debugged application must perform the initialization.
- **[Verify flash download]**
- **[Enable live expressions]** (To be able to use the *Live Expressions* view during debugging, the live expression mechanism must be enabled during startup. It is enabled by default.)
- **[Log to file]** (Enable in case of debugging problems. It starts the ST-LINK GDB server with a higher log level and saves the log into a file.)
- **[Shared ST-LINK]** (Shared ST-LINK must be enabled if other programs must be able to connect to the same ST-LINK during a debug session.). Refer to [Section 3.1.6.2: Shared ST-LINK](#) for details.
A detailed description of the ST-LINK GDB server is available in the ST-LINK GDB server manual ([ST-07]), which is available from the *Information Center*.

Note: *STM32_Programmer_CLI is used by the ST-LINK GDB server to program the STM32 or external flash memory. In this case, such external flash memory programming is automatically done using the external loader.*

3.1.4.2 Debug using OpenOCD and ST-LINK

When OpenOCD is used, the **[GDB Server Command Line Options]** in the *Debugger* tab contains a generator options toggle field, which alternates between **[Show generator options...]** and **[Hide generator options...]**. When the field is set to **[Hide generator options...]**, the dialog displays additional **[GDB Server Command Line Options]** as shown in [Figure 177](#).

Figure 177. OpenOCD debugger tab



The **[OpenOCD Command]** edit field contains the `openocd.exe` file to be used when debugging. The **[Browse]** button can be used to select another version of OpenOCD.

The **[OpenOCD Options]** edit field can be used to add additional command-line parameters to be used when starting OpenOCD.

The **[Configuration Script]** selections can be **[Automated Generation]** or **[User Defined]**. When **[Automated Generation]** is selected, an `openocd.cfg` file is created automatically based on the selections made in the *Debugger* tab. When **[User Defined]** is selected, the file must be specified in the **[Script File]** edit field.

The **[Interface]** selection **[Swd]** or **[Jtag]** selects how the ST-LINK probe must connect with the microcontroller. **[Swd]** is usually the preferred choice.

The **Frequency** selection configures the communication speed between the ST-LINK and STM32 device.

The **[Reset Mode]** selection contains:

- **[Connect under reset]** (default): ST-LINK reset line is activated and ST-LINK connects in the SWD or JTAG mode while reset is active. Then the reset line is deactivated.
- **[Hardware reset]**: ST-LINK reset line is activated and deactivated (pulse on reset line), then ST-LINK connects in the SWD or JTAG mode.
- **[Software system reset]**: System reset is activated by software writing in a register. This is resetting the core and peripherals, and can reset the whole system as the reset pin of the target is asserted by itself.
- **[Core reset]**: Core reset is activated by software writing in a register (not possible on Cortex®-M0, Cortex®-M0+ and Cortex®-M33 cores). This is only resetting the core, not the peripherals nor the reset pin.
- **[None]**: For attachment to a running target where the program is downloaded into the device already. There must not be any file program command in the *Startup* tab.

[Enable debug in low power modes] enables debug also with the STM32 device in low-power mode.

[Stop watchdog counters when halt] stops the watchdog when the debug session halts the STM32 device. Otherwise, a watchdog interrupt may be triggered.

The **[Serial Wire Viewer (SWV)]** selections can be used only when the **[SWD]** interface is selected. When **[SWV]** is enabled, it is required to configure the **[Clock Settings]**. The **[Core Clock]** must be set to the device speed. More information about SWV configuration is available in [Section 3.2.2.1: SWV debug configuration](#).


The **[RTOS Kernel Awareness]** selections are used to enable RTOS-kernel-aware debugging with the ThreadX and FreeRTOS™ operating systems. When RTOS-kernel-aware debugging is enabled and a debug session is started, all threads are listed in the *Debug* view. By selecting a thread in the *Debug* view the current line executed by the thread is displayed in the editor. More information about RTOS-kernel-aware debugging is available in [Section 3.4.3](#).

[Enable live expressions] must be enabled if the *Live Expressions* view is meant to be used during debugging.

[Shared ST-LINK] must be enabled if other programs have to connect to the same ST-LINK during a debug session. Refer to [Section 3.1.6.2: Shared ST-LINK](#) for details.

3.1.4.3 Debug using SEGGER J-Link

When **[SEGGER J-LINK]** is selected in the *Debugger* tab, the **[GDB Server Command Line Options]** corresponds to SEGGER J-Link GDB server.

Figure 178. SEGGER debugger tab


The **[Interface]** selection **[SWD]** or **[JTAG]** selects how the SEGGER J-Link probe must connect with the microcontroller. The **[SWD]** interface is usually the preferred choice; it is required if SWV is used.

The **[Initial Speed]** selection configures the communication speed used between SEGGER J-Link and the STM32 device.

When **[Use specific J-Link S/N]** is enabled, enter the S/N of the J-Link to be used when debugging in the edit/list field. When **[Use specific J-Link S/N]** is enabled, the SEGGER J-Link GDB server is started and connects only to the J-Link with the selected S/N.

The **Device** edit field is used if it contains an entry. This field can be used if there is a problem to start the SEGGER J-Link GDB server with the default device name used in **STM32CubeIDE**. In such case, enter the device name used by the SEGGER GDB server in the edit field.

The **[Reset strategy]** selection contains:

- **[Type 0: Normal]** - Default.
- **[None]** - Intended to be used for attaching to the running target. In this case, the program must already be downloaded into the device. There must not be any file program command in the *Startup* tab.

The **[JTAG Scan Chain]** selections can be used only when the **[JTAG]** interface is selected.

The **[Serial Wire Viewer (SWV)]** selections can be used only when the **[SWD]** interface is selected. When **[SWV]** is enabled, it is required to configure the **[Clock Settings]**. The **[Core Clock]** must be set to the device speed. More information about SWV configuration is available in [Section 3.2.2.1: SWV debug configuration](#).

The **[RTOS Kernel Awareness]** selections are used to enable RTOS-kernel-aware debugging with the ThreadX and FreeRTOS™ operating systems. When RTOS-kernel-aware debugging is enabled and a debug session is started, all threads are listed in the *Debug* view. By selecting a thread in the *Debug* view the current line executed by the thread is displayed in the editor. More information about RTOS-kernel-aware debugging is available in [Section 3.4.3](#).

The **[Misc]** selections contains:

- **[Use J-Link script file]**
- **[Enable live expressions]**
To be able to use the *Live Expressions* view during debug, the live expression mechanism must be enabled during startup.
- **[Verify flash download]**
- **[Select RTOS variant]** list box can be used if **[Thread-aware RTOS support]** is used with **[FreeRTOS]** and **[embOS]**.
When **[Thread-aware RTOS support]** is used, update the *Startup* tab: disable **[Resume]** and **[in Run Commands]**, add `thread 2` and `continue`. This forces a thread context switch before the `continue` command is sent.

Note: A detailed description of SEGGER J-Link GDB server is available in the SEGGER J-Link manual, which can be accessed from the “Information Center”.

3.1.5 Start and stop debugging

When a debug configuration is created for the project with the preferred JTAG probe, it is ready for debugging. In the following sections, the ST-LINK GDB server is used. However, the way to debug the STM32 project is quite independent of the choice among ST-LINK GDB server, OpenOCD or SEGGER J-Link.

Perform the following steps to prepare for debug:

1. Determine whether the board supports the JTAG debug, SWD debug, or both.
SWD-mode debug is usually the preferred choice.
2. Connect the JTAG cable between the JTAG probe and the target board.
When using STMicroelectronics STM32 Nucleo and Discovery boards, the ST-LINK is usually integrated on the board. Also, most STMicroelectronics STM32 Evaluation boards contain an embedded ST-LINK.
3. Connect the USB cable between the PC and the JTAG probe.
4. Make sure that the target board has a proper power supply attached.

Once the steps above are performed, a debug session can be started.


3.1.5.1 Start debugging

Open the *Debug Configurations* dialog with a right click on the project name in the *Project Explorer* view and select **[Debug As]>[Debug Configurations...]**.

It is also possible to open the dialog using the menu **[Run]>[Debug Configurations...]**.


This opens the *Debug Configurations* dialog.

Note: It is possible to select the project in the “Project Explorer” view and press **[F11]** to restart a debug session after it has been closed.

Figure 179. Debug configurations


Select in the left pane the debug configuration to use. Press the **[Debug]** button to start a debug session if all debug configurations have been made. The project is built if file updates are made, but the building depends on the debug configuration.

STM32CubeIDE launches the debugger and the following dialog is opened.


Figure 180. Confirm perspective switch


It is recommended to enable **[Remember my decision]** and press **[Switch]**. It opens the *Debug* perspective, which provides a number of views and windows suitable for debugging.

3.1.5.2

Debug perspective and views

The *Debug* perspective contains menus, toolbars and views frequently used during debugging.

Figure 181. Debug perspective


The most important views opened by default in the *Debug* perspective are:

- The *Debug* view, which displays the program under debug. It also lists threads and offers the possibility to navigate in the thread by selecting a line in threads.
- The *Editor* view, which displays the program file. It is possible to set break points and follow program execution in the file. It is also possible to hover the cursor over a variable to display its current value. The features available during file edition are available also during debug, such as opening the declaration of a function and others.
- The *Variables* view, which displays local variables automatically with their current value when the program is not running.

- The *Breakpoints* view, which displays current breakpoints. It is possible to disable and enable breakpoints in the list. The *Breakpoints* view also contains a toolbar, which, for instance, enables to remove breakpoints, and skip breakpoints with one click on the **[Skip All Breakpoints]** icon.
- The *Expressions* view, which is used to add and view expressions. An expression may be a single global variable, structure, or an expression calculating some variables. The values are only updated when the program is stopped. It is possible to select a global variable in the *Editor* and drag it over to the *Expressions* view instead of entering the variable name.
- The *Registers* view, which displays the debugged device current values. The values are only updated when the program is stopped.
- The *Live Expressions* view, which displays expression values sampled and updated regularly during program execution. The view allows the creation of mathematical expressions that are evaluated automatically, such as `(Index*4+Offset)`. The *Live Expressions* view update requires that live expressions are enabled in the debug configuration. Refer to [Section 3.1.6.1: Live Expressions view](#) for details.
- The *SFRs* view, which displays the Special Function Registers in the debugged device. Refer to [Section 3.3: Special Function Registers \(SFRs\)](#) for details.
- The *Console* view, which displays different console outputs. By default, the console output from the GDB server log is displayed. It is possible to change the console log by pressing the **[Display Selected Console]** icon to the right of the *Console* view.

Other views are also useful during debug, among which:

- The *Debugger Console* view, which can be used if there is a need to manually enter GDB commands. The easiest way to open the *Debugger Console* view is to use the **[Quick Access]** field and enter `Debugger` in this field. It lists choices containing the *Debugger Console* view. Select it to open the view. GDB can be entered in the *Debugger Console* view.

For instance, to display 16 words of memory from address `0x800 0000`, enter the GDB command `x /16 0x8000000`.


```
x /16 0x8000000
0x8000000: 0x20018000 0x080008b1 0x080007e9 0x080007f7
0x8000010: 0x080007fd 0x08000803 0x08000809 0x00000000
0x8000020: 0x00000000 0x00000000 0x00000000 0x0800080f
0x8000030: 0x0800081d 0x00000000 0x0800082b 0x08000839
```

- The *Memory* and *Memory Browser* views, which can be used to display and update memory data.
- The *Disassembly* view, which is used to view and step in the assembly code.
- The *SWV* views. Refer to [Section 3.2: Debug with Serial Wire Viewer tracing \(SWV\)](#) for details.
- The *Fault Analyzer* view. Refer to [Section 3.5: Fault Analyzer](#) for details.

3.1.5.3 Main controls for debugging

The **[Run]** menu in the *Debug* perspective contains a number of execution control functions.

Figure 182. [Run] menu



Alternatively, the *Debug* perspective toolbar has the following main debug control icons.

Figure 183. Debug toolbar



These icons are used for the following purpose, from left to right:

- Reset the device and restart the debug session
- Skip all breakpoints (**Ctrl+Alt+B**)
- Terminate and relaunch
- Resume (**F8**)
- Suspend
- Terminate (**Ctrl+F2**)
- Disconnect
- Step into (**F5**)
- Step over (**F6**)
- Step return (**F7**)
- Instruction stepping mode (assembler stepping)

Press **[Terminate and relaunch]** to terminate the current debug session, build a new program if the source code is modified, and relaunch the debug session.

When pressing **[Instruction stepping mode]**, the *Disassembly* view is opened and further stepping uses assembler instruction stepping level. Press **[Instruction stepping mode]** again to toggle back to C/C++ level stepping.

3.1.5.4 Run, start, and stop a program

Use the toolbar icons as follows to run, step, or stop the program:

- Run the program with the **[Resume]** toolbar icon (**[F8]**)
- Step into a function with the **[Step into]** toolbar icon (**[F5]**)
- Step over a function with the **[Step over]** toolbar icon (**[F6]**)
- Step until return from a function with the **[Step return]** toolbar icon (**[F7]**)
- Abort running program with the **[Suspend]** toolbar icon


3.1.5.5 Set breakpoints

It is common during a debug session to set breakpoints and let the code execute until it reaches a breakpoint.

3.1.5.5.1 Standard breakpoint

A standard code breakpoint at a source code line can easily be inserted by double-clicking in the left editor margin, or by right-clicking in the left margin of the C/C++ source code editor. A context menu is proposed in the latter case.

Figure 184. Debug breakpoint




Select the **[Toggle Breakpoint]** menu command to set or remove a breakpoint at the corresponding source code line.

3.1.5.5.2 Conditional breakpoint

When setting a standard breakpoint at a source code line, the program breaks each time it reaches this line. If that is not the desired behaviour, a condition can be set on the breakpoint that regulates if the program should actually break or not on that breakpoint.


Update breakpoint properties with a right-click on the breakpoint icon visible left of the editor on a line with breakpoint set. The **[Breakpoint Properties]** can also be opened from the *Breakpoints* view.

Figure 185. Breakpoint properties



Select **[Breakpoint Properties...]**. The following window opens. In the example illustrated below, `i>20` is entered as a condition.

Figure 186. Conditional breakpoint



With the condition above set, the program breaks each time the line is executed, then GDB tests the condition and restarts execution if the variable `i` is not greater than `20`. It takes some time for GDB to evaluate the condition.

The conditions are written in C-style. It is therefore possible to write expressions such as `i%2==0` to set more complex conditions.

3.1.5.6 Restart or terminate debugging

This section presents various ways to restart and stop a debug session.

3.1.5.6.1 Restart


During debugging, it is sometimes needed to restart the program to examine more carefully problems observed during debug. In such case, restart the program using the **[Reset the chip and restart debug session]** toolbar button or **[Run]>[Restart]** menu command. This resets the device, and starts the program if **[Resume]** is enabled in the debug configuration.

Note: To make restart work, the interrupt vector must be configured and used with the hardware reset. This is usually the case for STM32 programs located in the flash memory. However, if the program is located elsewhere such as in RAM, some manual handling may be needed to make the program start from the expected `Reset_Handler`.

3.1.5.6.2 Restart configurations


It is possible to create restart configurations defining how the reset and restart of a debug session must be performed. Click on the arrow to the right of the **[Reset the chip and restart debug session]** toolbar icon.

Figure 187. Reset the chip toolbar




This expands the menu with the **[Restart Configurations...]** selection.

Figure 188. Restart configurations selection



When **[Restart Configurations...]** is selected, the restart configurations dialog opens.

Figure 189. Restart configurations dialog




The dialog contains a left and right pane:

- The left pane is used to select and create new restart configuration, duplicate an existing restart configuration, and delete the selected restart configuration. The default restart configurations cannot be deleted.
- The right pane is used to set **[Name]** and select the **[Type]** of reset to be used for the selected configuration. It is also possible to add additional commands to be used with the reset.

Press **[Apply]** to save a setting.


Figure 190 shows a setting where a new restart configuration is created, which contains an additional command to set pc to 0x8000ca0.

Figure 190. Restart configurations dialog with additional command



When several reset configurations are defined, they appear in the toolbar dropdown menu in order of use. Select the desired one to perform a reset.

Figure 191. Select restart configuration



3.1.5.6.3 Terminate

The most common way to stop a debug session is by clicking the **[Terminate]** toolbar button. It is also possible to stop the debug session with the **[Run]>[Terminate]** menu. When the debug session is stopped, STM32CubeIDE switches automatically to the C/C++ perspective.

3.1.5.6.4 Terminate and relaunch

Use the **[Terminate And Relaunch]** toolbar button if changes in the source code have been made during the debug session. Menu command **[Run]>[Terminate And Relaunch]** can also be used for this purpose. This stops the debug session, rebuild the program, and relaunches a debug session with the new program loaded.

3.1.6 Debug features

3.1.6.1 Live Expressions view

The *Live Expressions* view in STM32CubeIDE works very much like the *Expression* view with the exceptions that all the expressions are sampled live during debug execution. The number of expressions being sampled determines the sampling speed. An increased number of expressions being sampled results in a slower sample rate.


The view displays many different types of global variables. The view also allows users to create mathematical expressions that are evaluated automatically, such as $(i * 4 + \text{offset})$. The address column shows the memory addresses of the evaluated variables and expressions.

Figure 192. Live Expressions

Expression	Type	Value	Address
i	uint32_t	2	0x20000000
offset	uint32_t	8	0x20000004
$i * 4 + \text{offset}$	unsigned int	16	0x80000008
+ Add new expression			

The view can parse complicated data types and display complex data types like C-language structures. Only one format of numbers is used at the same time. To change this format, use the dropdown menu.

Figure 193. Live expressions number format (selection)



The variable values can be changed on the fly in the *Live Expressions* view while the program is running. Select the variable and change its value. It requires that only a single variable name is used in the expression, and that no calculation is involved. In Figure 194 for example, the variable `i` is selected and its value is changed from 2 to 4. Consequently, the result is also changed and highlighted in yellow. Note that any value that changes during a halt/run/halt cycle is highlighted in yellow.

Figure 194. Live expressions number format (example)

Expression	Type	Value	Address
<code>i</code>	<code>uint32_t</code>	4	0x20000000
<code>offset</code>	<code>uint32_t</code>	8	0x20000004
<code>i * 4 + offset</code>	<code>unsigned int</code>	24	0x80000008
+ Add new expression			

Note: To be able to use the *Live Expressions* view during debug, the live expression mechanism must be enabled during startup.

3.1.6.2 Shared ST-LINK

In the *Debugger* tab in *Debug Configurations* for ST-LINK GDB server and OpenOCD, a selection enables shared ST-LINK. When shared ST-LINK is enabled, the communication to ST-LINK goes via the ST-LINK server. The ST-LINK server makes it possible for several programs to access the same ST-LINK when shared ST-LINK is enabled.

STM32CubeProgrammer (STM32CubeProg) also contains a configuration for shared ST-LINK. This means that when shared ST-LINK is enabled in the debug configuration in STM32CubeIDE, it is possible to debug a program and let STM32CubeProgrammer access and read the device flash memory and RAM at the same time.

Enabling the shared mode causes STM32CubeIDE to launch the ST-LINK server, if it is not already running, with the default port 7184 for listening to the TCP connection. This default port is not editable from STM32CubeIDE.

3.1.6.3 Debug multiple boards

Debugging with multiple boards is possible using two ST-LINK or SEGGER J-Link probes at the same time. Connected to two different microcontrollers, both probes are connected to one PC on different USB ports. In this section, let us suppose that two different boards/microcontrollers are used: HW_A and HW_B.

It is possible to run one instance of STM32CubeIDE containing one project for HW_A and one project for HW_B.

The default port to be used is:

- 61234 for ST-LINK GDB server
- 3333 for OpenOCD
- 2331 SEGGER J-Link

This is presented in the *Debugger* tab in the *Debug Configurations* dialog. The port number must be changed for one of the projects to use another port, such as port 61244.

The debug configuration can use GDB connection selection [**Autostart local GDB server**]. Note that when debugging multiple boards, two or more debug probes are connected to the PC; the correct serial number must be selected for each debug configuration.

When the debug configurations has been configured for both projects so that each board is associated to a specific probe, it is time to test and debug each board individually first. When it is confirmed that this is working, the debug of both targets at the same time can be started as follow:

1. Start to debug HW_A.
2. The perspective switches automatically to the *Debug* perspective in STM32CubeIDE when a debug session for HW_A is started.
3. Switch to the C/C++ perspective.
4. Select the project for HW_B and start debugging it. The *Debug* perspective opens again.
5. There are two application stacks/nodes in the *Debug* view, one for each project. When changing the selected node in the *Debug* view, the related editor, variable view and others are updated to present information associated to the selected project.

It is also possible to start the GDB servers manually: select [**Connect to remote GDB server**] in the debug configuration. In such case, make sure that the GDB servers are started with parameters defining the individual ports and serial numbers to be used, and that the corresponding port numbers are used in the *Debug Configurations* dialog for each project.

Below is an example using SEGGER J-Link GDB server connecting to SEGGER J-Link, with port=2341 and S/N=123456789:

```
>JLinkGDBServerCL.exe -port 2341 -if SWD -select usb=123456789
```

Information on command-line parameters to be used when starting the GDB servers manually are provided in the GDB server manuals available from the *Information Center*.

3.1.6.4 **STM32H7 multicore debugging**

Information about how to use STM32H7 multicore devices in STM32CubeIDE is available in [ST-09].

3.1.6.5 **STM32MP1 debugging**

Information about how to use STM32MP1 devices in STM32CubeIDE is available in [ST-08].

Users are advised to keep updated with the documentation evolution of the STM32MP1 Series at www.st.com/en/microcontrollers-microprocessors/stm32mp1-series.


3.1.6.6 **STM32L5 debugging**

Information about how to use STM32L5 devices with Arm® TrustZone® in STM32CubeIDE is available in [ST-11].

3.1.6.7 Incremental flash memory programming

This feature allows users to program only the modified memory sectors. To activate it, select **[Incremental flash programming (experimental)]** in the debug configuration options.

Figure 195. Incremental flash memory programming




3.1.7 Program and reset the device

It is possible to create run configurations to download applications and reset the target without launching a full debug session. The *Run Configurations* dialog is similar to the *Debug Configurations* dialog, however disabled widgets in the lower part of the *Startup* tab are not performed. When running a run configuration, the specified program is flashed but, after the program counter is set, the program execution is started in the target and the "run" session in STM32CubeIDE is closed.

To create a run configuration for the project, right-click on the project name in the *Project Explorer* view and select **[Run As]>[STM32 C/C++ Application]**.

Another way to create a run configuration is to select the project name in the *Project Explorer* view and use the menu [Run]>[Run As]>[STM32 C/C++ Application].

Figure 196. Run configurations startup tab



3.1.8 Attach the debugger to the running target

It is possible to connect **STM32CubeIDE** and a debugger via JTAG/SWD to the embedded target without performing a reset. This approach is useful when trying to resolve problems that occur at rare occasions. Finding the root cause of the problem in case of a CPU crash is further simplified by learning how to use the *Fault Analyzer* view (refer to [Section 3.5: Fault Analyzer](#)).

Before trying this approach, consider whether halting the application in the wrong state could potentially harm the hardware (for instance in the case of a motor controller application). This is because when GDB connects to the target, the CPU is halted. This behaviour cannot be modified.

The following three or four steps are needed to update the debug configuration and to attach to running target:


1. Modify the debug configuration to attach to the running target
2. Connect the debug probe to the embedded target
3. Start a debug session using the modified debug configuration
4. Optionally, analyze the CPU fault condition with the *Fault Analyzer* tool (refer to [Fault Analyzer](#))

Step 1: Modify the debug configuration

The default generated debug configurations in STM32CubeIDE contains settings to reset the device and download new program, and sets a breakpoint at `main`. This is not of any use when connecting to a running system which may, or may not, have crashed.

In order to create a modified debug configuration, perform these steps:

1. Open the *Debug Configurations* dialog.
2. In the left frame of the *Debug Configurations* dialog, select the debug configuration associated to the project to debug and make a copy of this by right-clicking it and selecting **[Duplicate]**.
3. Give the duplicate debug configuration a name.
4. Update the *Debugger* tab in *Debug Configurations*:
 - When using ST-LINK GDB server and OpenOCD, select **[None]** as **[Reset behaviour]**.
 - When using SEGGER J-Link GDB server, select **[None]** as **[Reset strategy]**.
5. Change needed/recommended in the *Startup* tab of *Debug Configurations* for both ST-LINK GDB server and SEGGER J-Link GDB server:
 - Disable file **[Download]** in **[Load Image and Symbols]**.
 - Disable **[Set program counter at (hex)]**.
 - Disable **[Set breakpoint at]**.
 - **[Exception on divide by zero]** and **[Exception on unaligned access]** can be disabled or enabled.
 - Disable **[Resume]**.
If the **[Resume]** is enabled, the debugger stops the target during connection and, after a short period of time, sends a `continue` command.

Figure 197. Startup tab attach


Step 2: Connect ST-LINK or SEGGER J-Link to the embedded target

Connect first ST-LINK or the SEGGER J-link to the computer. Then connect it to the embedded target. No reset is issued.

Step 3: Start a debug session using the modified debug configuration


Important: Do not launch the debug session using the wrong debug configuration, which may reprogram and reset the target. Use [Run]>[Debug Configurations...], select the modified debug configuration in the left frame, and click [Debug]. This is the safest way to launch a debug session with full control of the debug configuration applied and prevents from a potential reset.

The debugger is now connected to the embedded target, which is automatically halted. At this point, different status registers and variables can be investigated in the application. If the CPU has crashed, the *Fault Analyzer* can be used to get a better understanding of the root causes.

3.1.9 Import STM32 Cortex®-M executable


Use menu [File]>[Import...] to open the *Import* dialog.

Figure 198. Cortex®-M executable import dialog



Select **[STM32 Cortex-M Executable]** and press **[Next >]**.


Figure 199. STM32 Cortex®-M executable dialog



Use the **[Browse...]** button and select the `elf` file to import. When the `elf` file is selected, the STM32 device must be selected manually so that STM32CubeIDE can be used for debugging.

Press **[Select...]** to open the *MCU/MPU Selector* dialog.


Figure 200. STM32 Cortex®-M executable MCU/MPU selection



Select the microcontroller or microprocessor to be used. The search field can be used to find the device. Press **[OK]** once the device is selected.

As a result, the CPU and core are presented in the dialog.

Figure 201. STM32 Cortex®-M CPU and core



IDE STM32 Cortex-M Executable

Select executable to debug and configure a matching STM32 device.

Executable: C:\dev\STM32F401_Nucleo_ExtBuilt.elf Browse...

STM32 device

MCU: STM32F401RETx Select...


CPU: Cortex-M4 (0) ▼

Core: 0 ▼

? < Back Next > Finish Cancel

Press **[Finish]** and the debug configuration dialog automatically opens.


Figure 202. Cortex®-M debug configuration for imported project



The debug configuration can then be set up in similar way as with any other STM32CubeIDE project. Once the configuration is completed, press **[Debug]** to start a debug session.

The imported project is displayed in the *Project Explorer* view.

Figure 203. Project explorer view with imported project



3.2 Debug with Serial Wire Viewer tracing (SWV)

3.2.1 Introduction to SWV and ITM

This section provides information on how to use Serial Wire Viewer tracing (SWV) in [STM32CubeIDE](#).

System analysis and real-time tracing in STM32 requires a number of interaction technologies: Serial Wire Viewer (SWV), Serial Wire Debug (SWD), Instrumentation Trace Macrocell (ITM) and Serial Wire Output (SWO). These technologies are part of the Arm® CoreSight™ debugger technology. They are explained below.

Serial Wire Debug (SWD) is a debug port similar to JTAG. It provides the same debug capabilities (run, stop on breakpoints, single-step) but with fewer pins. It replaces the JTAG connector with a 2-pin interface (one clock pin and one bi-directional data pin). The SWD port alone does not allow real-time tracing.

The Serial Wire Output (SWO) pin can be used in combination with SWD. It is used by the processor to emit real-time trace data, thus extending the two SWD pins with a third pin. The combination of the two SWD pins and SWO pin enables Serial Wire Viewer (SWV) real-time tracing in compatible Arm® processors.

Beware that, SWO being just one pin, it is easy to set a configuration that produces more data than the SWO is able to send.

The Serial Wire Viewer (SWV) is a real-time trace technology that uses the Serial Wire Debug (SWD) port and the Serial Wire Output (SWO) pin. The Serial Wire Viewer provides advanced system analysis and real-time tracing without the need to halt the processor to extract the debug information.

Serial Wire Viewer (SWV) provides the following types of target information:

- Event notification on data reading and writing
- Event notification on exception entry and exit
- Event counters
- Timestamp and CPU cycle information, which can be used for program statistical profiling

The Instrumentation Trace Macrocell (ITM) enables applications to write arbitrary data to the SWO pin, which can be interpreted and visualized in the debugger. For example, ITM can be used to redirect `printf()` output to a SWV console view in the debugger. The standard is to use port 0 for this purpose.

The ITM port has 32 channels. Writing different types of data to different ITM channels allows the debugger to interpret or visualize the data on various channels differently.

Writing a byte to the ITM port takes only one write cycle, thus taking almost no execution time from the application logic.

Based on SWV, and ITM trace data, STM32CubeIDE can provide advanced debugger capabilities with special SWV views.

Note: *Arm® does not include SWV/ITM in Cortex®-M0 or Cortex®-M0+ cores. Therefore, STM32 devices based on these cores, such as STM32L053 microcontrollers, do not support SWV/ITM.*

3.2.2 SWV debugging

To debug and use the Serial Wire Viewer (SWV) in STM32CubeIDE, the JTAG probe and the GDB server must support SWV. The board must also support SWD, and the SWO pin needs to be available and connected to the JTAG probe.

The following sections describe the process to create a debug configuration, SWV settings configuration, and how to use SWV tracing in a debug session.

3.2.2.1 SWV debug configuration

Step 1: Open the *Debug Configurations* dialog

Use for instance menu **[Run]>[Debug Configurations...]** and select the STM32 Cortex®-M debug configuration to update.

Step 2: Select the SWD interface

Select the **[SWD]** interface in the *Debug Configurations* dialog.

Step 3: Enable SWV

Enable **[SWV]** in the *Debug Configurations* dialog.


Step 4: Enter the core clock frequency

Enter the **[Core Clock]** frequency in the *Debug Configurations* dialog. This must correspond to the value set by the application program to be executed.

Usually, the core clock setting is stored in the `SystemCoreClock` variable when using projects imported from STM32 firmware examples or created with STM32CubeMX. One method to inspect the core clock value is to start a debug session and add the `SystemCoreClock` variable to the *Expressions* view. Make sure that the system core clock is configured by the application before reading the value.

If the `SystemCoreClock` is not updated, change the program and add a call to the function `SystemCoreClockUpdate()`. Rebuild the program, restart debugging and inspect the `SystemCoreClock` value again.


Figure 204. SWV core clock



Step 5: Enter the SWO clock frequency

The **[Serial Wire Viewer (SWV)]** selections in the *Debug Configurations* dialog can be used only when the **[SWD]** interface is selected. When **[SWV]** is enabled, it is required to configure the **[Clock Settings]**. The **[Core Clock]** must be set to the device speed. The SWO clock is automatically set to the highest possible speed depending on debug probe used and core clock. However, if the debugged hardware does not allow too-high SWO clock speed, it is possible to enable **[Limit SWO clock]** and enter the maximum SWO clock speed in kHz. The SWV **[Port number]** must be set to the port to be used for SWV data communication. The SWV port cannot be set equal to the GDB connection **[Port number]**.

Figure 205. SWV debug configuration



Step 6: Save the configuration

Press **[Apply]** in the *Debug Configurations* dialog to save the configuration.

Step 7: Start a debug session

Press **[Debug]** to start a debug session. Make sure that the probe and board are connected.

Step 8: Possibly suspend the target


[Suspend] the target if it has not stopped at a breakpoint.

Step 9: Open a SWV view

Open one of the SWV views. For first-time users, it is recommended to open the *SWV Trace log* view because it gives a good overview of incoming SWV packets and how well the tracing is working.

Select the **[Window]>[Show View]>[SWV]>[SWV Trace log]** menu command to open the *SWV Trace log* view.


Figure 206. SWV show view



Step 10: View the trace log

The *SWV Trace log* view is now visible.

Figure 207. SWV Trace log view



3.2.2.2 SWV settings configuration

Step 1: Open the *Serial Wire Viewer* settings

Click on the **[Configure Trace]** toolbar button in the *SWV Trace Log* view to open the *Serial Wire Viewer settings* dialog.

Figure 208. SWV [Configure Trace] toolbar button



Note: The [Configure Trace] toolbar button is available in all SWV views.

Step 2: Configure the trace data

Configure the data to be traced in the *Serial Wire Viewer settings* dialog.

For this example [PC Sampling] and [Timestamps] are enabled.

Figure 209. SWV settings dialog

The SWV settings dialog has the following configurations:

- **[Clock Settings]:** These fields are disabled and only present the values used and configured in the *Debug Configurations* for the debug session. If these values need to be changed, close the debug session and open the *Debug Configurations* to modify them.

- **[Trace Events]:** The following events can be traced.
 - **[CPI]:** Cycles per instruction. For each cycle beyond the first one that an instruction uses, an internal counter is increased with one. The counter (`DWT_CPI_count`) can count up to 256 and is then set to 0. Each time that happens, one of these packets are sent. This is one aspect of the processors performance and used to calculate instructions per seconds. The lower the value, the better the performance.
 - **[SLEEP]:** Sleep cycles. The number of cycles the CPU is in sleep mode. Counted in `DWT_Sleep_count` register. Each time the CPU has been in sleep mode for 256 cycles, one of these packets is sent. This is used when debugging for power consumption or waiting for external devices.
 - **[FOLD]:** Folded instructions. A counter for how many instructions are folded (removed). Every 256 instruction folded (taken zero cycles) will receive one of these events. Counted in `DWT_Fold_count` register.
 Branch folding is a technique where, on the prediction of most branches, the branch instruction is completely removed from the instruction stream presented to the execution pipeline. Branch folding can significantly improve the performance of branches, taking the CPI for branches below 1.
 - **[EXC]:** Exception overhead. The `DWT_Exception_count` register keeps track of the number of CPU cycles spent in exception overhead. This includes stack operations and returns but not the time spent processing the exception code. When the timer overflows, one of these events is sent. Used to calculate the actual exception handling cost to the program.
 - **[LSU]:** Load Store Unit Cycles. The `DWT_LSU_count` register counts the total number of cycles the processor is processing an LSU operation beyond the first cycle. When the timer overflows, one of these events is sent.
 With this measurement, it is possible to track the amount of time spent in memory operations.
 - **[EXETRC]:** Trace Exceptions. Whenever an exception occurs, exception entry, exception exit and exception return events are sent. These events can be monitored in the *SWV Exception Trace Log* view. From this view, it is possible to jump to the exception handler code for that exception.
- **[PC Sampling]:** Enabling this starts sampling the Program Counter at some cycle interval. Since the SWO pin has a limited bandwidth, it is not advised to sample too fast. Experiment with the **[Resolution]** (cycles/sample setting) to be able to sample often enough. The results from the sampling are used, among other things, for the *SWV Statistical Profiling* view.
- **[Timestamps]:** Must be enabled to know when an event occurred. The **[Prescaler]** should only be changed as a last effort to reduce overflow packets.
- **[Data Trace]:** It is possible to trace up to four different C variable symbols, or fixed numeric areas of the memory. To do that, enable one comparator and enter the name of the variable or the memory-address to trace. The value of the traced variables can be displayed both in the *Data Trace* and *Data Trace Timeline Graph* views.
- **[ITM Stimulus Ports]:** There are 32 ITM ports available, which can be used by the application. For instance, the CMSIS function `ITM_SendChar` can be used to send characters to port 0 (refer to [Section 3.2.3.5: SWV ITM Data Console and printf redirection](#)). The packets from the ITM ports are displayed in the *SWV ITM Data Console* view.

Note: *It is recommended to limit the amount of data traced. Most STM32 microcontrollers read and write data faster than the maximum SWO pin throughput. Too many trace data result in data overflow, lost packets and possibly corrupt data. For optimum performance, trace only data necessary to the task at hand.*

Overflow while running SWV is an indication that SWV is configured to trace more data than the SWO pin is able to process. In such a case, decrease the amount of data traced.

Enable **[Timestamps]** to use any of the timeline views in STM32CubeIDE. The default **[Prescaler]** is 1. Keep this value, unless problems occur related to SWV packet overflow.

Three examples are provided below for illustrating SWV trace configuration:

- **Example 1:** To trace the value of a global variable, enable **[Comparator]** and enter the name of the variable or the memory address to be traced.
 The value of the traced variable is displayed both in the *Data Trace* and *Data Trace Timeline Graph* views.
- **Example 2:** To profile program execution, enable **[PC sampling]**. In the beginning, a high value for the **[Cycles/sample]** is recommended.
 The result from the PC sampling is then displayed in the *SWV Statistical Profiling* view.
- **Example 3:** To trace the exceptions occurring during program execution, enable **[Trace Event EXETRC: Trace Exceptions]**.
 Information about the exceptions is then displayed in the *SWV Exception Trace Log* view.

Step 3: Save the SWV configuration

Click on the **[OK]** button to save the SWV configuration. The configuration is saved together with other debug configurations and remains effective until changed.

3.2.2.3

SWV tracing

Step 1: Start SWV trace recoding

Press the **[Start/Stop Trace]** toolbar button in one of the SWV views to send the SWV settings to the target board and start the SWV trace recoding. This toolbar button is available in all SWV views. The board does not send any SWV packet until it is properly configured. The SWV configuration must be resent if the configuration registers on the target board are reset. Actual tracing does not start until the target starts to execute.

Figure 210. SWV [Start/Stop Trace] toolbar button



Note: The tracing cannot be configured while the target is running. Pause the debugging before attempting to send a new configuration to the board. Each new or updated configuration must be sent to the board to take effect. The configuration is sent to the board when the **[Start/Stop Trace]** button is pressed.

Step 2: Start the target

Press the **[Resume]** toolbar button on top of the *Debug* perspective to start the target.

Step 3: SWV Trace Log view

SWV packets are displayed in the **SWV Trace Log** view.

Figure 211. SWV Trace Log PC sampling

Index	Type	Data	Cycles	Time(s)	Extra info
10362	PC Sample	0x8000508	169777034	2.021155 s	
10363	PC Sample	0x8000516	169793417	2.021350 s	
10364	PC Sample	0x8000528	169809800	2.021545 s	
10365	PC Sample	0x8000500	169826183	2.021740 s	
10366	PC Sample	0x8000510	169842566	2.021935 s	
10367	PC Sample	0x80004f2	169858949	2.022130 s	
10368	PC Sample	0x8000504	169875332	2.022325 s	
10369	PC Sample	0x8000516	169891715	2.022520 s	
10370	PC Sample	0x8000528	169908098	2.022715 s	

Overflow packets: 0

Step 4: Clear collected SWV data

When the target is not running, the collected SWV data can be cleared by pressing the **[Remove all collected SWV data]** toolbar button. This toolbar button is available in all SWV views.

Figure 212. [Remove all collected SWV data] toolbar button




3.2.3 SWV views

The SWV views that display SWV traces data are:

- **SWV Trace Log:** Lists all incoming SWV packets in a spreadsheet. Useful as a first diagnostic for the trace quality.
- **SWV Exception Trace Log:** The view has two tabs, one is similar to the *SWV Trace Log* view and the other tab displays statistical information about exception events.
- **SWV Data Trace:** Tracks up to four different symbols or areas in the memory.
- **SWV Data Trace Timeline Graph:** A graphical display that shows the distribution of variable values over time.
- **SWV ITM Data Console:** Prints readable text output from the target application. Typically this is done via `printf()` with output redirected to ITM channel 0.
- **SWV Statistical Profiling:** Displays statistics based on the Program Counter (PC) sampling. Shows the amount of execution time spent within various functions.

Figure 213. SWV views selectable from the menu



Note: *More than one SWV view may be open at the same time for the simultaneous tracking of various events.*
 The SWV views toolbars contain these usual control icons.

Figure 214. SVW views common toolbar



These icons are used for the following purpose, from left to right:

- Configure trace
- Start/Stop trace
- Remove all collected SWV data
- Scroll lock
- Minimize
- Maximize

The SWV graph views toolbars contain these extra control icons.

Figure 215. SVW graph views extra toolbar



These icons are used for the following purpose, from left to right:

- Save graph as image
- Switch between seconds and cycle scale
- Adjust the Y-axis to best fit
- Zoom in
- Zoom out

3.2.3.1

SWV Trace Log

The *SWV Trace Log* view lists all incoming SWV packets in a spreadsheet. The data in this view can be copied to other applications in CSV format by selecting the rows to copy and type **Ctrl+C**. The copied data can be pasted into another application with the **Ctrl+V** command.

Figure 216. SWV Trace Log PC sampling and exceptions

Index	Type	Data	Cycles	Time(s)	Extra info
25012	PC Sample	0x80004f6	258481871	3.077165 s	
25013	PC Sample	0x8000508	258498254	3.077360 s	
25014	PC Sample	0x8000518	258514637	3.077555 s	
25015	Exception entry	SYSTICK (EXC 15)	258522309	3.077647 s	
25016	Exception exit	SYSTICK (EXC 15)	258522367	3.077647 s	
25017	Exception return	N/A (EXC 0)	258522374	3.077647 s	
25018	PC Sample	0x80004fc	258531017	3.077750 s	
25019	PC Sample	0x800050e	258547400	3.077945 s	
25020	PC Sample	0x800051e	258563783	3.078140 s	
25021	PC Sample	0x80004fa	258580166	3.078335 s	

Overflow packets: 0

The column information in the *SWV Trace Log* view is described in Table 11.

Table 11. SWV Trace Log columns details

Name	Description
Index	The packet ID. Shared with the other SWV packets.
Type	The type of packet (example PC sample, data PC value (comp 1), exceptions, overflow).
Data	The packet data information.
Cycles	The timestamp of the packet in cycles.
Time(s)	The timestamp of the packet in seconds.
Extra info	Optional extra packet information.

3.2.3.2

SWV Exception Trace Log

The *SWV Exception Trace Log* view is composed of two tabs.

Data tab

The first tab is similar to the *SWV Trace Log* view, but is restricted to exception events. It also provides additional information about the type of event. The data can be copied and pasted into other applications. Each row is linked to the code for the corresponding exception handler. Double-click on the event to open the corresponding interrupt handler source code in the *Editor* view.

Note: *Enable [Trace Event EXETRC: Trace Exceptions] in the Serial Wire Viewer settings dialog to trace exceptions during program execution. Enable [Timestamps] to log cycle and time for each interrupt packet.*

Figure 217. SWV Exception Trace Log – Data tab

Index	Type	Name	Peripheral	Function	Cycles	Time(s)	Extra info
17629	Exception exit	SYSTICK (EXC 15)		SysTick_Handler()	58204401	692.909536 ms	
17630	Exception return	N/A (EXC 0)			58205926	692.927690 ms	Timestamp delayed. Packet delayed.
17636	Exception entry	SYSTICK (EXC 15)		SysTick_Handler()	58288335	693.908750 ms	
17637	Exception exit	SYSTICK (EXC 15)		SysTick_Handler()	58288393	693.909440 ms	
17638	Exception return	N/A (EXC 0)			58288400	693.909524 ms	
17644	Exception entry	SYSTICK (EXC 15)		SysTick_Handler()	58372327	694.908655 ms	
17645	Exception exit	SYSTICK (EXC 15)		SysTick_Handler()	58372385	694.909345 ms	
17646	Exception return	N/A (EXC 0)			58372392	694.909429 ms	

Overflow packets: 0

The column information in the *SWV Exception Trace Log – Data* tab is described in Table 12.

Table 12. SWV Exception Trace Log – Data columns details

Name	Description
Index	The exception packet ID. Shared with the other SWV packets.
Type	Each exception generates three packets: Exception entry, Exception exit and then an Exception return packet.
Name	The name of the exception. Also the exception or interrupt number.
Peripheral	The peripheral for the exception.
Function	The name of the interrupt handler function for this interrupt. Updated when debug is paused. Is cached during the whole debug session. By double clicking the function, the editor will open that function in the source code.
Cycles	The timestamp for the exception in cycles.
Time(s)	The timestamp for the exception in seconds.
Extra info	Optional extra information about that packet.

Statistics tab

The second tab displays statistical information about exception events. This information may be of great value when optimizing the code. Hypertext links to exception handler source code in the editor is included.

Figure 218. SWV Exception Trace Log – Statistics tab

Exception	Handler	% of	Number of	% of excepti...	% of debug time	Total runtime	Avg runtime	Fastest	Slowest	First	First (s)	Latest	Latest (s)
SYSTICK (EXC 15)	SysTick_Handler()	100.0000%	2172	100.0000%	0.0690%	40309	57	57	58	71567	851.988095 µs	58372327	694.908655 ms
Total for all			2172		0.0690%	40309	18						

Overflow packets: 0

The column information in the *SWV Exception Trace Log – Statistics* tab is described in [Table 13](#).

Table 13. SWV Exception Trace Log – Statistics columns details

Name	Description
Exception	The name of the exception provided by the manufacturer. Also the exception or interrupt number.
Handler	The name of the interrupt handler for this interrupt. Updated when debug is paused. Is cached during the whole debug session. By double clicking the handler, the editor will open that function in the source code.
% of	This exception type's share, in percentage, of all exceptions.
Number of	The total number of entry packets received by SWV of this exception type.
% of exception time	How big part of the execution time for all exceptions that this exception type have.
% of debug time	How big part of the total execution time for this debug session that this exception type have. All the timers are restarted when the Empty SWV-Data button is pressed.
Total runtime	The total execution time in cycles for this exception type.
Avg runtime	The average execution time in cycles for this exception type.
Fastest	The execution time in cycles for the fastest exception of this exception type.
Slowest	The execution time in cycles for the slowest exception of this exception type.
First	The first encounter of an entry event for this exception type in cycles.
First(s)	The first encounter of an entry event for this exception type in seconds.
Latest	The latest encounter of an entry event for this exception type in cycles.
Latest(s)	The latest encounter of an entry event for this exception type in seconds.

3.2.3.3

SWV Data Trace

The *SWV Data Trace* view tracks up to four different symbols or areas in the memory. For example, global variables can be referenced by name. The data can be traced on Read, Write and Read/Write.

Enable **[Data Trace]** in *Serial Wire Viewer settings*. In [Figure 219](#), two global variables `pos1` and `pos2` in the program are traced on **[Write]** access.

Figure 219. SWV Data Trace configuration

IDE Serial Wire Viewer settings for NUCLEO-F401RE Debug (ST-LINK)

Clock Settings
 Core Clock: 84 MHz
 Clock Prescaler: 42
 SWO Clock: 2000.0 kHz

Trace Events
☐ CPI: Cycles per instruction ☐ EXC: Exception overhead
☐ SLEEP: Sleep cycles ☐ LSU: Load store unit cycles
☐ FOLD: Folded instructions ☐ EXETRC: Trace Exceptions

PC Sampling
☒ Enable Resolution: 16384 Cycles/sample

Timestamps
☒ Enable Prescaler: 1

Data Trace


Comparator 0	Comparator 1	Comparator 2	Comparator 3
<input checked="" type="checkbox"/> Enable	<input checked="" type="checkbox"/> Enable	<input type="checkbox"/> Enable	<input type="checkbox"/> Enable
Var/Addr: pos1	Var/Addr: pos2	Var/Addr: 0x0	Var/Addr: 0x0
Access: Write	Access: Read	Access: Read/Write	Access: Read/Write
Size: Word	Size: Word	Size: Word	Size: Word
Generate: Data Value + PC	Generate: Data Value + PC	Generate: Data Value	Generate: Data Value

ITM Stimulus Ports
 Enable port: 31 ☐ 24 ☐ 23 ☐ 16 ☐ 15 ☐ 8 ☐ 7 ☐ 0 ☐
 Privileged only ports: ☐ Port 31..24 ☐ Port 23..16 ☐ Port 15..8 ☐ Port 7..0

OK Cancel

When running the program in debugger with SWV trace enabled the *SWV Data Trace* view displays this information when [Comparator 0] with `pos1` data is selected in the [Watch] list.

Figure 220. SWV Data Trace




The column information in the *SWV Data Trace* described in Table 14.

Table 14. SWV Data Trace columns details

Name	Description
Access	Read or Write access type.
Value	The value of data read or written.
PC	The PC location where read or write access occurs.
Cycles	The timestamp for the packet in cycles.
Time(s)	The timestamp for the packet in seconds.

3.2.3.4 SWV Data Trace Timeline Graph

The *SWV Data Trace Timeline Graph* view contains a graphical display that shows the distribution of variable values over time. It applies to the variables or memory areas in the SWV Data Trace. The following is displayed when using the timeline graph displaying global variables `pos1` and `pos2` counting up and down.

Figure 221. SWV Data Trace Timeline Graph


The *SWV Data Trace Timeline Graph* has the following features:

- The graph can be saved as a JPEG image file by clicking on the camera toolbar button.
- The graph shows the time in seconds by default but can be changed to cycles by clicking on the clock toolbar button.
- Y-axis can be adjusted to best fit by clicking on the y-axis toolbar button.
- Zoom in and out by clicking on the **[+]** and **[-]** toolbar buttons.
- The zoom range is limited while debug is running. Zoom details are available when debug is paused.

3.2.3.5 **SWV ITM Data Console and printf redirection**

The *SWV ITM Data Console* prints readable text output from the target application. Typically, this is done via `printf()` with output redirected to ITM channel 0. Other ITM channels can get their own console views.

To use the *SWV ITM Data Console* view, first enable one or more of the 32 ITM ports in the *Serial Wire Viewer settings* dialog.

Figure 222. SWV settings

IDE Serial Wire Viewer settings for NUCLEO-F401RE Debug (ST-LINK)

Clock Settings
 Core Clock: 84 MHz
 Clock Prescaler: 42
 SWO Clock: 2000.0 kHz

Trace Events
☐ CPI: Cycles per instruction ☐ EXC: Exception overhead
☐ SLEEP: Sleep cycles ☐ LSU: Load store unit cycles
☐ FOLD: Folded instructions ☐ EXETRC: Trace Exceptions

PC Sampling
☐ Enable Resolution: 16384 Cycles/sample

Timestamps
☒ Enable Prescaler: 1

Data Trace

Comparator 0	Comparator 1	Comparator 2	Comparator 3
<input type="checkbox"/> Enable	<input type="checkbox"/> Enable	<input type="checkbox"/> Enable	<input type="checkbox"/> Enable
Var/Addr: pos1	Var/Addr: pos2	Var/Addr: 0x0	Var/Addr: 0x0
Access: Write	Access: Write	Access: Read/Write	Access: Read/Write
Size: Word	Size: Word	Size: Word	Size: Word
Generate: Data Value + PC	Generate: Data Value + PC	Generate: Data Value	Generate: Data Value

ITM Stimulus Ports
 Enable port: 31 ☐ 24 ☐ 23 ☐ 16 ☐ 15 ☐ 8 ☐ 7 ☐ 0 ☒
 Privileged only ports: ☐ Port 31..24 ☐ Port 23..16 ☐ Port 15..8 ☐ Port 7..0

OK Cancel

The packets from the ITM ports are displayed in the *SWV ITM Data Console* view. The CMSIS function `ITM_SendChar()` can be used by the application to send characters to the port 0, and the `printf()` function can be redirected to use the `ITM_SendChar()` function.

The following describes how to setup `printf` redirection over ITM:

1. Configure first file `syscalls.c`. Usually, the `syscalls.c` file is located in the same source folder as `main.c`. If no `syscalls.c` file is available in the project, it can be copied from another STM32CubeIDE project. One way to get the file is to create a new STM32 empty project for the device. In the `src` folder, this project contains a `syscall.c` file. Copy this file to a source folder in the project where it is needed.

2. Inside the `syscalls.c` file, replace the `_write()` function with code calling `ITM_SendChar()` instead of `__io_putchar()`

```
int _write(int file, char *ptr, int len)
{
    int DataIdx;

    for (DataIdx = 0; DataIdx < len; DataIdx++)
    {
        //__io_putchar(*ptr++);
        ITM_SendChar(*ptr++);
    }
    return len;
}
```

3. Locate the `core_cmX.h` file, which contains the function `ITM_SendChar()`. The `core_cmX.h` file is included by the Device Peripheral Access Layer header file (for instance `stm32f4xx.h`, which in turn must be included in the `syscalls.c` file).

```
#include "stm32f4xx.h"
```

Use the *Include Browser* view to find the Device Peripheral Access Layer header file. Drop the core file in the *Include Browser* view, and check which files are including the `core_cmX.h` file.


4. Test by adding include `stdio.h` and call to `printf()` into the application. Make sure that `printf()` is not called too often.

```
#include <stdio.h>

printf("Hello World %d\n", pos1);
```


5. Start a debug session and enable **[ITM port 0]** in the *SWV ITM Data Console* view.
6. Open the *SWV ITM Data Console* view and start tracing using the red **[Start/Stop Trace]** button on the toolbar in this view.
7. Start the program. Print commands are logged to the *Port 0* tab in the view.

Figure 223. SWV ITM Data Console



8. It is possible to open new port x tabs (x from 1 to 31) by pressing the green **[+]** button on the toolbar. This opens the *Add Port* dialog. In the dialog select the **[ITM Port number]** to be opened to display it as a tab in the *SWV ITM Data Console* view.

Figure 224. SWV ITM port configuration



Note: Study the `ITM_SendChar()` function to learn how to write a function that transmits characters to another ITM port channel.

3.2.3.6 SWV Statistical Profiling

The *SWV Statistical Profiling* view displays statistics based on Program Counter (PC) sampling. It shows the amount of execution time spent within various functions. This is useful when optimizing code. The data can be copied and pasted into other applications. The view is updated when debugging is suspended.

1. Configure SWV to send Program Counter samples, as shown in [Figure 225](#). Enable **[PC Sampling]** and **[Timestamps]**.
 With the given **[Core Clock]** cycle intervals, SWV reports the Program Counter values to STM32CubeIDE. Set the **[PC Sampling]** to a high **[Cycle/sample]** value to avoid interface overflow.

Figure 225. SWV PC sampling enable

The screenshot shows the 'Serial Wire Viewer settings for NUCLEO-F401RE Debug (ST-LINK)' dialog box. The 'PC Sampling' section is checked, with 'Resolution' set to 16384 Cycles/sample. The 'Timestamps' section is also checked, with 'Prescaler' set to 1. The 'Data Trace' section shows four comparators, each with 'Generate' set to 'Data Value + PC'. The 'ITM Stimulus Ports' section shows 'Enable port' checkboxes for 31, 24, 23, 16, 15, 8, 7, and 0, all of which are currently unchecked. The 'Privileged only ports' section shows checkboxes for 'Port 31..24', 'Port 23..16', 'Port 15..8', and 'Port 7..0', all of which are currently unchecked. The 'OK' and 'Cancel' buttons are at the bottom right.

2. Open the *SWV Statistical Profiling* view by selecting **[Window]>[Show View]>[SWV Statistical Profiling]**.
 The view is empty since no data is collected yet.
3. Press the red **[Start/Stop Trace]** button to send the configuration to the board.
4. Resume program debugging. STM32CubeIDE starts collecting statistics about function usage via SWV when the code is executing in the target system.
5. Suspend (Pause) the debugging. The view displays the collected data. The longer the debugging session, the more statistics are collected.

Figure 226. SWV Statistical Profiling

Function	% in use	Samples	Start addr...	Size
main()	59.06%	48575	0x80005bd	0x100
readSpeed()	24.82%	20413	0x80004d5	0x46
readTemp()	16.04%	13191	0x800051b	0x2e
HAL_IncTick()	0.07%	56	0x8000b1d	0x34
SysTick_Handler()	0.01%	8	0x80009e5	0xc
writeSpeed()	0.00%	1	0x8000549	0x46

Overflow packets: 0 PC Samples: 82244

Note: A double-click on a function line in the SWV Statistical Profiling view opens the file containing the function in the editor.

The column information in the SWV Statistical Profiling is described in [Table 15](#).

Table 15. SWV Statistical Profiling columns details


Name	Description
Function	The name of the function which is calculated by comparing address information in SWV packets with the program <code>elf</code> file symbol information.
% in use	The calculated percentage of time the function is used.
Samples	The number of samples received from the function.
Start address	The start address for the function.
Size	The size of the function.

3.2.4 Change the SWV trace buffer size

The incoming SWV packets are saved in the Serial Wire Viewer trace buffer, which has a default maximum size of 2 000 000 packets. To trace more packets, this figure must be increased.

Select the **[Windows]>[Preferences]** menu. In the *Preferences* dialog, select **[STM32Cube]>[Serial Wire Viewer]**. Update **[Trace buffer size]** if needed.

Figure 227. SWV Preferences



The buffer is stored in the heap. The allocated heap is displayed by first selecting the **[Windows]>[Preferences]** menu. In the *Preferences* dialog, select **[General]**. Enable **[Show heap status]** to display the current heap and allocated memory in the bottom right corner of STM32CubeIDE. There is an upper limit to the amount of memory STM32CubeIDE can allocate. This limit can be increased to store more information during a debug session.

To update the memory limit, proceed as follows:

1. Navigate to the STM32CubeIDE installation directory. Open the folder in which the IDE is stored.
2. Edit the `stm32cubeide.ini` file and change the `-Xmx1024m` parameter to the desired size in megabytes.
3. Save the file and restart STM32CubeIDE.

3.2.5 Common SWV problems

The following issues can occur when attempting to debug with SWV tracing:

- SWV is not enabled in the debug configuration currently used.
- The SWV Trace is not started, the red **Start/Stop Trace** button on the toolbar in some SWV view needs to be pressed to enable SWV and send SWV configuration to the target board. Then start the program to receive SWV data. For some SWV views the program then needs to be stopped again to visualize received SWV information.
- The SWO receives an excess of data. Reduce the amount of data enabled for tracing.
- The JTAG probe, the GDB server, the target board, or possibly some other part, does not support SWV.

- The target **[Core Clock]** is incorrectly set. It is very important to select the right **[Core Clock]**. If the frequency of the target **[Core Clock]** is unknown, it can sometimes be found by setting a breakpoint in a program loop and open the *Expressions* view, when the breakpoint is hit. Click on **[Add new expression]**, type `SystemCoreClock` and press **[Enter]**. This is a global variable that, according to the CMSIS standard, must be set by the software to the correct speed of the **[Core Clock]**. In CMSIS standard libraries, a function called `SystemCoreClockUpdate()` can be included in `main()` to set the `SystemCoreClock` variable. Use the *Variable* view to track it.

Note: *If the software dynamically changes the CPU clock speed during runtime, this might cause SWV to stop as the clocking suddenly becomes wrong during execution.*

To make sure that all data is received, apply the following steps:


1. Open the SWV configuration. Disable all tracing except **[PC Sampling]** and **[Timestamps]**. Set the **[Resolution]** to the highest possible value.
2. Save, and open the *SWV Trace Log* view.
3. Start tracing.
4. Make sure that incoming packets can all be seen in the *SWV Trace Log* view.

3.3 Special Function Registers (SFRs)

3.3.1 Introduction to SFRs

Special Function Registers (SFRs) can be viewed, accessed and edited via the *SFRs* view. The view displays the information for the current project. Its content changes if another project is selected. To open the view from the menu, select the **[Window]>[Show View]>[SFRs]** menu command or use the **[Quick Access]** field, search for “SFR”, and select it from the views.


Figure 228. Open the *SFRs* view using the **[Quick Access]** field



3.3.2 Using the *SFRs* view

The *SFRs* view contains information about peripherals, registers and bit fields for the STM32 device used in the project. When debugging the project, the registers and bit fields are populated with the values read from the target. The view contains two main nodes, the Cortex®-M node and the STM32 node. The Cortex®-M node includes common Cortex®-M core information and the STM32 node includes the STM32 device specific peripherals.

Figure 229. SFRs view



The top of the *SFRs* view contains a search field to filter visible nodes, such as peripherals, registers, bit fields. Upon text entry in the search field, only the nodes containing this text are displayed.

The information at the bottom of the *SFRs* view displays detailed information about the selected line. For registers and bit fields, this includes **[Access permission]** and **[Read action]** information.

The **[Access permission]** contains the following details:

- **[RO]**(read-only)
- **[WO]**(write-only)
- **[RW]**(read-write)
- **[W1]**(writeOnce)
- **[RW1]**(read-writeOnce)

The **Read action** contains information only if there is a read action when reading the register or bit field:

- `[clear]`
- `[set]`
- `[modify]`
- `[modifyExternal]`

The toolbar buttons are located at the top-right corner of the *SFRs* view.

Figure 230. SFRs view toolbar buttons



The **[RD]** button in the toolbar is used to force a read of the selected register. It causes a read of the register even if the register, or some of the bit fields in the register, contains a `ReadAction` attribute set in the *SVD* file.

When the register is read by pressing the **[RD]** button, all the other registers visible in the view are read again also to reflect all register updates.

The program must be stopped to read registers.

The base format buttons (**[X16]**, **[X10]**, **[X2]**) are used to change the registers display base.

The **[Configure SVD settings]** button opens the *CMSIS-SVD Settings Properties Panel* for the current project.

The **[Pin]** button ("don't follow" selection) can be used to keep focus on the current displayed *SVD* file even if the *Project Explorer* view is switched to another project.

3.3.2.1


Favorite lists

During a debug session, the user is interested usually only in certain information about peripherals, registers, or bit fields related to a specific problem. Favorite lists help the user to organize registers into different tabs to better focus on a particular problem area.

To add a set of peripherals, registers, or bit fields to a favorite list, follow these steps:


1. Select a project.
2. Right-click on a node in the *SFRs* view and select **[Add as favorite...]**.

Figure 231. Debug - Addition of a node SFRs view as favorite




3. Use the dialog that opens to add the selected node to an existing favorite list or create a new list.

Figure 232. Debug - SFRs view favorite list creation pop-up



4. The new tab *Favorite1* contains only the selected node added to the view.

Figure 233. Debug - Favorite SFRs view




3.3.2.2 Live update

When debugging a project in the standard way, the program must be stopped to read the registers. With STM32CubeIDE, it is also possible to use the live update debug with the *SFRs* view collecting register values periodically, even when the target is running.


To use the live update debug, first enable the live channel before starting the debugging session.

Figure 234. Debug - Live channel checkbox



Then, right-click on the desired register node in the *SFRs* view and select **[Toggle live update]**.

Figure 235. Debug - Live update



3.3.2.3

Exporting registers


During an active debugging session, all registers and their corresponding values can be exported to a text file. This allows the user to have a snapshot of all registers, or of the desired registers selected in the favorite list, when the program is stopped at a defined point.

With this feature, the user can easily compare the values of registers between different execution points of the application. This is done using the diff utilities available for comparing previously exported files.

To export registers, perform the following steps in the halted debug session:

1. Select the tab relevant for export.
Exporting the entire device register map from the *All registers* tab might be time consuming. It is more convenient to use the favorites lists as the basis for export.
2. Select [**Export view data to file**] from the *SFRs* view toolbar.

Figure 236. Debug – Export view data to file




A *View export* dialog opens, where it is possible to define the destination of the export file.

Note that the exported file is placed by default in the `SFR_export` directory of the associated project as a `.txt` file. The file basename is incremented each time.

3. - Select [**Open generated file with associated editor**]>[OK].

Figure 237. Debug – Export destination file



To compare the register values between two different execution points:

1. Select the two files in the *Project Explorer* view.
2. Select [**Compare With**]>[**Each Other**] from the context menu.


3.3.3 Updating CMSIS-SVD settings

The *SFRs* view for a project can display two CMSIS-SVD (System View Description) files for this project:

- The default file selected by STM32CubeIDE is the SVD file for the selected device in the project
- The other file can be a custom SVD file made to visualize specific user hardware configuration

To update the settings, use the **[Configure SVD settings]** toolbar button in the *SFRs* view to open the *CMSIS-SVD Settings* properties.

Figure 238. SFRs CMSIS-SVD Settings



All SVD files must comply with the syntax outlined in the CMSIS-SVD specification available on Arm® website. If these requirements are not met, the *SFRs* view is likely not to show any register information.

The **[Device file]** field is used for the System View Description (SVD) file. This file must describe the whole device. Other views may fetch information from the SVD file pointed out by this field, therefore it is recommended to use this field only for SVD files containing full STM32 device description. Updated SVD files can be obtained from STMicroelectronics (refer to the *HW Model*, *CAD Libraries* and *SVD* columns in the device description section on the STMicroelectronics website at www.st.com).

The **[Custom file]** field can be used to define special function registers related to custom hardware, in order to simplify the viewing of different register states. Another possible use case is to create an *SFRs* favourites' file, containing a subset of the content in the **[Device file]**. This subset may be for instance composed of frequently checked registers. If a **[Custom file]** is pointed out, a new top-node in the *SFRs* view is created, which contains the **[Custom file]** related register information.

Both fields may be changed by the user and both fields may be used at the same time.

Note:

- It is possible to write new values in the value columns of registers and bit fields when these have write access permission.
- It is possible to use the *SFRs* view while the target is running when using the ST-LINK GDB server. However the **[Live expression]** option in the debug configuration must be enabled in this case.
- It is not possible to use *SFRs* view while the target is running when using OpenOCD or SEGGER J-Link.
- The *SFRs* view can also be useful in the C/C++ Editing perspective, however then only the names and addresses of the registers are displayed.

3.4 RTOS-aware debugging

Real-time operating systems (RTOS) add different kinds of objects to the design such as threads, semaphores, and timers. STM32CubeIDE includes dedicated set of views to handle Microsoft® Azure® RTOS ThreadX and FreeRTOS™ kernel objects.

These views visualize the status of the RTOS objects when stepping through the code or when the program hits a breakpoint during a debug session.

Note:

FreeRTOS is a trademark of Amazon in the United States and/or other countries.
 All other trademarks are the property of their respective owners.

3.4.1 Azure® RTOS ThreadX

The following views are available for ThreadX:


- ThreadX Thread List
- ThreadX Semaphores

- ThreadX Mutexes
- ThreadX Message Queues
- ThreadX Event Flags
- ThreadX Timers
- ThreadX Memory Block Pools
- ThreadX Memory Byte Pools

3.4.1.1 Finding the views

In the *Debugger* perspective, the ThreadX-related views are opened from the menu. Select the menu command **[Window]>[Show View]>[ThreadX]>[...]** or use **[Quick Access]** and search for “ThreadX” and select it from the views.

Figure 239. ThreadX views selectable from the menu



3.4.1.2 ThreadX Thread List view

The *ThreadX Thread List* view displays detailed information regarding all available threads in the target system. The thread list is updated automatically each time the target execution is suspended.

There is one column for each type of thread parameter, and one row for each thread. If the value of any parameter for a thread has changed since the last time the debugger was suspended, the corresponding row is highlighted in yellow.

Figure 240. ThreadX Thread List view (default)

Name	Priority	State	Run Count	Stack Start	Stack End	Stack Size	Stack Ptr	Stack Usage
Main Thread	5	SUSPENDED (MySemaphore_1)	1	0x24001634	0x24001833	512	0x240016cc	Disabled
System Timer Thread	0	SUSPENDED	0	0x24000a18	0x24000e17	1024	0x24000dcc	Disabled
Thread One	10	SUSPENDED (MyMutex_1)	1	0x2400183c	0x24001a3b	512	0x240018d4	Disabled
Thread Two	10	RUNNING	1	0x24001a44	0x24001c43	512	0x24001bfc	Disabled
Idle								

Due to performance reasons, the *Stack Usage* column is disabled by default. To enable the stack analysis, use the **[Toggle Stack Checking]** toolbar button (circled in pink in [Figure 241](#)) in the *ThreadX Thread List* view toolbar.

Figure 241. ThreadX Thread List view (Stack Usage enabled)

Name	Priority	State	Run Count	Stack Start	Stack End	Stack Size	Stack Ptr	Stack Usage
Main Thread	5	SUSPENDED (Event Flag)	2	0x240015a4	0x240017a3	512	0x24001614	512
System Timer Thread	0	SUSPENDED	505	0x24000984	0x24000d83	1024	0x24000c4c	1024
Thread One	10	READY	381	0x240017ac	0x240019ab	512	0x24001824	512
Thread Two	8	RUNNING	126	0x240019b4	0x24001bb3	512	0x24001b0c	512
Idle								

The column information in the *ThreadX Thread List* view is described in [Table 16](#).

Table 16. ThreadX Thread List details

Name	Description
N/A	A green arrow symbol indicates the currently running thread.
Name	The name assigned to the thread.
Priority	The thread priority.
State	The current state of the thread.
Run Count	The threads run counter.
Stack Start	The start address of the stack area.
Stack End	The end address of the stack area.
Stack Size	The size of the stack area (bytes).
Stack Ptr	The address of the stack pointer.
Stack Usage	The maximum thread stack (bytes). By default, ThreadX fills every byte of thread stacks with a 0xEF data pattern during thread creation. See the note below for more information.

Note: If the *Stack Usage* column contains the same values as the *Stack Size* column for all threads, the reason could be that the thread stack has not been filled with the 0xEF data pattern during task creation. This happens if the ThreadX kernel is built with stack data pattern filling disabled. Normally, a `<tx_user.h>` file is used, which contains a `TX_DISABLE_STACK_FILLING` define. Comment this define as shown in the example below and rebuild the project to solve the problem. It is good to know that the `<tx_user.h>` file also contains a `TX_ENABLE_STACK_CHECKING` define, which can be enabled to get run-time stack checking if stack corruption is detected. Additional information can be found in the ThreadX user guide.

Example of `tx_user.h` file from ThreadX header file with commented `TX_ENABLE_STACK_CHECKING` define:

```
/* Determine if stack filling is enabled. By default, ThreadX stack filling is enabled,
   which places an 0xEF pattern in each byte of each thread's stack. This is used by
   debuggers with ThreadX-awareness and by the ThreadX run-time stack checking feature. */

/* #define TX_DISABLE_STACK_FILLING */

/* Determine whether or not stack checking is enabled. By default, ThreadX stack checking is
   disabled. When the following is defined, ThreadX thread stack checking is enabled. If sta
   ck
   checking is enabled (TX_ENABLE_STACK_CHECKING is defined), the TX_DISABLE_STACK_FILLING
   define is negated, thereby forcing the stack fill which is necessary for the stack checkin
   g
   logic. */

/*#define TX_ENABLE_STACK_CHECKING*/
```

3.4.1.3 ThreadX Semaphores view

The *ThreadX Semaphores* view displays detailed information regarding all available resource semaphores in the target system. The view is updated automatically each time the target execution is suspended.

There is one column for each type of semaphore parameter, and one row for each semaphore. If the value of any parameter for a particular semaphore has changed since the last time the debugger was suspended, the corresponding row is highlighted in yellow.

Figure 242. ThreadX Semaphores view

Name	Count	Suspended
MySemaphore_1	0	Main Thread
MySemaphore_2	5	
MySemaphore_3	8	

Table 17. ThreadX Semaphores details

Name	Description
Name	The name assigned to the semaphore.
Count	The current semaphore count.
Suspended	The threads currently suspended because of the semaphore state.

3.4.1.4 ThreadX Mutexes view

The *ThreadX Mutexes* view displays detailed information regarding all available mutexes in the target system. The view is updated automatically each time the target execution is suspended.

There is one column for each type of mutex parameter, and one row for each mutex. If the value of any parameter for a particular mutex has changed since the last time the debugger was suspended, the corresponding row is highlighted in yellow.

Figure 243. ThreadX Mutexes view

Name	Owner	Owner Count	Suspended
MyMutex_1	Main Thread	1	Thread One, Thread Two
MyMutex_2		0	
MyMutex_3		0	

Table 18. ThreadX Mutexes details

Name	Description
Name	The name assigned to the mutex.
Owner	The thread that currently owns the mutex.
Owner Count	The mutex owner count (number of get operations performed by the owner thread).
Suspended	The threads currently suspended because of the mutex state.

3.4.1.5 ThreadX Message Queues view

The *ThreadX Message Queues* view displays detailed information regarding all available message queues in the target system. The view is updated automatically each time the target execution is suspended.

There is one column for each type of message queue parameter, and one row for each message queue. If the value of any parameter for a particular message queue has changed since the last time the debugger was suspended, the corresponding row is highlighted in yellow.

Figure 244. ThreadX Message Queues view

Name	Address	Capacity	Used	Free	Message size	Suspended
Message Queue One	0x240002b8	10	0	10	1	
Message Queue Two	0x2400003c	10	0	10	1	

Table 19. ThreadX Message Queues details

Name	Description
Name	The name assigned to the message queue.
Address	The address of the message queue.
Capacity	The maximum number of entries allowed in the queue.
Used	The current number of used entries in the queue.
Free	The current number of free entries in the queue.
Message size	The size (in 32-bit words) of each message entry.
Suspended	The threads currently suspended because of the message queue state.

3.4.1.6 ThreadX Event Flags view

The *ThreadX Event Flags* view displays detailed information regarding all available event flag groups in the target system. The view is updated automatically each time the target execution is suspended.

There is one column for each type of parameter, and one row for each event flag group. If the value of any parameter for a particular event flag group has changed since the last time the debugger was suspended, the corresponding row is highlighted in yellow.

Figure 245. ThreadX Event Flags view

Name	Flags	Suspended
Event Flag1	0	Main Thread
Event Flag2	0	

Table 20. ThreadX Event Flags details

Name	Description
Name	The name assigned to the event flag group.
Flags	The current value of the event flag group.
Suspended	The threads currently suspended because of the event flag group.

3.4.1.7 ThreadX Timers view

The *ThreadX Timers* view displays detailed information regarding all available software timers in the target system. The timers view is updated automatically each time the target execution is suspended.

There is one column for each type of timer parameter, and one row for each timer. If the value of any parameter for a particular timer has changed since the last time the debugger was suspended, the corresponding row is highlighted in yellow.

Figure 246. ThreadX Timers view

Name	Remaining	Re-init	Function
MyTimer_1	68	100	0x80005d1 <MyTimerFunction1>
MyTimer_2	72	200	0x80005f3 <MyTimerFunction2>
MyTimer_3	276	500	0x8000615 <MyTimerFunction3>

Table 21. ThreadX Timers details

Name	Description
Name	The name assigned to the timer.
Remaining	The remaining number of ticks before the timer expires.
Re-init	The timer re-initialization value (ticks) after expiration. It contains value 0 for one-shot timers.
Function	The address and name of the function that is called when the timer expires.

3.4.1.8 ThreadX Memory Block Pools view

The *ThreadX Memory Block Pools* view displays detailed information regarding all available memory block pools in the target system. The view is updated automatically each time the target execution is suspended.

There is one column for each type of parameter, and one row for each memory block pool. If the value of any parameter for a particular memory block pool has changed since the last time the debugger was suspended, the corresponding row is highlighted in yellow.

Figure 247. ThreadX Memory Block Pools view

Name	Address	Used	Free	Total	Block size	Pool size	Suspended
MyBlockPool_1	0x240005ec <P...	0	3	3	28	100	
MyBlockPool_2	0x240004ac <P...	0	4	4	40	200	
MyBlockPool_3	0x2400034c <P...	0	5	5	52	300	

Table 22. ThreadX Memory Block Pools details

Name	Description
Name	The name assigned to the memory block pool.
Address	The starting address of the memory block pool.
Used	The current number of allocated blocks.
Free	The current number of free blocks.
Total	The total number of memory block pools available.
Block size	The size (bytes) of each block.
Pool size	The total pool size (bytes).
Suspended	The threads currently suspended because of the memory block pool state.

3.4.1.9 ThreadX Memory Byte Pools view

The *ThreadX Memory Byte Pools* view displays detailed information regarding all available memory byte pools in the target system. The view is updated automatically each time the target execution is suspended.

There is one column for each type of parameter, and one row for each memory byte pool. If the value of any parameter for a particular memory byte pool has changed since the last time the debugger was suspended, the corresponding row is highlighted in yellow.

Figure 248. ThreadX Memory Byte Pools view

Name	Address	Used	Free	Size	Fragments	Suspended
Byte Pool	0x24000f84 "\214\021"	1664	6528	8192	7	

Table 23. ThreadX Memory Byte Pools details

Name	Description
Name	The name assigned to the memory byte pool.


Name	Description
Address	The starting address of the memory byte pool.
Used	The current number of allocated bytes.
Free	The current number of free bytes.
Size	The number of fragments.
Fragments	The size (bytes) of each block.
Suspended	The threads currently suspended because of the memory byte pool state.

3.4.1.10 **Azure® RTOS TraceX tool**

Important: *The Microsoft® Azure® RTOS TraceX tool (TraceX) only exists for Windows®.*

To open TraceX automatically upon data export, select the **[Windows]>[Preferences]** menu to associate the file type `.trx` with TraceX through the *Preferences* window as shown in Figure 249.

Figure 249. File associations



The Azure® RTOS ThreadX kernel can generate various system events into the MCU RAM buffer. These events can later be analyzed “*off target*” by the TraceX application. This requires an export of the RAM buffer to a suitable file format. Trace data can be exported using the [Export trace] button available from the menu of any Azure® RTOS ThreadX view as shown in Figure 250 and Figure 251.

Figure 250. RAM buffer export (1 of 2)

Name	Pri...	State	Run Count	Stack Start	Stack End	Stack Size	Stack Ptr	Stack Usa...	View Menu
sine wave	8	SLEEP (1)	124	0x24002...	0x24002...	1024	0x24002...	Disabled	
System Timer T...	0	SUSPENDED	123	0x24013...	0x24013...	1024	0x24013...	Disabled	
thread 0	1	SLEEP (10)	13	0x24000...	0x24000...	1024	0x24000...	Disabled	
thread 1	16	READY	1874	0x24000...	0x24000...	1024	0x24000...	Disabled	
→ thread 2	16	RUNNING	1876	0x24000...	0x24000...	1024	0x24000...	Disabled	
thread 3	8	SUSPENDED (semaph...	62	0x24000...	0x24001...	1024	0x24000f...	Disabled	
thread 4	8	SLEEP (2)	62	0x24001...	0x24001...	1024	0x24001...	Disabled	
thread 5	4	SUSPENDED (event fl...	13	0x24001...	0x24001...	1024	0x24001...	Disabled	
thread 6	8	SUSPENDED (mutex 0)	62	0x24001...	0x24001...	1024	0x24001...	Disabled	
thread 7	8	SLEEP (2)	62	0x24001...	0x24002...	1024	0x24001f...	Disabled	
Idle									

Figure 251. RAM buffer export (2 of 2)

Name	Pri...	State	Run Count	Stack Start	Stack End	Stack Size	Stack Ptr	Stack Usa...
sine wave	8	SLEEP (1)	124	0x24002...	0x24002...	1024	0x24002...	Disabled
System Timer T...	0	SUSPENDED	123	0x24013...	0x24013...	1024	0x24013...	Disabled
thread 0	1	SLEEP (10)	13	0x24000...	0x24000...	1024	0x24000...	Disabled
thread 1	16	READY	1874	0x24000...	0x24000...	1024	0x24000...	Disabled
→ thread 2	16	RUNNING	1876	0x24000...	0x24000...	1024	0x24000...	Disabled
thread 3	8	SUSPENDED (semaph...	62	0x24000...	0x24001...	1024	0x24000f...	Disabled
thread 4	8	SLEEP (2)	62	0x24001...	0x24001...	1024	0x24001...	Disabled
thread 5	4	SUSPENDED (event fl...	13	0x24001...	0x24001...	1024	0x24001...	Disabled
thread 6	8	SUSPENDED (mutex 0)	62	0x24001...	0x24001...	1024	0x24001...	Disabled
thread 7	8	SLEEP (2)	62	0x24001...	0x24002...	1024	0x24001f...	Disabled


There are four prerequisites to export traces:

- The Azure® RTOS ThreadX kernel must be built with trace enabled
 - The embedded STM32CubeMX editor provides GUI support to enable the trace events
- The function `tx_trace_enable()` must be called before any data can be exported
- The trace export operation must not be performed inside the kernel API to avoid data file corruption
- The RAM buffer can only be read when the target is halted

On run

When exporting, the export destination is prepopulated from the active debug context available at: `$PATH_TO_PROJECT/TraceX/$LAUNCH_CONFIGNAME.trx`. If previous trace data already exists, the user is prompted whether to overwrite them as shown in Figure 252.


Figure 252. Existing trace overwrite



On export

When exporting the data to TraceX, STM32CubeIDE reads the RAM buffer from the target. The corresponding data is then used to create a *.trx file, which can later be opened with the TraceX tool. By default, a TraceX directory is created in the project, containing the .trx file.

Figure 253. TraceX analysis



- Remember:**
- The export function only works once *TraceX* is initialized (`tx_trace_enable()`). The tool exports the last *N* trace events.
 - There is a risk of exported trace data corruption if the export is performed inside the kernel API. To avoid such a corruption, make sure that the export is performed when the target is at a suitable location. For instance, set a breakpoint outside the kernel API or configure the trace full callback.

3.4.2 FreeRTOS™

The following views are available for FreeRTOS™:

- *FreeRTOS Task List*
- *FreeRTOS Timers*
- *FreeRTOS Semaphores*
- *FreeRTOS Queues*

3.4.2.1 Requirements

To be able to populate the FreeRTOS™-related views with detailed information about the RTOS status, some files in the FreeRTOS™ kernel must be configured. The following sections describes some required configurations. Consult the *FreeRTOS reference manual* for detailed information.

3.4.2.1.1 Enable trace information

The define `configUSE_TRACE_FACILITY` in `freeRTOSConfig.h` must be enabled (set to 1). It results in additional structure members and functions to be included in the build and enables for instance stack checking in the *FreeRTOS Task List* view and lists the semaphore types in the *FreeRTOS Semaphores* view.

Example:

```
freeRTOSConfig.h
#define configUSE_TRACE_FACILITY 1
```

3.4.2.1.2 Add to registry

The application software must call the `vQueueAddToRegistry()` function to make the *FreeRTOS Queues* and *FreeRTOS Semaphores* views able to display objects. The function adds an object to the FreeRTOS™ *Queue registry* and takes two parameters, the first is the handle of the queue, and the second is a description of the queue, which is presented in FreeRTOS™-related views.

Example:

```
vQueueAddToRegistry(mailId, "osMailQueue");
vQueueAddToRegistry(osQueueHandle, "osQueue");
vQueueAddToRegistry(osSemaphoreHandle, "osSemaphore");
```

3.4.2.1.3 RTOS profiling information

To get valid RTOS run time statistics, the application must set up a run time statistics time base. The time-base clock is recommended to run at least 10 times faster than the frequency of the clock used to handle the RTOS tick interrupt. To enable the FreeRTOS™ collection of run time statistics, file `freeRTOSConfig.h` must include:

1. Define `configGENERATE_RUN_TIME_STATS` 1
2. Define `portCONFIGURE_TIMER_FOR_RUN_TIME_STATS()` to call the function that configures a timer to be used for profiling
3. Define `portGET_RUN_TIME_COUNTER_VALUE()` to call the function that reads the current value from the profiling timer

Example:

```
freeRTOSConfig.h
#define configGENERATE_RUN_TIME_STATS 1
#define portCONFIGURE_TIMER_FOR_RUN_TIME_STATS() configureRunTime()
#define portGET_RUN_TIME_COUNTER_VALUE() getRunTimeCounter()
```

Or, if a run time variable is available in the system:

```
freeRTOSConfig.h
#define configGENERATE_RUN_TIME_STATS 1
#define portCONFIGURE_TIMER_FOR_RUN_TIME_STATS() (RunTime=0UL)
#define portGET_RUN_TIME_COUNTER_VALUE() RunTime
```

If the *Run Time* column in the *FreeRTOS Task List* view displays N/A after making these three settings, the problem can arise if project is not built with optimization level -O0. The reason is quite likely found in the declaration in `tasks.c` of `ulTutortalRunTime`.

Example:

```
#if ( configGENERATE_RUN_TIME_STATS == 1 )
    PRIVILEGED_DATA static uint32_t ulTaskSwitchedInTime = 0UL;
    /*< Holds the value of a timer/counter the last time a task was switched in. */
    PRIVILEGED_DATA static uint32_t ulTotalRunTime = 0UL;
    /*< Holds the total amount of execution time as defined by the run time counter clock. */
#endif
```

Solutions:

- Either declare the variable as volatile:


```
PRIVILEGED_DATA volatile static uint32_t ulTotalRunTime = 0UL;
/*< Holds the total amount of execution time as defined by the run time counter clock.
*/
```

- Or simply change the optimization level only for `tasks.c` by
 1. Right-clicking it in *Project Explorer* view and open *Properties*
 2. Select **[Properties]>[C/C++ Build]>[Settings]>[Tool Settings]>[Optimization]**
 3. Set **[Optimization Level]** to **None (-O0)**

3.4.2.2 Finding the views

In the *Debugger* perspective, the FreeRTOS™-related views are opened from the menu. Select the menu command [Window]>[Show View]>[FreeRTOS]>[...] or use [Quick Access], search for “FreeRTOS” and select from the views.

Figure 254. FreeRTOS™-related views selectable from the menu



3.4.2.3 FreeRTOS Task List view

The *FreeRTOS Task List* view displays detailed information regarding all available tasks in the target system. The task list is updated automatically each time the target execution is suspended.

There is one column for each type of task parameter, and one row for each task. If the value of any parameter for a task has changed since the last time the debugger was suspended, the corresponding row is highlighted in yellow, as shown in the example in Figure 255.

Figure 255. FreeRTOS Task List (default)

Name	Priority (Base/...	Start of Stack	Top of Stack	State	Event Object	Min Free Stack	Run Time (%)
→ IDLE	0/0	0x200003c0	0x20000558 <ucHeap=1308>	RUNNING		Disabled	99%
LEDThread	3/3	0x20000150	0x20000308 <ucHeap=716>	SUSPENDED		Disabled	0%
Tmr Svc	2/2	0x20000630	0x200009b0 <ucHeap=2420>	BLOCKED	TmrQ	Disabled	1%

Due to performance reasons, stack analysis (the *Min Free Stack* column) is disabled by default. To enable stack analysis (refer to Figure 257), use the *Toggle Stack Checking* toolbar button in the *FreeRTOS Task List* view toolbar as shown in Figure 256.

Figure 256. FreeRTOS™ Toggle Stack Checking




Figure 257. FreeRTOS Task List (Min Free Stack enabled)

Name	Priority (Base/...	Start of Stack	Top of Stack	State	Event Object	Min Free Stack	Run Time (%)
→ IDLE	0/0	0x200003c0	0x20000560 <ucHeap=1316>	RUNNING		>256	99%
LEDThread	3/3	0x20000150	0x200002b8 <ucHeap=636>	DELAYED		>256	0%
Tmr Svc	2/2	0x20000630	0x200009b0 <ucHeap=2420>	BLOCKED	TmrQ	>256	1%

The *FreeRTOS Task List* view in Figure 257 contains a *Min Free Stack* column. The column information is changed to *Stack Usage* if the project is built with the following define set:

```
#define configRECORD_STACK_HIGH_ADDRESS 1
```

In this case, the full stack usage is presented according to the format *Used/Total(%Used)* as shown in Figure 258.

Figure 258. FreeRTOS Task List with ConfigRECORD_STACK_HIGH_ADDRESS enabled

Name	Priority (B...	Start of S...	Top of St...	State	Event Object	Stack Usage	Run Time...
→ IDLE	0/0	0x20000...	0x20000...	RUNNING		96B / 2052B (4.7%)	N/A
THREAD1	24/24	0x20001...	0x20001...	DELAYED		144B / 512B (28.1%)	N/A
THREAD2	24/24	0x20001...	0x20001...	DELAYED		144B / 512B (28.1%)	N/A
Tmr Svc	2/2	0x20000...	0x20000...	BLOCKED	TmrQ	168B / 1028B (16.3%)	N/A

The column information in the *FreeRTOS Task List* view is described in Table 24.

Table 24. FreeRTOS Task List details

Name	Description
N/A	A green arrow symbol indicates the task currently running.
Name	The name assigned to the task.
Priority (Base/Actual)	The task base priority and actual priority. The base priority is the priority assigned to the task. The actual priority is a temporary priority assigned to the task due to the priority inheritance mechanism.
Start of Stack	The address of the stack region assigned to the task.
Top of Stack	The address of the saved task stack pointer.
State	The current state of the task.
Event Object	The name of the resource that has caused the task to be blocked.
Min Free Stack ⁽¹⁾	The stack “high watermark”. Displays the minimum number of bytes left on the stack for a task. A value of 0 (most likely) indicates that a stack overflow has occurred. <i>Note:</i> This feature must be enabled in the “View” toolbar.
Run Time (%)	The run time statistics provide information on the percentage of time the task has been used. This can be used for profiling the system during development.

1. When the application is built with `configRECORD_STACK_HIGH_ADDRESS = 1`, the column name is changed to “Stack Usage”. It displays the stack usage in detailed format as “Used/Total(%Used)”.

3.4.2.4 FreeRTOS Timers view

The *FreeRTOS Timers* view displays detailed information regarding all available software timers in the target system. The view is updated automatically each time the target execution is suspended. There is one column for each type of timer parameter, and one row for each timer. If the value of any parameter for a timer has changed since the last time the debugger was suspended, the corresponding row is highlighted in yellow.

Figure 259. FreeRTOS Timers

Name	Active	Period	Type	Id	Callback
myTimerTEST	True	200	Auto-Reload	0x0	0x8000429 <osTimerCallback>

The column information in the *FreeRTOS Timers* view is described in [Table 25](#).

Table 25. FreeRTOS Timers details

Name	Description
Name	The name assigned to the timer.
Active	The active status information.
Period	The time (in ticks) between timer start and the execution of the callback function.
Type	The type of timer. Auto-reload timers are automatically reactivated after expiration. One-shot timers expire only once.
Id	The timer identifier.
Callback	The address and name of the callback function executed when the timer expires.

Note:

1. If no name appears in the Name field, check that the timer is created with a name. The first parameter when calling `xTimerCreate()` must contain the timer name string.
2. When using software timers, a `Tmr Svc` task and a `TmrQ` queue are created automatically. These objects are displayed in the *FreeRTOS Task List* view and *FreeRTOS Queues* view.

3.4.2.5

FreeRTOS Semaphores view

The *FreeRTOS Semaphores* view displays detailed information regarding all available synchronization objects in the target system, including:

- Mutexes
- Counting semaphores
- Binary semaphores
- Recursive semaphores

The view is updated automatically each time the target execution is suspended. There is one column for each type of semaphore parameter, and one row for each semaphore. If the value of any parameter for a semaphore has changed since the last time the debugger was suspended, the corresponding row is highlighted in yellow.

Figure 260. FreeRTOS Semaphores

Name	Address	Type	Size	Free	# Blocked tasks
osSemaphore	0x20000058	BINARY_SEMAPHORE	1	0	0

Note:

If the Type information displays N/A, make sure that the define `configUSE_TRACE_FACILITY` is enabled in file `FreeRTOSconfig.h`.

The column information in the *FreeRTOS Semaphores* view is described in [Table 26](#).

Table 26. FreeRTOS Semaphores details

Name	Description
Name	The name assigned to the semaphore.
Address	The address of the object.
Type	The type of the object.
Size	The maximum number of owning tasks.
Free	The number of free slots currently available.
#Blocked tasks	The number of tasks currently blocked waiting for the object.

3.4.2.6 FreeRTOS Queues view

The *FreeRTOS Queues* view displays detailed information regarding all available queues in the target system. The view is updated automatically each time the target execution is suspended. There is one column for each type of queue parameter, and one row for each queue. If the value of any parameter for a queue has changed since the last time the debugger was suspended, the corresponding row is highlighted in yellow.

Figure 261. FreeRTOS Queues

Name	Address	Max Length	Item Size	Current Length	# Waiting Tx	# Waiting Rx
osQueue	0x20000068	1	2	0	0	1

The column information in the *FreeRTOS Queues* view is described in [Table 27](#).

Table 27. FreeRTOS Queues details

Name	Description
Name	The name assigned to the queue in the queue registry.
Address	The address of the queue.
Max Length	The maximum number of items that the queue can hold.
Item Size	The size in bytes of each queue item.
Current Length	The number of items currently in the queue.
#Waiting Tx	The number of tasks currently blocked waiting to be sent to the queue.
#Waiting Rx	The number of tasks currently blocked waiting to be received from the queue.

3.4.3 RTOS-kernel-aware debug

The RTOS-kernel-aware debug in [STM32CubeIDE](#) supports the Microsoft® Azure® RTOS ThreadX and FreeRTOS™ operating systems using an RTOS proxy. The RTOS proxy is included in STM32CubeIDE and can be used with ST-LINK GDB server, OpenOCD, and SEGGER J-Link GDB server.

When RTOS-kernel-aware debugging is enabled and a debug session is started, all threads are listed in the *Debug* view. By selecting a thread in the *Debug* view, the thread current context is visualized in views. For instance, the *Variables*, *Registers*, *Editor* views reflect the active stack frame.

Figure 262 shows a debug session. The *ThreadX Thread List* view displays that the Message Queue Receiver Thread is RUNNING. This can also be seen in the *Debug* view. In the *Debug* view the `MsgSenderThreadTwo_Entry` function is selected, and the editor area displays that the thread is waiting in a sleep for 500 ms state.

Figure 262. RTOS-kernel-aware debug

The screenshot displays the ST-Link GDB server interface. The Project Explorer on the left shows the thread list with the following threads:

- Thread #2 (Message Queue Sender Thread One) 603979944 (Suspended : Container)
- Thread #3 (Message Queue Receiver Thread) 603980120 (RUNNING : Signal : SIGINT)
- Thread #4 (Message Queue Sender Thread Two) 603980296 (Suspended : Container)
- Thread #5 (System Timer Thread) 603980976 (Suspended : Container)

The main editor shows the source code for 'app_thread.c' with the 'MsgSenderThreadTwo_Entry' function selected. The function is currently in a sleep state for 500 ms.

```

195 * @param thread_input: Not used
196 * @retval None
197 */
198 void MsgSenderThreadTwo_Entry(ULONG thread_input)
199 {
200     ULONG Msg = TOGGLE_LED;
201     (void) thread_input;
202     /* Infinite loop */
203     while(1)
204     {
205         /* Send message to MsgQueueTwo. */
206         if (tx_queue_send(&MsgQueueTwo, &Msg, TX_WAIT_FOREVER) != TX_SUCCESS)
207         {
208             Error_Handler();
209         }
210         /* Sleep for 500ms */
211         tx_thread_sleep(500);
212     }
213 }
214
215 /**
216 * @brief Function implementing the MsgReceiverThread thread.
217 * @param thread_input: Not used
218 * @retval None
219 */
220 void MsgReceiverThread_Entry(ULONG thread_input)
221 {
222     ULONG RMsg = 0;
223     UINT status = 0;
224     (void) thread_input;
225     /* Infinite loop */
226     while (1)
227     {
228         /* Determine whether a message MsgQueueOne or MsgQueueTwo is available */
229         status = tx_queue_receive(&MsgQueueOne, &RMsg, TX_NO_WAIT);
230         if (status == TX_SUCCESS)
231         {
232             /* Check Message value */
233             if (RMsg != TOGGLE_LED)
234             {
235                 Error_Handler();
236             }
237             else
238             {
239                 BSP_LED_Toggle(LED_GREEN);
240             }
241         }
242     }
243 }

```

The ThreadX Thread List at the bottom shows the following threads:

Name	Pri...	State	Run Count	Stack Start	Stack End	Stack Size	Stack Ptr	Stack Usage
Message Queue Receiver Thread	10	RUNNING	875	0x2400139c	0x2400159b	512	0x240014fc	Disabled
Message Queue Sender Thread One	5	SLEEP (200)	74	0x24000f8c	0x2400118b	512	0x2400105c	Disabled
Message Queue Sender Thread Two	5	SLEEP (404)	30	0x24001194	0x24001393	512	0x24001264	Disabled
System Timer Thread	0	SUSPENDED	874	0x24000570	0x2400096f	1024	0x2400083c	Disabled
Idle								

To enable RTOS-kernel-aware debugging the *Debugger* tab in the *Debug Configurations* dialog contains settings to enable RTOS proxy, driver (RTOS ThreadX or FreeRTOS™), port (Cortex® core) and configuration of port number to use with the proxy.

The *RTOS* tab also contains a *Driver settings* selection to select the *Driver* (“ThreadX” or “FreeRTOS”) and the port used. The “Auto-detect” driver setting is still experimental.

Figure 263. RTOS-kernel-awareness debug configuration





Figure 264. ThreadX-kernel-awareness debug configuration



The port selection lists the supported cores. The items listed depend on the selected RTOS driver as displayed in Figure 265 and Figure 266.

Figure 265. ThreadX port configuration





Figure 266. FreeRTOS™ port configuration



Known limitations

- Live expressions must be disabled when used with the ST-LINK GDB server
- The *Registers* view content for swapped out threads is intermixed with active CPU context for some registers (all registers are not saved by the context switcher)
- The *Registers* view floating point registers are not updated correctly

3.5 Fault Analyzer

3.5.1 Introduction to the Fault Analyzer

The STM32CubeIDE Fault Analyzer feature interprets information extracted from the Cortex®-M nested vector interrupt controller (NVIC) in order to identify the reasons that caused a fault. This information is visualized in the *Fault Analyzer* view. It helps to identify and resolve hard-to-find system faults that occur when the CPU is driven into a fault condition by the application software.

Among such conditions are:

- Accessing invalid memory locations
- Accessing memory locations on misaligned boundaries
- Executing undefined instruction
- Division by zero


Upon fault occurrence, the code line where the fault occurred is displayed in the debugger. The view displays the reasons for the error condition. Faults are coarsely categorized into hard, bus, usage and memory faults.

- Hard and bus faults occur when an invalid access attempt is made across the bus, either of a peripheral register or a memory location
- Usage faults are the result of illegal instructions or other program errors
- Memory faults include attempts of access to an illegal location or violations of rules maintained by the memory protection unit (MPU)

To further assist fault analysis, an exception stack frame visualization option provides a snapshot of the MCU register values at the time of the crash. Isolating the fault to an individual instruction allows to reconstruct the MCU condition at the time the faulty instruction was executed.

In the *Debugger* perspective, the *Fault Analyzer* view is opened from the menu. Select the menu command **[Window]>[Show View]>[Fault Analyzer]** or use the **[Quick Access]** field, search for “*Fault Analyzer*” and select it from the views.

Figure 267. Open the *Fault Analyzer* view



3.5.2 Using the *Fault Analyzer* view


The *Fault Analyzer* view has five main sections, which can be expanded and collapsed. The sections contain different kinds of information for better understanding the reason that caused a particular fault to occur. The sections are:

- *Hard Fault Details*
- *Bus Fault Details*
- *Usage Fault Details*
- *Memory Management Fault Details*
- *Register Content During Fault Exception*

Figure 268 shows an example of the *Fault Analyzer* view when an error is detected. In this example, the error is caused by a project making a divide by zero with the debugger stopped in the `HardFault_Handler()`.

Opening the *Fault Analyzer* view when this happens displays the reason of the error. In the example, it displays **[Usage Fault Detected]** and **[Attempt to perform a division by zero (DIVBYZERO)]**.

Figure 268. Fault Analyzer view



- The *Editor* view is opened from the *Project Explorer* view on the fault location return address by using the information in the PC and LR registers in the stack and the symbol information in the debugged `elf` file.
- Clicking on the [Instruction stepping mode] toolbar opens the *Disassembly* view on the fault location return address by using the information in the PC and LR registers in the stack and the symbol information in the debugged `elf` file.

Figure 269 and Figure 270 show the *Editor* and *Disassembly* views opened using the toolbar buttons to find the fault location in the example.

Figure 269. Fault analyzer open editor on fault

```

142
143 int writeSpeed(int pos)
144 {
145
146     // update speed
147     speed= pos/tsec;
148     return speed;
149
150 }
  
```

Figure 270. Fault analyzer open disassembly on fault

```

0800055c: sdiv    r2, r1, r2
08000560: ldr     r1, [pc, #28] ; (0x8000580 <writeSpeed+56>)
08000562: ldr     r1, [r3, r1]
08000564: str     r2, [r1, #0]
148      return speed;
  
```

Note: The fault analyzer can be used on all STM32 projects. It requires no special code and no special build configuration. All data are collected for the Cortex®-M registers. The symbol information is read from the debugged `elf` file.

4 Code verification

4.1 Cyclomatic complexity

4.1.1 Introduction to the cyclomatic complexity view

The **STM32CubeIDE** cyclomatic complexity is a calculation of the built program complexity. It analyzes in detail the `.cyclo` files, generated by gcc, and the `.elf` file. It presents the resulting information in the view.

The view contains a list of all the functions included in the selected program. It provides the options to **[Hide dead code]** functions and **[Filter]** the visible functions. Use the **[Hide dead code]** selection to enable or disable the listing of dead code functions. If it is used, the **[Filter]** field restricts the display to the functions matching the filter key.

The view is populated with the complexity of each function included in the program, each line consisting of the *Function*, *Location*, and *Complexity* columns.

Figure 271. Cyclomatic complexity view

Function	Location	Complexity
HAL_RCC_OscConfig	stm32f4xx_hal_rcc.c:219	60
HAL_RCC_ClockConfig	stm32f4xx_hal_rcc.c:591	19
HAL_RCCEx_PeriphCLKConfig	stm32f4xx_hal_rcc_ex.c:2513	16
HAL_GPIO_Init	stm32f4xx_hal_gpio.c:164	15
HAL_RTC_SetTime	stm32f4xx_hal_rtc.c:686	7
HAL_RTC_SetDate	stm32f4xx_hal_rtc.c:845	6
main	main.c:54	6
RTC_EnterInitMode	stm32f4xx_hal_rtc.c:1799	5
HAL_RTC_Init	stm32f4xx_hal_rtc.c:249	5
HAL_RCC_GetSysClockFreq	stm32f4xx_hal_rcc.c:885	4
HAL_InitTick	stm32f4xx_hal.c:253	3
HAL_Delay	stm32f4xx_hal.c:389	3
HAL_NVIC_SetPriority	stm32f4xx_hal_cortex.c:163	3
HAL_RTC_WaitForSynchro	stm32f4xx_hal_rtc.c:1662	3
RTC_ExitInitMode	stm32f4xx_hal_rtc.c:1834	3
HAL_RTC_MspInit	stm32f4xx_hal_msp.c:53	3
HAL_SYSTICK_Config	stm32f4xx_hal_cortex.c:227	2
HAL_GPIO_WritePin	stm32f4xx_hal_gpio.c:410	2
RTC_BinaryToBcd2	stm32f4xx_hal_rtc.c:1860	2
HAL_RTC_GetTime	stm32f4xx_hal_rtc.c:800	2
HAL_RTC_GetDate	stm32f4xx_hal_rtc.c:994	2
BSP_LED_Init	stm32f4xx_nucleo.c:171	1
BSP_LED_Toggle	stm32f4xx_nucleo.c:235	1
SystemInit	system_stm32f4xx.c:132	1
HAL_MspInit	stm32f4xx_hal.c:219	1
HAL_Init	stm32f4xx_hal.c:157	1
HAL_IncTick	stm32f4xx_hal.c:312	1
HAL_GetTick	stm32f4xx_hal.c:323	1
HAL_NVIC_SetPriorityGrouping	stm32f4xx_hal_cortex.c:141	1
HAL_GPIO_TogglePin	stm32f4xx_hal_gpio.c:433	1
HAL_RTC_MspInit	stm32f4xx_hal_rtc.c:629	1
RTC_Bcd2ToByte	stm32f4xx_hal_rtc.c:1878	1
HAL_RTCEx_BKUPWrite	stm32f4xx_hal_rtc_ex.c:1245	1
HAL_RTCEx_BKUPRead	stm32f4xx_hal_rtc_ex.c:1268	1

Table 28. Cyclomatic Complexity details

Name	Description
Function	Function name.
Location	Indicates where the function is declared. It is possible to double-click on a line and open the file with the defined function in the editor.
Complexity	The number displays the complexity score of the function.

The sorting order can be changed by clicking on a column name.


Note: Double-click on a line that displays the file location and the line number in the table to open the function in the "Editor" view.

The small icon left of the function name in the column *Function* indicates the following:

- Green dot: the function has a score below the default complexity ceiling.
- Red dot: the function has a score that exceeds the default complexity ceiling.

To change the default complexity ceiling, go under **[Window]>[Preferences]**, select the *Build Views settings* option of *STM32Cube* in the left pane, and fill the field **[Complexity Ceiling]**.


Figure 272. Cyclomatic complexity - Default complexity ceiling preference



4.1.2 Using the cyclomatic complexity view


By default, the view *Cyclomatic Complexity* is found open in the *C/C++* perspective. If the view is closed, it can be opened from the menu by selecting **[Window]>[Show View]>[Cyclomatic complexity]**.

Figure 273. Cyclomatic complexity - Open the view



Another way to open the *Cyclomatic Complexity* view is to type “*cyclomatic complexity*” in the [Quick Access] search bar and select the view among the list of proposed views.

Figure 274. Cyclomatic complexity - Open the view (alternate)



The *Cyclomatic Complexity* view is populated when a built project is selected in the *Project Explorer*. The project must be built with the option [-f*cyclomatic-complexity*] enabled, otherwise the view cannot present any information.


The next section [Enable cyclomatic complexity information](#) explains how to set up the compiler to generate cyclomatic complexity information.

4.1.3 Enable cyclomatic complexity information

If the top of the view displays the message “No Cyclomatic Complexity information found, please enable in the compiler settings”, the build configuration must be updated for the compiler to generate the cyclomatic complexity information:

1. Open the project properties, for instance with a right-click on the project in the *Project Explorer* view
2. Select **[Properties]** and, in the dialog, select **[C/C++ Build]>[Settings]**
3. Select the *Tool Settings* tab
4. Select **[MCU GCC Compiler]>[Miscellaneous]**
5. Select **[Enable Cyclomatic Complexity (-fcyclomatic-complexity)]** as shown in [Figure 275](#)
6. Save the setting and rebuild the program

Figure 275. Cyclomatic complexity - Generate information per function



4.1.4 Using the filter field

The view proposes a field to search functions by their names. It selects all the function names matching the characters entered in the field.

Figure 276. Cyclomatic complexity - Function search field

Cyclomatic Complexity

STM32F4xx-Nucleo.elf - /STM32F4xx-Nucleo/Debug - Feb 16, 2023, 11:27:24 AM

☒ Hide dead code

RCC		
Function	Location	Complexity
● HAL_RCC_OscConfig	stm32f4xx_hal_rcc.c:219	60
● HAL_RCC_ClockConfig	stm32f4xx_hal_rcc.c:591	19
● HAL_RCCEx_PeriphCLKConfig	stm32f4xx_hal_rcc_ex.c:2513	16
● HAL_RCC_GetSysClockFreq	stm32f4xx_hal_rcc.c:885	4

5 Tools update


5.1 Installing updates and additional Eclipse® plugins

5.1.1 Check for updates

STM32CubeIDE checks for available updates regularly and opens the *Available Updates* dialog when a new update is detected. It is also possible to check for updates manually. Use menu **[Help]>[Check for Updates]** to check if new software is available.


When updates are found, select the update to install and press **[Next]**.

Figure 277. STM32CubeIDE available updates




Update details is displayed. Review and confirm the update. Press **Next**.

Figure 278. STM32CubeIDE update details



Review *Licenses* details are displayed. Review the licenses, select **[I accept the terms of the license agreements]** and press **[Finish]** to install the update.

Figure 279. STM32CubeIDE update review licenses




The progress bar displayed at the bottom of the STM32CubeIDE window shows the installation completion rate. Restart STM32CubeIDE when the update is finished.

5.1.2 Install from the Eclipse® market place


It is possible to install additional third-party Eclipse® plugins in STM32CubeIDE using the Eclipse Marketplace. To install from Eclipse Marketplace, select menu [Help]>[Eclipse Marketplace...].

Figure 280. Eclipse Marketplace menu



The *Eclipse Marketplace* dialog opens. Search for the plugin or use the tabs (*Recent*, *Popular*, *Favorites*) to find the software wanted and install it.

Figure 281. Eclipse marketplace




Wait until the installation is finished and restart STM32CubeIDE.

5.1.3 Install using [Install new software...]

Another way to install new software is to use menu **[Help]>[Install New Software...]**.


Note: When installing a new toolchain, it is recommended to use the Toolchain Manager described in [Section 2.3.1: Toolchain Manager](#).

Figure 282. Install new software menu




The *Install* dialog opens. Enter the plugin update site URL. If the URL is not known, use [--All Available Sites--].

Figure 283. Install new software



If no direct Internet connection is available, the plugin can be downloaded into an archive on a computer with an Internet connection, and then manually transferred to the computer with an STM32CubeIDE installation. Add the archived file by clicking on the **[Add...]** button and then select **[Archive and select the downloaded file]**.

Figure 284. Install new software from computer




Select the appropriate plugins and install the software. Restart STM32CubeIDE when installation is finished.

Remember: Not all Eclipse® plugins are compatible with STM32CubeIDE.

5.1.4 Uninstalling installed additional Eclipse® plugins


To uninstall a plugin that is no longer needed, select menu **[Help]>[About STM32CubeIDE]**.

Figure 285. About STM32CubeIDE



Press the **[Installation Details]** button to open the *STM32CubeIDE Installation Details* dialog.

Figure 286. Installation details




Select the plugin to uninstall in the *Installed Software* tab and press **[Uninstall...]**. Restart STM32CubeIDE when the uninstallation is finished.

5.1.5

Update to new CDT™

When a new version of STM32CubeIDE is installed based on a new version of Eclipse®, CDT™ or both, it is recommended to create a new workspace instead of using a former workspace. The following warning is displayed when trying to use an old workspace with a new STM32CubeIDE.

Figure 287. Older workspace version warning



6 References

Table 29. STMicroelectronics reference documents

Reference	Document short name	Description	Document source
[ST-01]	DB3871	STM32CubeIDE data brief	www.st.com
[ST-02]	RN0114	STM32CubeIDE release note	
[ST-03]	UM2553	STM32CubeIDE quick start guide	
[ST-04]	UM2563	STM32CubeIDE installation guide	
[ST-05]	UM2578	Migration guide from TrueSTUDIO to STM32CubeIDE	
[ST-06]	UM2579	Migration guide from the system workbench to STM32CubeIDE	
[ST-07]	UM2576	STM32CubeIDE ST-LINK GDB server	
[ST-08]	Getting started with projects based on the STM32MP1 Series in STM32CubeIDE ⁽¹⁾		Refer to STM32CubeIDE in the “Tools” section of wiki.st.com/stm32mpu
[ST-09]	AN5361	Getting started with dual-core STM32H7 MCUs in STM32CubeIDE	www.st.com
[ST-10]	AN6127	Getting started with STM32H7Rx/7Sx MCUs in STM32CubeIDE	
[ST-11]	AN5394	Getting started with STM32L5 MCUs in STM32CubeIDE	
[ST-12]	AN6265	Getting started with STM32N6 MCUs in STM32CubeIDE	
[ST-13]	AN5564	Getting started with dual-core STM32WL MCUs in STM32CubeIDE	
[ST-14]	AN4296	Use STM32F3/STM32G4 CCM SRAM with IAR Embedded Workbench®, Keil® MDK-ARM, STMicroelectronics STM32CubeIDE, and other GNU-based toolchains	
[ST-15]	AN5952	How to use CMake in STM32CubeIDE	
[ST-16]	SLA0048	License agreement applicable to STM32CubeIDE	
[ST-17]	UM1718	STM32CubeMX for STM32 configuration and initialization C code generation	
[ST-18]	UM2238	STM32 trusted package creation tool in the STM32CubeProgrammer tool set	

1. Legacy application note [AN5360](#) remains available on www.st.com.

Table 30. External reference documents

Reference	Description	Document source
[EXT-01]	GNU Assembler	GNU tool suite ⁽¹⁾
[EXT-02]	GNU Compiler Collection	
[EXT-03]	GNU C Library	
[EXT-04]	GNU C Preprocessor	
[EXT-05]	GNU Linker	
[EXT-06]	GNU Binary Utilities	
[EXT-07]	Red Hat Newlib C Library	
[EXT-08]	Red Hat Newlib C Math Library	
[EXT-09]	Newlib nano readme	
[EXT-10]	Debugging with GDB	
[EXT-11]	GDB Quick Reference Card	
[EXT-12]	GNU Tools for STM32 Patch list	Information Center

1. For GNU documentation principles, refer to www.gnu.org.

Revision history

Table 31. Document revision history

Date	Revision	Changes
24-Jul-2020	1	Initial release.
02-Nov-2020	2	Document updated for STM32CubeIDE v1.5.0: <ul style="list-style-type: none"> Only one toolchain is installed by default The <i>SFRs</i> view displays the Arm® Cortex® core registers node Debug with OpenOCD supports SWV and live expressions Added <i>Preferences - Build variables</i> Added <i>Toolchain Manager</i> Added <i>RTOS-aware debugging</i> with FreeRTOS™ information Added <i>General debug and run launch flow</i> Added <i>Post-build with makefile targets</i>
18-Feb-2021	3	Document updated for STM32CubeIDE v1.6.0: <ul style="list-style-type: none"> Added the <i>Azure RTOS ThreadX</i> section into the chapter <i>RTOS-aware debugging</i>. Reorganized the <i>FreeRTOS</i> section Updated the <i>Toolchain Manager</i> section for the support of local toolchains Updated the <i>Project C/C++ build settings</i> section, MCU toolchain selection moved Updated <i>Information Center</i> Updated the entire document for the “SWV packet” terminology Updated <i>References</i> Removed <i>Section 4.3.3 SWV Exception Timeline Graph</i>
05-Jul-2021	4	Document updated for STM32CubeIDE v1.7.0: <ul style="list-style-type: none"> Added <i>Section 2.7 Thread-safe wizard for empty projects and CDT projects</i> Added <i>Section 3.8 Import STM32 Cortex-M executable</i> Added <i>Section 6.3 RTOS-kernel-aware debug</i> Updated <i>Information Center – Home page</i> Updated <i>Headless build</i> description Updated <i>Section 2.5.6 Linker script</i> with new memory map layout figure and additional description Updated <i>Position-independent code</i> description Updated debug configuration descriptions for ST-LINK GDB server, OpenOCD, and SEGGER in <i>Debug using different GDB servers</i> Updated <i>FreeRTOS Task List</i> view
17-Nov-2021	5	Document updated for STM32CubeIDE v1.8.0: <ul style="list-style-type: none"> Added <i>Section 1.3.3 Videos</i> Added <i>Section 6.1.10 Azure RTOS TraceX tool</i> Updated <i>Section 2.2.2 Creating a new STM32 static library project</i> Removed <i>Section 1.3.3 Technical documentation</i> and <i>Section 1.3.4 Closing the Information Center</i>
13-Jun-2022	6	Document updated for STM32CubeIDE v1.10.0: <ul style="list-style-type: none"> Updated <i>Table 2. Key shortcut examples</i> Added a note in <i>Section 2.5.7.3 Place variables at specific addresses</i> about the possible linker garbage collection of nonreferenced variables Updated figures about debug configurations and tabs: <i>Figure 137</i>, <i>Figure 143</i>, <i>Figure 145</i>, <i>Figure 146</i>, <i>Figure 147</i>, <i>Figure 148</i>, <i>Figure 156</i>, <i>Figure 164</i>, and <i>Figure 223</i>
21-Nov-2022	7	Document updated for STM32CubeIDE v1.11.0: <ul style="list-style-type: none"> Updated <i>Section 2.2.2 Creating a new STM32 static library project</i> with the <i>Figure 52</i> featuring the new static lib project Updated the debug session name in <i>Section 3.2 Debug configurations</i>, <i>Section 3.3 Manage debug configurations</i>, and <i>Section 3.7 Run configurations</i>

Date	Revision	Changes
15-Feb-2023	8	Document updated for STM32CubeIDE v1.12.0: <ul style="list-style-type: none"> Added <i>Favorite lists</i>, <i>Live update</i>, and <i>Exporting registers</i> in <i>Section 5.2 Using the SFRs view</i> Added the <i>Cyclomatic complexity</i> chapter Updated <i>Figure 4. Help menu</i>, <i>Figure 5. Help - Information Center menu</i>, and <i>Section 1.3.3 Videos</i>
05-Jul-2023	9	Document updated for STM32CubeIDE v1.13.0: <ul style="list-style-type: none"> Added <i>Section 1.2.3 STM32CubeIDE user authentication</i> Updated <i>Figure 6. Help menu</i>, <i>Figure 7. Help - Information Center menu</i>, and <i>Figure 8. Information Center – Home page</i> Updated the figures from <i>Figure 204 to Figure 209</i> in the <i>Section 5.2 Using the SFRs view</i> Updated the figures from <i>Figure 264 to Figure 269</i> in the <i>Cyclomatic complexity</i> chapter Updated <i>Section 2.2.2 Creating a new STM32 static library project</i>. Added <i>Section 2.2.3 Creating a new CDT™ project</i> and <i>Section 2.2.4 Creating a new CMake project</i> Updated <i>Figure 143. Debug configuration debugger tab</i>, <i>Figure 150. ST-LINK GDB server debugger tab</i>, and <i>Figure 153. Debug configurations</i> Added <i>Debug authentication</i> in <i>Section 3.2.3 Debugger tab</i> Updated <i>Section 3.6.1 Live Expressions view</i> Updated <i>Figure 241. Fault Analyzer view</i>
13-Nov-2023	10	Document updated for STM32CubeIDE v1.14.0: <ul style="list-style-type: none"> Reorganized as detailed in <i>Appendix A Document reorganization from revision 9 to revision 10</i> Added the offline work description in <i>Section 1.2.3 STM32CubeIDE user authentication</i>
07-Mar-2024	11	Document updated for STM32CubeIDE v1.15.0: <ul style="list-style-type: none"> Added <i>Section 2.5: Build view setting</i> Updated <i>Figure 46</i>, <i>Figure 188</i>, and <i>Figure 267</i>
25-Jun-2024	12	Document updated for STM32CubeIDE v1.16.0: <ul style="list-style-type: none"> Updated <i>Section 1.2.3: STM32CubeIDE user authentication</i> Updated <i>Figure 2</i>, <i>Figure 10</i>, and <i>Figure 13</i>
14-Nov-2024	13	Document updated for STM32CubeIDE v1.17.0: <ul style="list-style-type: none"> Updated the user authentication scheme and description in <i>Section 1.2.3: STM32CubeIDE user authentication</i> and <i>Section 3.1.2.3: Debugger tab</i> Updated <i>Figure 2. STM32CubeIDE window</i> Updated <i>Section 1.2.4: Help system</i>
14-Feb-2025	14	Document updated for STM32CubeIDE v1.18.0: <ul style="list-style-type: none"> Updated <i>Figure 10</i>, <i>Figure 11</i>, and <i>Figure 13</i> in <i>Section 1.3: Information Center</i> Updated <i>Figure 16</i> in <i>Section 1.4.1.1: C/C++ perspective</i> Updated <i>Section 2.1.3.1: Importing an STM32CubeIDE project</i>, including <i>Figure 66</i>, <i>Figure 68</i>, and <i>Figure 69</i> detailing project import from the root directory or an archive file Updated <i>Figure 74</i> in <i>Section 2.2.1: Linking the project</i> Updated <i>Section 3.5.2: Using the Fault Analyzer view</i>, including the removal of the <i>Fault Analyzer toolbar</i> and its description Removed <i>Appendix A Document reorganization from revision 9 to revision 10</i>
17-Jun-2025	15	Document updated for STM32CubeIDE v1.19.0: <ul style="list-style-type: none"> Added <i>Section 3.1.6.7: Incremental flash memory programming</i> Updated <i>Table 29. STMicroelectronics reference documents</i>

Contents

1	Getting started	2
1.1	Product information	2
1.1.1	System requirements	3
1.1.2	Downloading the latest STM32CubeIDE version	3
1.1.3	Installing STM32CubeIDE	3
1.1.4	License	3
1.1.5	Support	3
1.2	Using STM32CubeIDE	3
1.2.1	Basic concepts and terminology	3
1.2.2	Starting STM32CubeIDE	5
1.2.3	STM32CubeIDE user authentication	6
1.2.4	Help system	8
1.3	<i>Information Center</i>	9
1.3.1	Accessing the <i>Information Center</i>	9
1.3.2	Home page	10
1.3.3	Videos	11
1.4	Perspectives, editors, and views	11
1.4.1	Perspectives	12
1.4.2	Editors	16
1.4.3	Views	16
1.4.4	<i>Quick Access</i> edit field	17
1.5	Configuration - Preferences	19
1.5.1	Preferences - Editors	20
1.5.2	Preferences - Code style formatter	21
1.5.3	Preferences - Network proxy settings	23
1.5.4	Preferences - Build variables	24
1.6	Workspaces and projects	25
1.7	Managing existing workspaces	25
1.7.1	Backup of preferences for a workspace	26
1.7.2	Copy preferences between workspaces	26
1.7.3	Keeping track of Java heap space	26
1.7.4	Unavailable workspace	27
1.8	STM32CubeIDE and Eclipse® basics	27
1.8.1	Keyboard shortcuts	27
1.8.2	Editor zoom in and zoom out	30
1.8.3	Quickly find and open a file	30

1.8.4	Branch folding	31
1.8.5	Block selection mode	31
1.8.6	Compare files	34
1.8.7	Local file history	36
2	Project set up and build	41
2.1	Create and import C/C++ projects	41
2.1.1	Introduction to projects	41
2.1.2	Creating a new STM32 project	41
2.1.3	Importing existing projects	55
2.2	Edit C/C++ projects	62
2.2.1	Linking the project	62
2.2.2	I/O redirection	85
2.2.3	Thread-safe wizard for empty projects and CDT™ projects	87
2.2.4	Position-independent code	94
2.2.5	Exporting projects	99
2.3	Build and compile C/C++ projects	101
2.3.1	<i>Toolchain Manager</i>	101
2.3.2	Configure the project build setting	112
2.3.3	Building the project	125
2.4	<i>Build Analyzer</i>	129
2.4.1	Introduction to the <i>Build Analyzer</i>	129
2.4.2	Using the <i>Build Analyzer</i>	130
2.5	Build view setting	137
2.6	<i>Static Stack Analyzer</i>	138
2.6.1	Introduction to the <i>Static Stack Analyzer</i>	138
2.6.2	Using the <i>Static Stack Analyzer</i>	140
3	Debug	147
3.1	Basic debug functions	147
3.1.1	Introduction to debugging	147
3.1.2	Debug configurations	148
3.1.3	Manage debug configurations	158
3.1.4	Debug using different GDB servers	159
3.1.5	Start and stop debugging	165
3.1.6	Debug features	175
3.1.7	Program and reset the device	178
3.1.8	Attach the debugger to the running target	179
3.1.9	Import STM32 Cortex®-M executable	182

3.2	Debug with Serial Wire Viewer tracing (SWV).....	186
3.2.1	Introduction to SWV and ITM	186
3.2.2	SWV debugging	187
3.2.3	SWV views	193
3.2.4	Change the SWV trace buffer size	202
3.2.5	Common SWV problems.....	203
3.3	Special Function Registers (SFRs).....	204
3.3.1	Introduction to SFRs	204
3.3.2	Using the <i>SFRs</i> view	204
3.3.3	Updating CMSIS-SVD settings	210
3.4	RTOS-aware debugging.....	210
3.4.1	Azure® RTOS ThreadX.....	210
3.4.2	FreeRTOS™	221
3.4.3	RTOS-kernel-aware debug	226
3.5	<i>Fault Analyzer</i>	229
3.5.1	Introduction to the Fault Analyzer	229
3.5.2	Using the <i>Fault Analyzer</i> view	230
4	Code verification	233
4.1	Cyclomatic complexity	233
4.1.1	Introduction to the cyclomatic complexity view	233
4.1.2	Using the cyclomatic complexity view	234
4.1.3	Enable cyclomatic complexity information	236
4.1.4	Using the filter field	236
5	Tools update	238
5.1	Installing updates and additional Eclipse® plugins	238
5.1.1	Check for updates	238
5.1.2	Install from the Eclipse® market place	240
5.1.3	Install using [Install new software...]	241
5.1.4	Uninstalling installed additional Eclipse® plugins	243
5.1.5	Update to new CDT™	244
6	References	245
	Revision history	247
	List of tables	252
	List of figures.....	253

List of tables

Table 1.	Examples of toolchain build variables	24
Table 2.	Key shortcut examples	28
Table 3.	Memory map layout	70
Table 4.	<i>Toolchain Manager</i> column details	102
Table 5.	<i>Toolchain Manager</i> button information	102
Table 6.	<i>Memory Regions</i> tab information	131
Table 7.	<i>Memory Regions</i> usage color	131
Table 8.	<i>Memory Details</i> tab information	132
Table 9.	<i>Static Stack Analyzer List</i> tab details	142
Table 10.	<i>Static Stack Analyzer Call Graph</i> tab details	143
Table 11.	<i>SWV Trace Log</i> columns details.	194
Table 12.	<i>SWV Exception Trace Log – Data</i> columns details	195
Table 13.	<i>SWV Exception Trace Log – Statistics</i> columns details	196
Table 14.	<i>SWV Data Trace</i> columns details	197
Table 15.	<i>SWV Statistical Profiling</i> columns details.	202
Table 16.	<i>ThreadX Thread List</i> details	212
Table 17.	<i>ThreadX Semaphores</i> details	213
Table 18.	<i>ThreadX Mutexes</i> details	214
Table 19.	<i>ThreadX Message Queues</i> details	214
Table 20.	<i>ThreadX Event Flags</i> details	215
Table 21.	<i>ThreadX Timers</i> details.	215
Table 22.	<i>ThreadX Memory Block Pools</i> details	216
Table 23.	<i>ThreadX Memory Byte Pools</i> details.	216
Table 24.	<i>FreeRTOS Task List</i> details	224
Table 25.	<i>FreeRTOS Timers</i> details	225
Table 26.	<i>FreeRTOS Semaphores</i> details	226
Table 27.	<i>FreeRTOS Queues</i> details	226
Table 28.	<i>Cyclomatic Complexity</i> details	233
Table 29.	STMicroelectronics reference documents	245
Table 30.	External reference documents	246
Table 31.	Document revision history	247

List of figures

Figure 1.	STM32CubeIDE key features	2
Figure 2.	STM32CubeIDE window	4
Figure 3.	STM32CubeIDE Launcher – Workspace selection	5
Figure 4.	Connection to myST menu	6
Figure 5.	Connection to myST window	6
Figure 6.	Registration or login window	7
Figure 7.	Authentication window from the current session	7
Figure 8.	Authentication window from the computer	8
Figure 9.	Help menu	9
Figure 10.	Help - Information Center menu	9
Figure 11.	Information Center – Home page	10
Figure 12.	Help – Tutorial video	11
Figure 13.	Information Center – Video browser page	11
Figure 14.	Reset perspective	12
Figure 15.	Toolbar buttons for switching perspective	12
Figure 16.	C/C++ perspective	13
Figure 17.	Debug perspective	13
Figure 18.	Device Configuration Tool perspective	14
Figure 19.	Remote System Explorer perspective	15
Figure 20.	New connection	15
Figure 21.	[Show View] menu	16
Figure 22.	Show View dialog	17
Figure 23.	Quick access	18
Figure 24.	Preferences	19
Figure 25.	Preferences - Text Editors	20
Figure 26.	Preferences - Formatter	21
Figure 27.	Preferences - Code style edit	22
Figure 28.	Preferences - Network Connections	23
Figure 29.	Preferences – Build variables	24
Figure 30.	Pre-build step using build variables	24
Figure 31.	Preferences - Workspaces	25
Figure 32.	Display of Java heap space status	26
Figure 33.	Workspace unavailable	27
Figure 34.	Shortcut keys	27
Figure 35.	Shortcut preferences	28
Figure 36.	Editor with text zoomed in	30
Figure 37.	Editor folding	31
Figure 38.	Editor block selection	32
Figure 39.	Editor text block addition	32
Figure 40.	Editor column block selection	33
Figure 41.	Editor column block paste	33
Figure 42.	Editor - Compare files	34
Figure 43.	Editor - File differences	35
Figure 44.	Local history	36
Figure 45.	Show local history	37
Figure 46.	File history	38
Figure 47.	Compare current history with local history	39
Figure 48.	Compare local file differences	40
Figure 49.	STM32 target selection	42
Figure 50.	STM32 board selection	42
Figure 51.	Project setup	43
Figure 52.	Firmware library package setup	44
Figure 53.	Initialization of all peripherals	44

Figure 54.	STM32CubeMX perspective opening	45
Figure 55.	Project creation started	45
Figure 56.	STM32CubeMX	46
Figure 57.	STM32 static library project	47
Figure 58.	New C/C++ project	48
Figure 59.	Project type	49
Figure 60.	Project configuration selection	50
Figure 61.	Project default target selector	51
Figure 62.	Project MCU/MPU selector	52
Figure 63.	Project target selection	53
Figure 64.	Project target selection (advanced)	53
Figure 65.	Project target change	54
Figure 66.	Import project	55
Figure 67.	Import dialog	56
Figure 68.	Import projects from the root directory	57
Figure 69.	Import projects from an archive file	58
Figure 70.	Import System Workbench projects (1 of 3)	59
Figure 71.	Import System Workbench projects (2 of 3)	60
Figure 72.	Import System Workbench projects (3 of 3)	60
Figure 73.	Import using project files association	61
Figure 74.	Linker documentation	62
Figure 75.	Linker run time library	63
Figure 76.	Linker newlib-nano library and floating-point numbers	64
Figure 77.	Linker discard unused sections	65
Figure 78.	Linker include additional object files	67
Figure 79.	Linker fatal warnings	69
Figure 80.	Linker memory output	80
Figure 81.	Linker memory output specified order	81
Figure 82.	Linker memory displaying file <code>readme</code>	82
Figure 83.	Include a library	83
Figure 84.	Add library header files to the include paths	84
Figure 85.	Set project references	85
Figure 86.	Select a wizard	88
Figure 87.	<i>Thread-Safe Solution</i> wizard	89
Figure 88.	Thread-safe source folder location	90
Figure 89.	Thread-safe strategy selection	91
Figure 90.	Thread-safe properties	92
Figure 91.	Thread-safe files	93
Figure 92.	Thread-safe error dialog	93
Figure 93.	Position independent code, <code>-fPIE</code>	95
Figure 94.	Debugging position independent code	98
Figure 95.	Export project	99
Figure 96.	Export dialog	100
Figure 97.	Export archive	100
Figure 98.	Open <i>Toolchain Manager</i>	101
Figure 99.	<i>Toolchain Manager</i>	101
Figure 100.	Install toolchain	102
Figure 101.	Check items to install	103
Figure 102.	Review items to install	103
Figure 103.	Review and accept licenses	104
Figure 104.	Security warning	104
Figure 105.	Restart to apply software update	104
Figure 106.	Toolchain installed	105
Figure 107.	Default toolchain	105
Figure 108.	Default toolchain updated	106

Figure 109.	Uninstall toolchain	107
Figure 110.	Uninstall details	107
Figure 111.	Software updates	108
Figure 112.	Toolchain uninstalled	108
Figure 113.	Add local toolchain	109
Figure 114.	Specify local toolchain location	110
Figure 115.	Specify local toolchain prefix	110
Figure 116.	Local toolchain added	111
Figure 117.	Edit local toolchain	111
Figure 118.	Toolchain network error	112
Figure 119.	Set the active build configuration using the toolbar	113
Figure 120.	Set active build configuration using right-click	114
Figure 121.	Set active build configuration using menu	115
Figure 122.	<i>Manage Configurations</i> dialog	115
Figure 123.	Create a new build configuration	116
Figure 124.	Updated <i>Manage Configurations</i> dialog	116
Figure 125.	Configuration deletion dialog	117
Figure 126.	Configuration renaming dialog	117
Figure 127.	Properties tabs	118
Figure 128.	Properties configurations	118
Figure 129.	Properties toolchain version	119
Figure 130.	Properties toolchain selection	119
Figure 131.	Properties tool MCU settings	120
Figure 132.	Properties tool MCU post-build settings	121
Figure 133.	Properties tool GCC assembler settings	122
Figure 134.	Properties tool GCC compiler settings	123
Figure 135.	Properties tool GCC linker settings	124
Figure 136.	Properties build steps settings	125
Figure 137.	Project build toolbar	125
Figure 138.	Project build console	126
Figure 139.	Project build all	126
Figure 140.	Project build-all configurations	127
Figure 141.	Headless build	128
Figure 142.	Parallel build	129
Figure 143.	Build analyzer	130
Figure 144.	<i>Memory Regions</i> tab	131
Figure 145.	<i>Memory Details</i> tab	132
Figure 146.	<i>Memory Details</i> sorted by size	134
Figure 147.	<i>Memory Details</i> search and filter	134
Figure 148.	Sum of sizes	135
Figure 149.	Show byte count	135
Figure 150.	Show hex count	136
Figure 151.	Copy and paste	136
Figure 152.	On request build view refresh mode	137
Figure 153.	Build view refresh button	138
Figure 154.	<i>Static Stack Analyzer List</i> tab	139
Figure 155.	<i>Static Stack Analyzer Call Graph</i> tab	139
Figure 156.	Open the <i>Static Stack Analyzer</i> view	140
Figure 157.	Enable generate per function stack usage information	141
Figure 158.	<i>Static Stack Analyzer List</i> tab	142
Figure 159.	<i>Static Stack Analyzer Call Graph</i> tab	143
Figure 160.	Function symbols in <i>Static Stack Analyzer</i>	144
Figure 161.	<i>Static Stack Analyzer List</i> tab using search	145
Figure 162.	<i>Static Stack Analyzer Call Graph</i> using search	145
Figure 163.	Copy and paste	146

Figure 164.	General debug and run launch flowchart	148
Figure 165.	Debug as STM32 MCU	149
Figure 166.	Debug as STM32 MCU menu	150
Figure 167.	Debug configuration main tab	151
Figure 168.	Debug configuration debugger tab	152
Figure 169.	GDB server command line dialog	153
Figure 170.	Debug configuration debugger tab (secure)	154
Figure 171.	Debug configuration - Debugger tab (debug authentication with password file)	155
Figure 172.	Debug configuration startup tab	156
Figure 173.	Add/Edit item	157
Figure 174.	Manage debug configurations	158
Figure 175.	Manage debug configurations toolbar	158
Figure 176.	ST-LINK GDB server debugger tab	160
Figure 177.	OpenOCD debugger tab	162
Figure 178.	SEGGER debugger tab	164
Figure 179.	Debug configurations	166
Figure 180.	Confirm perspective switch	167
Figure 181.	Debug perspective	167
Figure 182.	[Run] menu	169
Figure 183.	Debug toolbar	169
Figure 184.	Debug breakpoint	170
Figure 185.	Breakpoint properties	171
Figure 186.	Conditional breakpoint	171
Figure 187.	Reset the chip toolbar	172
Figure 188.	Restart configurations selection	172
Figure 189.	Restart configurations dialog	173
Figure 190.	Restart configurations dialog with additional command	174
Figure 191.	Select restart configuration	174
Figure 192.	Live Expressions	175
Figure 193.	Live expressions number format (selection)	175
Figure 194.	Live expressions number format (example)	176
Figure 195.	Incremental flash memory programming	178
Figure 196.	Run configurations startup tab	179
Figure 197.	Startup tab attach	181
Figure 198.	Cortex®-M executable import dialog	182
Figure 199.	STM32 Cortex®-M executable dialog	183
Figure 200.	STM32 Cortex®-M executable MCU/MPU selection	183
Figure 201.	STM32 Cortex®-M CPU and core	184
Figure 202.	Cortex®-M debug configuration for imported project	185
Figure 203.	Project explorer view with imported project	186
Figure 204.	SWV core clock	187
Figure 205.	SWV debug configuration	188
Figure 206.	SWV show view	189
Figure 207.	SWV Trace log view	189
Figure 208.	SWV [Configure Trace] toolbar button	190
Figure 209.	SWV settings dialog	190
Figure 210.	SWV [Start/Stop Trace] toolbar button	192
Figure 211.	SWV Trace Log PC sampling	192
Figure 212.	[Remove all collected SWV data] toolbar button	192
Figure 213.	SWV views selectable from the menu	193
Figure 214.	SWV views common toolbar	193
Figure 215.	SWV graph views extra toolbar	193
Figure 216.	SWV Trace Log PC sampling and exceptions	194
Figure 217.	SWV Exception Trace Log – Data tab	195

Figure 218.	SWV Exception Trace Log – Statistics tab	195
Figure 219.	SWV Data Trace configuration	196
Figure 220.	SWV Data Trace	197
Figure 221.	SWV Data Trace Timeline Graph	198
Figure 222.	SWV settings	199
Figure 223.	SWV ITM Data Console	200
Figure 224.	SWV ITM port configuration	200
Figure 225.	SWV PC sampling enable	201
Figure 226.	SWV Statistical Profiling	202
Figure 227.	SWV Preferences	203
Figure 228.	Open the SFRs view using the [Quick Access] field	204
Figure 229.	SFRs view	205
Figure 230.	SFRs view toolbar buttons	206
Figure 231.	Debug - Addition of a node SFRs view as favorite	206
Figure 232.	Debug - SFRs view favorite list creation pop-up	207
Figure 233.	Debug - Favorite SFRs view	207
Figure 234.	Debug - Live channel checkbox	208
Figure 235.	Debug - Live update	208
Figure 236.	Debug – Export view data to file	209
Figure 237.	Debug – Export destination file	209
Figure 238.	SFRs CMSIS-SVD Settings	210
Figure 239.	ThreadX views selectable from the menu	211
Figure 240.	ThreadX Thread List view (default)	211
Figure 241.	ThreadX Thread List view (Stack Usage enabled)	212
Figure 242.	ThreadX Semaphores view	213
Figure 243.	ThreadX Mutexes view	214
Figure 244.	ThreadX Message Queues view	214
Figure 245.	ThreadX Event Flags view	215
Figure 246.	ThreadX Timers view	215
Figure 247.	ThreadX Memory Block Pools view	216
Figure 248.	ThreadX Memory Byte Pools view	216
Figure 249.	File associations	218
Figure 250.	RAM buffer export (1 of 2)	219
Figure 251.	RAM buffer export (2 of 2)	219
Figure 252.	Existing trace overwrite	220
Figure 253.	TraceX analysis	220
Figure 254.	FreeRTOS™-related views selectable from the menu	223
Figure 255.	FreeRTOS Task List (default)	223
Figure 256.	FreeRTOS™ Toggle Stack Checking	223
Figure 257.	FreeRTOS Task List (Min Free Stack enabled)	223
Figure 258.	FreeRTOS Task List with ConfigRECORD_STACK_HIGH_ADDRESS enabled	224
Figure 259.	FreeRTOS Timers	224
Figure 260.	FreeRTOS Semaphores	225
Figure 261.	FreeRTOS Queues	226
Figure 262.	RTOS-kernel-aware debug	227
Figure 263.	RTOS-kernel-awareness debug configuration	228
Figure 264.	ThreadX-kernel-awareness debug configuration	228
Figure 265.	ThreadX port configuration	229
Figure 266.	FreeRTOS™ port configuration	229
Figure 267.	Open the Fault Analyzer view	230
Figure 268.	Fault Analyzer view	231
Figure 269.	Fault analyzer open editor on fault	232
Figure 270.	Fault analyzer open disassembly on fault	232
Figure 271.	Cyclomatic complexity view	233
Figure 272.	Cyclomatic complexity - Default complexity ceiling preference	234

Figure 273.	Cyclomatic complexity - Open the view	235
Figure 274.	Cyclomatic complexity - Open the view (alternate).	235
Figure 275.	Cyclomatic complexity - Generate information per function	236
Figure 276.	Cyclomatic complexity - Function search field	237
Figure 277.	STM32CubeIDE available updates	238
Figure 278.	STM32CubeIDE update details.	239
Figure 279.	STM32CubeIDE update review licenses	239
Figure 280.	Eclipse Marketplace menu	240
Figure 281.	Eclipse marketplace	241
Figure 282.	Install new software menu	242
Figure 283.	Install new software.	242
Figure 284.	Install new software from computer	243
Figure 285.	About STM32CubeIDE	243
Figure 286.	Installation details	244
Figure 287.	Older workspace version warning	244

IMPORTANT NOTICE – READ CAREFULLY

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgment.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. For additional information about ST trademarks, refer to www.st.com/trademarks. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2025 STMicroelectronics – All rights reserved